



4-246-840-71
030305AMI-NV-FM

Mini Hi-Fi Component System JAX-S7

OPERATING INSTRUCTIONS

En (English)

INSTRUCCIONES DE MANEJO

E (Español)



For assistance and information
visit us on the internet at
www.us.aiwa.com
call toll free 1-800-BUY-AIWA
(United States only)

Owner ' s Record

The model and serial numbers are located on the rear panel of the unit.
Record the serial number in the space provided below. Refer to them
whenever you call upon your Sony dealer regarding this product.

Model No.

Serial No.

WARNING


To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

To prevent fire, do not cover the ventilation of the apparatus with newspapers, table-cloths, curtains, etc. And don't place lighted candles on the apparatus.

To prevent fire or shock hazard, do not place objects filled with liquids, such as vases, on the apparatus.



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

CAUTION

The use of optical instruments with this product will increase eye hazard.



As an ENERGY STAR® Partner, Sony Corporation has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

PRECAUTIONS

WARNING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Note to CATV system installer:

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

On operating voltage

Before operating the system, check that the operating voltage of your system is identical with the voltage of your local power supply.

On safety

- The unit is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the unit itself has been turned off.
- Unplug the system from the wall outlet (mains) if it is not to be used for an extended period of time. To disconnect the cord (mains lead), pull it out by the plug. Never pull the cord itself.
- Should any solid object or liquid fall into the component, unplug the stereo system and have the component checked by qualified personnel before operating it any further.
- The AC power cord must be changed only at a qualified service shop.

On placement

- Place the unit in a location with adequate ventilation to prevent heat build-up the unit.
- Do not place the unit in an inclined position.
- Do not place the unit in locations where it is;
 - Extremely hot or cold
 - Dusty or dirty
 - Very humid
 - Vibrating
 - Subject to direct sunlight.

On heat buildup

- Although the unit heats up during operation, this is not malfunction.
- Place the unit in a location with adequate ventilation to prevent heat build-up in the unit.

If you continuously use this unit at a loud volume, the cabinet temperature of the top, side and bottom rises considerably. To avoid burning yourself, do not touch the cabinet.

On operation

- If the system is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lens inside the CD player. Should this occur, the system will not operate properly. Remove the CD and leave the system turned on for about an hour until the moisture evaporates.
- When you move the system, take out any discs.

Notes on discs

- Discs recorded on CD-R/RW drives may not be played back because of scratches, dirt., recording condition or the drive's characteristics.
- CD-R/RW discs which are not finalized at the end of recording cannot be played back.
- Do not attach adhesive label, etc. to either side of a CD-R/RW disc, as doing so may cause malfunction.
- Do not load an unrecorded CD-R/RW disc. The disc may be damaged.
- Discs with non-standard shapes (e.g., heart, square, star) cannot be played on this unit. Attempting to do so may damage the unit. Do not use such discs.
- DVD, SACD, CD-ROM and VCD cannot be played on this unit.

Music discs encoded with copyright protection technologies

This product is designed to playback discs that conform to the Compact Disc (CD) standard. Recently, various music discs encoded with copyright protection technologies are marketed by some record companies. Please be aware that among those discs, there are some that do not conform to the CD standard and may not be playable by this product.

If you have any questions or problems concerning your stereo system, please consult your nearest Aiwa dealer.

TABLE OF CONTENTS

| | |
|-------------------------------------|----|
| PRECAUTIONS | 2 |
| PREPARATIONS | 4 |
| PARTS AND CONTROLS | 5 |
| ADJUSTMENTS BEFORE OPERATIONS | 10 |
| CD OPERATIONS | 12 |
| MP3-CD OPERATIONS | 15 |
| TUNER OPERATIONS | 17 |
| TAPE OPERATIONS | 19 |
| SOUND ADJUSTMENTS | 22 |
| TIMER OPERATIONS | 24 |
| REFERENCE | 26 |


PREPARATIONS

Connection

Plug in the AC power cord to the AC power outlet after all other connections are made.


1 Connect the front speakers.

Connect the right front speaker (marked with "R") to the SPEAKERS R terminals and place it on the right side of the unit. Connect the left (marked with "L") to the SPEAKERS L terminals and place it on the left side. The speaker cords with the black stripes go to the \ominus terminals.



2 Connect the supplied antennas.

Connect the FM antenna to the Υ FM 75 Ω terminal and the AM antenna to the AM LOOP terminals.



3 Connect the AC power cord to a wall outlet.


When the AC power cord is connected to a wall outlet for the first time, DEMO appears in the display.

To deactivate the DEMO, press DISPLAY.

- Do not short-circuit the \oplus and \ominus speaker cord leads.
- Do not leave objects generating magnetism or objects affected by magnetism near the speakers.

Remote

Detach the battery compartment lid at the rear of the remote and insert two R6 (size AA) batteries with correct polarity.




- Replace the batteries with new ones when the operational distance between the remote and main unit becomes shorter.
- Remove the batteries if the unit is not going to be used for an extended period of time.
- The remote may not operate if it is used under intense sunlight, etc., or if its line of sight is obstructed.

PARTS AND CONTROLS

Main unit: rear

Refer to the pages indicated in parentheses for details.



❶ AM LOOP, γ FM 75 Ω terminals (4)

Plug in the supplied AM and FM antennas here.

❷ VIDEO (MD) jacks

Accepts analog sound signals from external equipment. Connect using an optional connecting cable with RCA phono plugs (red plug to R jack, white plug to L jack). Refer also to the operating instructions of your equipment. To switch function to external input, press VIDEO (MD).

Tip:

To change the displayed name for this function, turn the unit on, then hold down VIDEO (MD) and press POWER on the unit. Repeat the procedure to select "VIDEO" or "MD".


❸ SPEAKER terminals (4)

Connect the speaker cord of the supplied front speakers here.

❹ AC power cord (4)

Main unit: front

Refer to the pages indicated in parentheses for details.



En

❶ DISC CHANGE/DISC SKIP (12)

Rotates the CD trays.

❷ POWER \odot STANDBY/ON (10)

Switches the unit on and off (standby).

The red indicator flashes when receiving a signal from the remote.

❸ TAPE A/B (19)

Selects Tape function, and deck A or B.

TUNER BAND (17)

Selects Tuner function and the radio band.

VIDEO (MD) (5)

Selects the function of external equipment connected to VIDEO (MD) jacks.

CD (12)

Selects CD function.

❹ TREBLE/MIDDLE (22)

Enhances high or middle frequency sound.

❺ CD SYNC (21)

Starts Automatic CD dubbing.

REC PAUSE/START (20, 21)

Starts recording.

❻ PHONES jack

Plug in here an optional headphones set with a mini stereo plug ($\phi 3.5$ mm). Speaker output is canceled.

❽ DISC DIRECT PLAY 1-3 (12)

Selects a disc.

❾ \triangle OPEN/CLOSE (12)

Opens or closes the disc compartment.

❹ HEAVY, VOCAL, SALSA, TECHNO, HIP HOP, MANUAL (23)

Activates a graphic equalization curve.

❺ MODE (10-14, 21, 22)

Selects various modes (Play mode, etc.) when used in combination with ENTER and MULTI JOG.

ENTER (10-14, 17, 18, 21, 22, 24, 25)

Fixes the modes and the time (Play mode, etc.) when used in combination with MODE and MULTI JOG.

❻ MULTI JOG (10-14, 17, 21, 22, 24, 25)

CD: skips to a previous or a succeeding track.

Tuner: selects a preset station.

Clock and Timer: sets the time.

Selects the mode and the time when used in combination with MODE and ENTER.

❺ VOLUME (10)

Adjusts the volume.

13 BASS (22)

Adjusts low frequency sound.

SURROUND (23)

Switches surround on and off.

i-Bass (22)

Produces rich and clear low frequency sound.

14 DISPLAY (11, 12, 15)

Displays the time and the remaining time for CD.

When the unit is off, press DISPLAY to switch between DEMO, Clock and ECO display modes.

ALBUM ▼/▲ (15)

Selects a previous album or a succeeding album with MP3-CDs.

**15 I◀◀TUNING DOWN, ▶▶ITUNING UP
(◀◀, ▶▶) (12, 17, 19)**

CD: searches a track in fast forward or fast reverse playback when held down.

Tape: fast forwards or rewinds the tape.

Tuner: manually tunes down or up within the band.

II PAUSE (12, 20)

CD and Tapes: pauses playback.

▶ (12, 19)


CD and Tapes: starts playback.

■ STOP (12, 19)

CD and Tapes: stops playback.

Remote control

Refer to the pages indicated in parentheses for details.



Buttons with the same or similar names with the main unit basically have the same function.

1 POWER (10)

2 1-0/10, +10 (12, 14, 15)

Selects a CD track of the specified number.

The numbered buttons take on these functions below when pressed together with SHIFT held down:

EDIT (21)

Enters Automatic CD dubbing mode when pressed in stop mode.

BAND (17, 18)

Selects Tuner function and the radio band.

TAPE A/B (19)

Selects Tape function, and deck A or B.

SPECTRUM (10)

Changes the spectrum analyzer display.

TUNER MODE (19)

Switches between stereo or monaural FM reception.

GEQ (23)

Enters Graphic Equalizer setting mode.

TUNER MEMORY (17)

Tuner: stores the received station in to preset.

SURROUND (23)

Switches surround on and off.

3 ◀▶ (12, 17, 22–25)

CD: selects a track.

Tuner: selects a preset station.

BASS, MID and TREBLE: adjusts the level.

Clock and Timer: sets the time.

4 ALBUM ∨/∧ (15)

Selects a previous album or a succeeding album.

5 PLAY MODE (13, 14)

CD: selects a playback mode.

Tape: selects a playback mode

REPEAT (13)

Enters CD repeat playback mode.

ENTER

6 CLOCK/TIMER/SET (24, 25)

Enters timer setting mode.

CLOCK/TIMER/SELECT (24, 25)

Selects timer playback, timer recording or timer off.

7 DISPLAY (11, 12, 15)

Displays the time and the remaining time for CD.

When the unit is off, press DISPLAY to switch between DEMO, Clock and ECO display modes.

8 SHIFT

Hold down when pressing a numbered button to change its function to that printed above the number.

e.g.)

"Press **SHIFT+BAND** on the remote" indicates "Hold down SHIFT and press '2' (BAND)". Doing so makes you be able to select Tuner function and the radio band.

9 FUNCTION

Switches the active function among CD, TAPE, TUNER and VIDEO (MD).

10 DISC SKIP (12, 14)

Select a disc.

11 ►/◄► (12–14)

CD and Tape: starts playback.



CD and Tape: stops playback.

◄◄, ►► (12, 17, 19)

CD: searches a track in fast forward or fast reverse playback when held down.

Tape: fast forwards or rewinds the tape.

Tuner: manually tunes down or up within the band.

II (12, 19)

CD and Tape: pauses playback.

12 SLEEP (24)

Switches the sleep-timer on/off and selects the duration.

13 VOLUME (+, -) (10)

Adjusts the volume.

14 SOUND (22)

Selects BASS, MID or TREBLE setting mode


CLEAR (14)

Clears a track of the CD programed playback.

Note

The buttons not explained above (**KARAOKE**) do not operate for this unit.

ADJUSTMENTS BEFORE OPERATIONS



En

Power

Turning the unit on

Press POWER ϕ STANDBY/ON (POWER on the remote). Pressing TAPE A/B, TUNER/BAND, VIDEO (MD) or CD also turns the unit on (Direct Play Function.)

Turning the unit off

Press POWER ϕ STANDBY/ON again. The unit goes into standby.

Volume

Turn VOLUME (Press VOLUME +, - on the remote). Adjust from 0 (minimum) to 30 and MAX (maximum).

Tip:

Volume level setting is retained during power-off standby: If the unit is turned off with the volume set to 17 or more, it is automatically set to 16 the next time the unit is turned on.

Spectrum analyzer display

You can change the spectrum analyzer display.

- 1 Press MODE repeatedly until "SPECTRUM" appears in the display when the unit is turned on and then press ENTER within 6 seconds.
- 2 Turn MULTI JOG to select one of the three spectrum analyzer displays (PATTERN 1, 2 and 3), then press ENTER within 6 seconds.

On the remote, press SHIFT+SPECTRUM repeatedly.

Dimmer

Adjusts the brightness of the display.

- 1 Press MODE repeatedly until "DIMMER" appears in the display when the unit is turned on and then press ENTER.
- 2 Turn MULTI JOG to select one of the four dimmer modes "DIMMER 0" to "DIMMER 3" and then press ENTER.
"DIMMER 0" is the brightest and "DIMMER 3" is the dimmest.
If there is no MULTI JOG or button operation within 6 seconds, the setting is canceled.

To cancel the dimmer

Repeat the above and select "DIMMER 0" in step 2 .

Setting the clock

Use the remote.

- 1 Press CLOCK/TIMER/SET.
Go to step 3 when the time appears and the 'hour' flashes.
- 2 Press ◀◀ or ▶▶ repeatedly until "CLOCK" appears in the display and then press ENTER.
- 3 Press ◀◀ or ▶▶ repeatedly to set the hour and then press ENTER.
- 4 Press ◀◀ or ▶▶ repeatedly to set the minute and then press ENTER.
The time display stops flashing and the clock starts from 00 seconds.

• MULTI JOG is also available in place of ◀◀ or ▶▶.

To display the time

Press DISPLAY. The time will be displayed for 6 seconds.

Tip:

"AM 12:00" indicates midnight and "PM 12:00" noon.

If " - :- - " appears when the unit is turned off

There has been a power interruption. Re-set the clock.

Display mode (when off)

You can select what is displayed when the unit is off. While the unit is off, press DISPLAY repeatedly to select one of three display modes, DEMO, CLOCK or ECO, as explained below:

DEMO mode

You can enjoy DEMO in the display when the unit is turned off.

Press DISPLAY until DEMO is displayed when the unit is turned off.

Clock mode

Displays the time while the unit is off.


Press DISPLAY until the time is displayed when the unit is turned off.

ECO mode

Saves power while the unit is off.

Press DISPLAY until the screen goes blank when the unit is turned off.

CD OPERATIONS



To replace disc(s) during playback without interruption

While one disc is being played back, press DISC CHANGE/DISC SKIP so that the compartment opens, replace disc(s) with other one(s), and press DISC CHANGE/DISC SKIP to close the compartment.

En

This unit plays back finalized CD-R/RW discs as well as audio CDs.

Playback

1 Press CD and load disc(s).

Press **▲ OPEN/CLOSE** to open the disc compartment and place one or two disc(s) with the labelled side up.

To place three discs, press DISC CHANGE/DISC SKIP so that the trays rotate, then place the third one. Lastly, close the compartment with **▲ OPEN/CLOSE**.

- When loading an 8-cm (3-inch) disc, place it on the inner circle of the tray.

2 Press **▶ (▶/◀▶)** on the remote).

The DISC DIRECT PLAY button slowly pulses to indicate the currently playing disc.

To stop playback

Press **■**.

To pause playback

Press **⏸**. Press again to resume playback.

To select a track

Turn MULTI JOG, or press **◀◀** or **▶▶** on the unit, or press **◀◀◀** or **▶▶▶** on the remote repeatedly.

With the numbered buttons on the remote,

- To select track 10, press 0/10.
- To select track 20, press +10, +10 and 0/10.
- To select track 25, press +10, +10 and 5.

To search (playback in fast forward or fast reverse)

Hold down **◀◀** or **▶▶**. Release at the desired point.

To select a disc

Press DISC DIRECT PLAY 1-3 or DISC SKIP on the remote.

To display the remaining time of the track or the disc

Press DISPLAY repeatedly during playback.

The display changes cyclically as follows:

- Track number and elapsed playing time of the current track
- Track number and remaining time of the current track
- Remaining time of the current disc (only for one disc playback)
- Clock display (for 6 seconds)
- Presently selected sound equalization curve

Repeat playback

Plays all the tracks or one track on the discs repeatedly.

- 1 Press MODE repeatedly until "REPEAT" appears in the display and then press ENTER.
- 2 Turn MULTI JOG to select one of the two repeat modes as below or "REP OFF", and then press ENTER.
 - **REP ALL:**
For all the tracks on one desired disc or all discs up to 5 times. "↺" lights up.
 - **REP 1:**
For a single track only. "↺1" lights up.

If there is no MULTI JOG or button operation within 6 seconds, the setting is canceled.

- 3 Press ►/◄ (on the remote).

On the remote, press REPEAT repeatedly until "↺" or "↺1" appears and carry out step 3.

To cancel repeat playback

Carry out step 1 and 2, and select "REP OFF" in step 2.
On the remote, press REPEAT repeatedly until "↺" and "↺1" disappear.

Selecting playback mode

You can select one or all of the discs to playback.

- 1 In the stop mode, press MODE repeatedly until "PLAYMODE" appears in the display and then press ENTER.
- 2 Turn MULTI JOG to select one of the three play modes and then press ENTER.
 - **ALL DISCS CONTINUE:** Selections are played from all discs in order.
 - **1 DISC CONTINUE:** Selections are played from one disc only.
 - **1 ALBUM CONTINUE:** Selections are played from one MP3 album only. (When an Audio CD is being played, this mode is the same as 1 DISC CONTINUE.)

On the remote, press PLAY MODE repeatedly until the desired playback mode displays.

Shuffle playback

Shuffle playback plays all the tracks on one or all the discs in random order.


- 1 In the stop mode, press MODE repeatedly until "PLAYMODE" appears in the display and then press ENTER.
- 2 Turn MULTI JOG to select one of the three play modes and then press ENTER.
 - **ALL DISCS SHUFFLE:** Selections are played from all discs in random.
 - **1 DISC SHUFFLE:** Selections are played from one disc in random order.
 - **1 ALBUM SHUFFLE:** Selections are played from one MP3 album in random order. (When an Audio CD is being played, this mode is the same as 1 DISC SHUFFLE.)

On the remote, press PLAY MODE repeatedly until the desired playback mode displays.

To cancel shuffle playback

Carry out step 1 and 2 and select "ALL DISCS CONTINUE", "1 DISC CONTINUE" or "1 ALBUM CONTINUE" in step 2.

- Although repeat playback is not possible during ALL DISCS SHUFFLE, repeat playback during 1 DISC SHUFFLE is possible.



Programed playback

You can program the unit to playback selected tracks from one or more discs in any order you specify.

1 In the stop mode, press **MODE** repeatedly until “**PLAYMODE**” appears in the display and then press **ENTER**.

2 Turn **MULTI JOG** to select “**PROGRAM**” and then press **ENTER**.
“**PGM**” lights up.

If there is no **MULTI JOG** or button operation within 6 seconds, the setting is canceled.

3 Press **DISC DIRECT PLAY 1-3** to select a disc.
Go to the next step when the tray stops rotating.

On the remote, press **DISC SKIP**.

- If you press **ENTER** after pressing **DISC DIRECT PLAY 1-3** to select a disc, the complete disc is programmed to play.
- If you press **ENTER** after you select a MP3 album (see “To select an album” on page 15), the complete album is programmed to play.

4 Turn **MULTI JOG** to select a track and then press **ENTER**.

The selected track number and the program number appear in the display.

On the remote, press **◀◀** or **▶▶** and then press **ENTER** or press the numbered buttons:

- To select the track 10, press 0/10.
- To select the track 20, press +10, +10 and 0/10.
- To select the track 25, press +10, +10 and 5.

5 Repeat step 3 and 4 to program other tracks.

6 Press **▶(▶/◀▶)** on the remote).

On the remote, press **PLAY MODE** repeatedly until “**PGM**” lights up and carry out step 3 to 6.

- During programed playback, you cannot select a disc or a track with the numbered buttons.
- If the total playback time of the program exceeds 99:59 minutes, or if a track with a track number exceeding 20 is programed, the playing time is displayed as “-:-”.
- You cannot program more than 25 tracks. “**FULL**” is displayed.

To clear a track

Press **■** (CLEAR on the remote) in stop mode. A track is cleared from the end of the program.

To add tracks to the program

Repeat step 1 to 4 before starting playback. The tracks are added to the end of the program.

To cancel programed playback


Carry out step 1 and 2 and select “**ALL DISCS CONTINUE**”, “**1 DISC CONTINUE**” or “**1 ALBUM CONTINUE**” in step 2.

- The program contents are retained even if the program is canceled or after programed playback finishes. The same program plays back if you carry out step 1, 2 and 6.

Notes on CDs

- Do not place more than one disc on one tray.
- Do not tilt the unit with discs loaded.

MP3-CD OPERATIONS



Playback

This unit plays back MP3-CDs: discs recorded with MP3 tracks (files). Basic operations for MP3-CDs are mostly the same as those in “CD OPERATIONS”. This section explains MP3-CD OPERATIONS where there is additional information or exceptions to the information in “CD OPERATIONS”. Before playing an MP3-CD, also refer to “Descriptions of MP3” for the details of MP3.

To select an album

Press ALBUM ▼ or ▲ (▼ or ▲ on the remote).

To select a track on the remote

When the album has more than 99 tracks, press the numbered buttons in the following way to select a track.

- To select the track 100, press +10, 1, 0/10 and 0/10.
- To select the track 147, press +10, 1, 4 and 7.

To display the title of the album and track in the display

Press DISPLAY during playback.

The display changes in the following order:

- Track number being played and elapsed playing time
- Track (file) name being played or ID3 information*
- Album name* (for 2 seconds)
- Clock display (for 6 seconds)
- Presently selected sound equalization curve

* ID3 information and album name are not displayed if they are not registered.

Descriptions of MP3

An MP3 file stores audio data compressed using MPEG1/2, the audio layer-3 file-coding scheme.

In this manual, CDs, CD-R discs and CD-RW discs are all referred to as “discs”. We refer to what are called “folder” and “file” in PC terminology as “album” and “track”.

Notes on playing MP3 files

- An MP3 track must be recorded on a disc in the format compliant with ISO 9660. Note, however, that the unit may not play tracks in the order they were recorded.
- The maximum allowable number of tracks and albums in a disc are as follows:
 - number of tracks: 300 (including number of albums)
 - number of albums: 300
- The maximum allowable depth of nested albums is 8.
- It may take 30 seconds or more before the unit can start play of MP3 tracks, depending on the number of recorded tracks and the complexity of the album tree.
- The unit cannot play MP3 tracks recorded using a packet writing utility.
- The unit can play MP3 tracks having a file extension “.mp3”.
- If you play a non-MP3 track that has the “.mp3” file extension, you may hear some noise.

En

Notes on display indications during play

- Up to 32 characters are displayed for the title of an album or a track. If ID3TAG version 1.X was applied to record additional information for an MP3 track, up to 30 characters showing track title is displayed. However, this unit does not support ID3TAG version 2.X. Characters other than uppercase letters ("A" to "Z") and numerals ("0" to "9") may not be displayed correctly.
- The elapsed playing time may not be displayed correctly for MP3 tracks.


Terminology

- **ISO 9660**
ISO stands for the "International Organization for Standardization". ISO 9660 determines the file structure for the CD-ROMs. This unit can play MP3 files recorded in the format compliant with ISO 9660.
- **Nesting of folders (albums)**
To organize data files stored in a PC, you can store related files in a folder. A folder can contain other folders as well as files. For example, folder A can contain folder B, and folder B can contain folder C; this is called "nesting of folders". The maximum depth of nested folders, allowed by ISO 9660, is 8.
- **Writing utilities**
There are 3 utilities used to record data on a disc.
 1. **DAO (Disc At Once) utility**
All data to be written must be prepared in advance and written onto a disc from the beginning to the end in one operation. No data can be added to a disc on which data were already written with DAO utility.
 2. **TAO (Track At Once) utility**
Data are written onto a disc track by track. Data can be added to a disc on which data were written with TAO utility.
 3. **Packet writing utility**
Tracks are divided into smaller pieces while being recorded, depending on the size of available spaces on the disc. Data can be added to a disc on which data were written with packet writing utility.
This unit can play MP3 discs recorded using DAO and TAO utilities.
- **ID3TAG**
ID3TAG determines the data format for the text to be added to an MP3 file, mainly used to indicate a track title or an artist's name, etc.

Notes on creating MP3 discs

- **When converting audio data to MP3**
The unit supports MP3 files with a sampling frequency from 8 kHz to 48 kHz.
The assured bit rate range for sound quality on the unit is 8 kbps to 320 kbps.
- **When creating MP3 discs**
Do not store more than 300 albums in a disc. Also, keep the total number of albums and tracks 300 or less in a disc.
- **To play tracks in the order they were recorded**
 1. Use a writing software capable of recording MP3 tracks (files) in numerical and alphabetical order. For details on using the software, refer to the operating instructions supplied with the software.
 2. Use only one album. (Do not create a sub-album within an album.)
 3. Include a two- or three- digit number at the beginning of each album or track name so that the albums and tracks are played in order.
<example of recommended names>
01XXXXX.mp3
02XXXXX.mp3
03XXXXX.mp3
04XXXXX.mp3
05XXXXX.mp3
<example of names not recommended>
1XXXXX.mp3
5XXXXX.mp3
10XXXXX.mp3
15XXXXX.mp3
20XXXXX.mp3
(Numbers at the beginning have different digit number. The tracks will not be played in this order but played in the order of "1", "10", "15", "20" and "5".)

TUNER OPERATIONS



Manual tuning

- 1 Press TUNER BAND (SHIFT+BAND on the remote) repeatedly to select a band (FM or AM.)
- 2 Press ◀◀ or ▶▶ to tune in to a station.
"TUNED" appears when a station is tuned in.

To search for a station automatically (Auto Search)

Hold down ◀◀ or ▶▶.

The unit searches for a station up or down the band and stops at reception.

To stop the search manually, press ◀◀ or ▶▶.

- Auto Search may not stop at stations with weak signals.

Preset tuning

Preset up to 30 of your favorite stations (20 FM and 10 AM) and tune them in directly.

Presetting stations

- 1 Press TUNER BAND to select a band.
- 2 Press ◀◀ or ▶▶ to tune in to the desired station.
- 3 Press SHIFT+TUNER MEMORY on the remote to store the station.
The preset number, beginning from "1", appears in the display.
- 4 Press ◀◀ or ▶▶ on the remote to select a preset number and press ENTER to set the number.
- 5 Repeat step 1 to 4 to preset other stations.

Tuning in to preset stations


On the unit

- 1 Press TUNER BAND to select a band.
- 2 Turn MULTI JOG.
The station with the previous/succeeding preset number is tuned in.

On the remote

- 1 Press SHIFT+BAND to select a band.
- 2 Press ◀◀ or ▶▶ repeatedly to select the desired station.

En



To switch the AM tuning interval

Hold down POWER and press ENTER on the unit. With each press, the AM tuning interval alternates between 9 kHz/step and 10 kHz/step.

Tip:

The default is 10 kHz/step. Change it only when using the unit in a 9 kHz/step area. Switching AM tuning interval clears all the preset stations.

Adjustments

Antennas

Keep antennas away from metallic objects, electrical equipment and cords.

FM antenna: Extend fully and position for the best reception. If receiving condition is poor, connect optional outdoor antenna to Ψ FM 75 Ω terminal. Use an adapter as required.

AM antenna: Rotate to find best reception.


To switch to monaural FM reception

Press SHIFT+TUNER MODE on the remote. With each press, a dot, representing MONO, or no dot, representing STEREO, is displayed.

Tip:

When FM stereo reception is poor, switching to monaural reduces noise.


TAPE OPERATIONS



Playback

Use only TYPE I (normal) tapes.

- 1 Press TAPE A/B and insert the tape in either deck. Press ▲ PUSH EJECT/CLOSE on either side (deck A and deck B) to open the outer cassette holder and insert the tape in the deck. Insert with the exposed side down and playback side facing out from the unit. To close, push ▲ PUSH EJECT/CLOSE on the side where the tape is inserted.



- 2 Press ► (►/◄► on the remote).

To open the inner cassette holder

The inner cassette holder opens or closes automatically when opening or closing the outer cassette holder. If the outer cassette holder is already open, press ▲ PUSH EJECT/CLOSE of the inner cassette holder to open it.

To open or close both decks (deck A and deck B) simultaneously

Press or push ▲ PUSH EJECT/CLOSE on both sides of the outer cassette holder simultaneously.

To stop playback

Press ■.

To pause playback

Press |||. Press again to resume.

To fast forward or rewind

Press ◄◄ or ►►.

To select a deck (deck A or deck B)

Press TAPE A/B (SHIFT+TAPE A/B on the remote) in stop mode when tapes are loaded in both decks. The deck name ("TAPE A" or "TAPE B") is displayed.

To select a playback mode

- 1 Press MODE repeatedly to display "REV MODE", and then press ENTER within 6 seconds.
- 2 Turn MULTI JOG within 6 seconds to select one of the three reverse modes and then press ENTER.
 - REV OFF (⏮): Plays only one side
 - RELAY ON: Plays from both tapes in turn (once)

On the remote, press PLAY MODE repeatedly until the desired playback mode displays.

To reset the tape counter

Press ■ in stop mode, and the tape counter on the display is reset to "0000". Opening and closing the cassette holder will also reset the tape counter.

To play continuously (deck A to deck B)


Load tapes in both decks and start playback on deck A. Then, as soon as playback on deck A finishes, playback on deck B will start without interruption.

- The both decks play one side of the tapes.

Notes on cassettes

- Use of 90-minute or longer tapes is not recommended since they are extremely thin and easily deformed or damaged.
- Take up any slack in the tape with a pencil or similar tool before use. Slack tape may jam in the mechanism.

En



To stop recording

Press ■.

To pause recording

Press REC PAUSE/START. Press again to resume.

To record a selected set of tracks from a CD

Program the desired tracks (see "Programmed playback") and then press REC PAUSE/START twice and then press ►.

To erase a tape

- 1 Insert the tape in deck B. Set the tape to the desired point if needed.
- 2 Press TAPE A/B to select "TAPE B".
- 3 Press REC PAUSE/START.

Basic recording

Use only type I (normal) tapes. Deck B is the recording deck.

1 Insert the recordable tape in deck B.

Press ▲ PUSH EJECT/CLOSE to open the outer cassette holder, and insert with the exposed side down and the side to be recorded on facing out from the unit. Wind up the tape to the desired point if needed.

2 Prepare the source.

To record CD(s), select the CD function and load disc(s).

To record a radio broadcast, tune in to the desired station.

To record a tape, insert the source tape in deck A and select the TAPE function (deck A).

To record from connected external equipment, select the VIDEO (MD) function and prepare the equipment.

3 Press REC PAUSE/START.


Recording is paused and ready to start.

4 Press REC PAUSE/START again to begin recording.

If your source is CD, press ►.

If your source is connected equipment, manually start playback of the source.

- Volume or tone adjustment does not affect recording.
- "NO TAB" is displayed if you attempt to record a tape with the tab broken off.



CD SYNC

You can automatically switch to recording tape from a CD.

- 1 Insert the recordable tape in deck B.
- 2 Load disc(s).
- 3 Select playback mode with MODE, MULTI JOG and ENTER (see "Selecting playback mode").
 - You cannot select Repeat playback or Shuffle playback.
- 4 Press CD SYNC.
CD function is automatically selected.
- 5 Press REC PAUSE/START to start recording.


Automatic CD dubbing

You can use your unit to automatically determine the best tape length and rearrange track order for recording from a CD. The order of tracks is changed so that no music is split from one side to the other side of the tape.


- 1 Load a disc and select it to play by pressing a DISC CHANGE/DISK SKIP.
- 2 Press SHIFT+EDIT on the remote.
The unit will read the CD then display what tape length is necessary.
 - Tape lengths displayed, in minutes, are: 10, 20, 30, 40, 46, 50, 54, 60, 64, 70, 80 and 90. If a tape longer than 90 minutes is needed "OVER 90" is displayed.
- 3 Insert the recordable tape in deck B.
- 4 Press CD SYNC.
- 5 Press REC PAUSE/START to begin recording.

To prevent accidental erasure

Remove the plastic tab of the cassette tape with a screwdriver or other pointed tool. To record on the tape again, cover the detection slot with adhesive tape.



SOUND ADJUSTMENTS



En

TREBLE and MIDDLE

TREBLE enhances high frequency for sound clarity and MIDDLE enhances mid frequency for presence.

- 1 Press MODE repeatedly until "TRE/MID" displays and press ENTER.
 - 2 Turn MULTI JOG to select "TREBLE" or "MIDDLE" and then press ENTER.
 - 3 Turn TREBLE/MIDDLE to adjust the level from -4 to +4.
On the remote, press SOUND repeatedly until "TRE" or "MID" is displayed and then adjust the level by pressing ◀◀ or ▶▶.
- If the sound becomes distorted at higher levels of TREBLE or MIDDLE decrease the level.

BASS

Emphasizes low frequencies for a powerful sound.

Turn BASS to adjust from -4 to +3 and MAX.

On the remote, press SOUND repeatedly until "BAS" appears in the display and then press ◀◀ or ▶▶ repeatedly within 6 seconds.

- If the sound becomes distorted with higher levels of bass turn the bass level down.

i-Bass

Produces a rich and clear low-frequency sound besides BASS effect.

- 1 Press i-Bass.
"I-BA ON" is displayed and a red indicator on the i-Bass button lights up.
- 2 Turn BASS to adjust i-Bass from 1 to 4 and MAX.
On the remote, press SOUND repeatedly until "I-BA" appears in the display and then press ◀◀ or ▶▶ repeatedly within 6 seconds.

Note

i-Bass must be turned on at the unit before the level can be adjusted with the remote.

Select an i-Bass frequency

- 1 Press i-Bass to turn i-Bass on.
- 2 Press MODE repeatedly until "FREQ" is displayed and then press ENTER.
- 3 Turn MULTI JOG to select one of the three frequency ranges and then press ENTER.
 - FREQ 1: Low range
 - FREQ 2: Mid range
 - FREQ 3: High rangeAfter step 3, adjust the i-Bass level by turning BASS if needed.
If there is no MULTI JOG or button operation within 6 seconds, the setting is canceled.

To cancel i-Bass

Press i-Bass to select "I-BA OFF".

Graphic equalizer

Selects a sound equalization curve to match the music type.

Press HEAVY, VOCAL, SALSA, TECHNO, HIP HOP or MANUAL.

On the remote, press SHIFT+GEQ and then press ◀◀ or ▶▶ repeatedly within 2 seconds.

The selected equalization curve is displayed.

- MANUAL is a customized curve (see "Saving a custom equalization curve").

To cancel equalization

Press the selected button on the unit again. "GEQ OFF" is displayed.

On the remote, press SHIFT+GEQ and then press ◀◀ or ▶▶ repeatedly within 2 seconds until "GEQ OFF" is displayed.

Saving a custom equalization curve

You can save TREBLE, MIDDLE and BASS settings to the MANUAL button.

Hold down MANUAL until "PRESET" appears in the display.

The customized curve is stored in MANUAL.

- If you select one of the preset curves such as HEAVY you can customize it and save it to MANUAL.

Surround playback

You can playback any source with surround sound.

Press SURROUND.


Each press turns SURROUND ON or OFF.

When SURROUND is on, "SURR" lights up in the display.

Note

Some MONO sources cannot be played back with surround sound.

TIMER OPERATIONS




En

Sleep timer

Turns off the unit automatically after a specified time.

Press SLEEP on the remote repeatedly.

With each press, the timer duration changes cyclically as follows:



The unit turns off after the selected time.

* "AUTO": The unit turns off when the current CD or tape finishes the playback (for up to 100 minutes).

Tip:

The display is dimmed while the sleep timer is active.

To check the remaining time until the unit turns off

Press SLEEP on the remote once. The remaining time is displayed for 4 seconds.

To cancel the sleep timer

Press SLEEP on the remote repeatedly until "SLEEP OFF" appears.

Timer playback

Turns on the unit at a specified time every day.

Make sure the clock is set correctly.

Use the remote from step 2.

1 Prepare the source.

To play CD(s), load disc(s).

To play the radio, select the band and tune in to the desired station or tune in to a preset station (see "Tuning in to preset stations").

To play a tape, insert the tape and select the deck.

2 Press VOLUME +, - to set the volume level.

3 Press CLOCK/TIMER/SET to display "DAILY" and then press ENTER.

"⌚" indicator lights up and "ON" appears for a moment. If "SET CLOCK" is displayed, set the clock (see "Setting the clock") and carry out from this step again.

4 Press ◀ or ▶ to set the timer-on hour and then press ENTER.

5 Press ◀ or ▶ to set the timer-on minute and then press ENTER.

"OFF" appears for a moment.

6 Repeat step 4 and 5 to set the timer-off hour and minute.

7 Press ◀ or ▶ to select the source (CD, TAPE and TUNER) and then press ENTER.

8 Press POWER to turn the unit off.

The unit turns on at the specified timer-on time and plays the selected source and then turns off at the specified timer-off time.

- To stop timer setting in step 3 to 6, press CLEAR on the remote.
- The Timer playback will not begin unless the unit is turned off first.
- Turning VOLUME on the unit is also available in step 2.
- MULTI JOG is also available in place of ◀ or ▶.

To display the timer setting

Press CLOCK/TIMER/SELECT on the remote, then press ◀ or ▶ to select "DAILY" and press ENTER. The timer-on time, the timer-off time and the source are displayed.

To change the timer setting

Re-set the timer again.

To cancel the timer

Press CLOCK/TIMER/SELECT on the remote, then press ◀ or ▶ to select "OFF" and press ENTER. "⌚" disappears from the display.

Choosing a Timer function

You cannot use both Timer playback and Timer recording at the same time. If both have been set, choose one or the other.

1 Press CLOCK/TIMER/SELECT on the remote.

"SELECT" is displayed.

2 Press **I◀◀** or **▶▶I** to select "DAILY" (Timer playback) or "REC" (Timer recording) and press ENTER.

Timer recording

Turns on the unit and makes recording once at a specified time. Timer recording is available only for TUNER source.

Use the remote from step 3.

1 Prepare the TUNER source.

Select the band and tune in to the desired station or tune in to a preset station (see "Tuning in to preset stations").

2 Prepare the recording destination.

Insert the recordable tape in deck B.

3 Press CLOCK/TIMER/SET0 to display "DAILY".

If "SET CLOCK" is displayed, set the clock (see "Setting the clock") and carry out from this step again.

4 Press **I◀◀** or **▶▶I** repeatedly until "REC" appears in the display and then press ENTER.

"REC"  indicator lights up and "ON" appears for a moment.

5 Carry out step 4 to step 6 described in "Timer playback" to set the timer-on time and timer-off time.

6 Press POWER to turn the unit off.

The unit turns on at the specified timer-on time and records the source (TUNER) and then turns off at the specified timer-off time.

- To stop timer setting in step 3 to 4, press CLEAR on the remote.

- The Timer recording will not begin unless the unit is turned off first.

- Volume level is automatically set to 0 (minimum) when the Timer recording is activated.

- MULTI JOG is also available in place of **I◀◀** or **▶▶I**.


To display the timer setting

Press CLOCK/TIMER/SELECT on the remote, then press **I◀◀** or **▶▶I** to select "REC" and press ENTER. The timer-on time, the timer-off time and the source (TUNER) are displayed.

To change the timer setting

Re-set the timer again.

To cancel the timer

Press CLOCK/TIMER/SELECT on the remote, then press **I◀◀** or **▶▶I** to select "OFF" and press ENTER. "REC"  disappears from the display.

Choosing a Timer function

You cannot use both Timer playback and Timer recording at the same time. If both have been set, choose one or the other.

1 Press CLOCK/TIMER/SELECT on the remote.

"SELECT" is displayed.

2 Press **I◀◀** or **▶▶I** to select "DAILY" (Timer playback) or "REC" (Timer recording) and press ENTER.

Notes

- The Timer playback performs every day at the specified time unless you cancel it. However, the Timer recording performs only once: it automatically cancels itself when the recording finishes.

- You cannot set the same time for timer-on time and timer-off time. "TIME NG" is displayed if you do that. In this case, reset the time.

- You cannot select the Timer playback/recording with CLOCK/TIMER/SELECT on the remote before setting it up. "SET TIMER" is displayed if you do that. You must set it up first and then select it.

- When you use the sleep timer, the timer playback/recording will not turn on the unit until the sleep timer turns it off.

REFERENCE

Care and maintenance

Occasional care and maintenance of the unit and the software are needed to optimize the performance of your unit.

To clean the cabinet

Use a soft and dry cloth. If the unit surfaces are extremely dirty, use a soft cloth lightly moistened with mild detergent solution. Do not use strong solvents such as alcohol, benzine or thinner.

To clean the tape heads

Dirty tape heads cause sound deterioration. After every 10 hours of use, clean the tape heads by using a dry-type or wet-type head-cleaning cassette, sold separately. Refer to the instructions of the cleaning cassette.

To demagnetize the tape heads

Use a sold demagnetizing cassette after every 20 to 30 hours of use. Refer to the instructions of the demagnetizing cassette.

Care of CDs

When a CD becomes dirty, wipe it from the center out with a cleaning cloth. However, do not use solvents. After playing a CD, store it in its case. Do not expose a CD to direct sunlight or heat sources.

Care of tapes

Store tapes in their cases after use. Do not leave tapes near magnets, motors, television sets, or any source of magnetism. Do not expose tapes to direct sunlight, or leave them in a car parked in direct sunlight.

Troubleshooting

If your unit fails to perform properly, check the following guide and the relevant sections of the Operating Instructions.

First, check that the AC power cord and the speakers are connected correctly and firmly.

Should any problem persist, consult your nearest Aiwa dealer.

General

There is no sound.

- Are the speakers and AC power cord connected properly?
- Turn VOLUME clockwise and hold.
- The headphones are connected.
- Insert only the stripped portion of the speaker cord into the SPEAKER terminal. Inserting the vinyl portion of the speaker cord will obstruct the speaker connections.

The unit shut off suddenly.

- Possibly a short circuit in the speaker terminals. Disconnect the AC power cord from the wall outlet and reconnect the speaker cords correctly. After a while, connect the AC power cord to the wall outlet.

The unit blacks out when the unit is turned off.

- ECO mode is set to on (see "ECO mode" on page 11).

Erroneous display.

- Reset the unit (see "Resetting the unit" on page 27).

There is severe hum or noise.

- A TV or VCR is placed too close to the stereo system. Move the stereo system away from the TV or VCR.

The clock indication does not show the correct time.

- A power interruption occurred. Set the clock and timer settings again.

The clock setting/radio presetting/timer is canceled.

- The AC power cord is disconnected or a power failure occurs longer than half a day.

Redo the following:

- "Setting the clock" on page 11
- "Presetting stations" on page 17

If you have set the timer, also redo "Timer playback/recording" on page 24 and 25.

The timer does not function.

- Set the clock correctly.
- When you used the Sleep timer, the Timer playback/recording will not turn on the unit until the Sleep timer turns it off.

The remote does not function.

- There is an obstacle between the remote and the unit.
- The remote is not pointing in the direction of the unit's remote sensor.
- The batteries have run down. Replace the batteries.

Speakers

Sound comes from one channel or unbalanced left and right volume.

- Check the speaker connection and speaker placement.

Sound lacks bass.

- Check that the speaker's \oplus and \ominus terminals are connected correctly.

CD player

The disc compartment does not close.

- The CD is not placed properly.

The sound drops out.

- The lens is dirty. Clean it with a commercially available blower.

The CD will not play.

- The CD is not lying flat in the disc compartment.
- The CD is dirty.
- The CD is inserted label side down.
- Moisture condensation has built up. Remove the CD and leave the system turned on for about an hour until the moisture evaporates.

Tape Deck**The tape does not record.**

- No tape in deck B.
- The tab has been removed from the cassette tape.
- The tape has reeled to the end.

The tape does not record nor play or there is decrease in sound level.

- The heads are dirty. Clean them (see "To clean the tape heads" on page 26).
- The record/playback heads are magnetized. Demagnetize them (see "To demagnetize the tape heads" on page 26).

The tape does not run.

- Is the deck in pause?

The tape does not erase completely.

- The record/playback heads are magnetized. Demagnetize them (see "To demagnetize the tape heads" on page 26).

There is excessive wow or flutter, or the sound drops out.

- The capstans or pinch rollers are dirty. Clean them (see "To clean the tape heads" on page 26).

Noise increases or the high frequencies are erased.

- The record/playback heads are magnetized. Demagnetize them (see "To demagnetize the tape heads" on page 26).

Poor tape sound.

- Use TYPE I (normal) tapes.

Tuner**Noise is heard or poor reception.**

- Check the antenna connections.
- For FM, move the FM antenna to reduce the noise.
- For AM, re-rotate the AM antenna to reduce the noise.
- Move the unit and the antennas away from other electric appliances and cords.

If the red indicator on POWER STANDBY/ON flashes continuously.**Rapid flashing (in approx. 0.5 sec. cycle):****Abnormal voltage flows in the unit.**

- Disconnect the AC power cord from the wall outlet and then check the voltage.

Slow flashing (in approx. 2 sec. cycle):**A short circuit in the speaker terminal or some malfunction occurs in the unit.**

- Disconnect the AC power cord from the wall outlet and then check the speaker connection. Should the problem persist, consult your nearest Aiwa dealer.

En**Resetting the unit**

If an unusual condition occurs in the display window or the cassette deck, reset the unit as follows:

1 Press POWER to turn off the power.

If the power cannot be turned off, disconnect the AC power cord, then plug it in again.

2 While holding down ■ and ENTER press POWER.

Everything stored in memory after purchase is cleared.

Specifications

MAIN UNIT CX-JS7

TUNER

| | |
|-----------------------------|---|
| FM tuning range | 87.5 MHz to 108 MHz |
| FM usable sensitivity (IHF) | 13.2 dBf |
| FM antenna terminal | 75 ohms (unbalanced) |
| AM tuning range | 530 kHz to 1710 kHz (10 kHz step) 531 kHz to 1710 kHz (9 kHz step) |

| | |
|-----------------------|---------------|
| AM usable sensitivity | 350 μ V/m |
| AM antenna | Loop antenna |

AMPLIFIER

| | |
|---------------------------|--|
| Power output | 160 W + 160 W (40 Hz - 20 kHz, THD less than 1 %, 6 ohms) 200 W + 200 W (1 kHz, THD less than 10 %, 6 ohms) 0.08 % (100 W, 1 kHz, 6 ohms) VIDEO (MD): 500 mV SPEAKERS: 6 ohms or more PHONES: 32 ohms or more |
| Total harmonic distortion | |
| Input | |
| Outputs | |

CASSETTE DECK

| | |
|--------------------|--|
| Track format | 4 tracks, 2 channels stereo |
| Frequency response | 50 Hz - 8 kHz |
| Recording system | AC bias |
| Heads | Deck A: playback x 1 Deck B: recording/playback x 1, erase x 1 |

CD PLAYER

| | |
|-----------------------|--|
| Laser | Semiconductor laser (λ = 780 nm) Emission duration: continuous |
| D/A converter | 1 bit dual |
| Signal-to-noise ratio | 85 dB (1 kHz, 0 dB) |
| Harmonic distortion | 0.05 % (1 kHz, 0 dB) |

GENERAL

| | |
|--------------------------------------|---|
| Power requirements | 120 V AC, 60 Hz |
| Power consumption | 160 W |
| Power consumption in standby mode | With ECO mode on: 0.25 W With ECO mode off: 25 W |
| Dimensions (W x H x D) | 280 x 328 x 437 mm (11 ¹ / ₈ x 12 ¹⁵ / ₁₆ x 17 ⁷ / ₃₂ in.) |
| Weight | 10.2 kg (22 lbs 8 oz) |

FRONT SPEAKERS SX-JS7

| | |
|------------------------|--|
| Speaker system | 3 way, bass reflex |
| Speaker units | Woofer: 140 mm (5 ⁵ / ₈ in.) cone x 2 Tweeter: 60 mm (2 ³ / ₈ in.) cone Super tweeter: 20 mm (1 ³ / ₁₆ in.) ceramic |
| Impedance | 6 ohms |
| Dimensions (W x H x D) | 298 x 327 x 278 mm (11 ³ / ₄ x 12 ⁷ / ₈ x 11 in.) |
| Weight | 5.3 kg (11 lbs 11 oz) |

Supplied accessories

Remote commander (1)
Batteries (2)
FM antenna (1)
AM antenna (1)

Specifications and external appearance are subject to change
without notice.

COPYRIGHT

Check copyright laws relevant to recordings from discs, tuner
or tape for the country where the unit is to be used.

Licensed by BBE Sound, Inc. under USP4638258, 5510752
and 5736897.

