

SONY.

3-856-131-21(1)

Stereo Cassette Deck

Operating Instructions

**TC-KA1ESA
TC-KE500S**

© 1996 by Sony Corporation

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet.
Refer servicing to qualified personnel only.

FOR THE CUSTOMERS IN THE UNITED STATES



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Owner's record

The model and serial numbers are located on the rear of the unit. Record the serial number in the space provided below. Refer to these numbers whenever you call upon your Sony dealer regarding this product.

Model No. TC-KA1ESA/TC-KE500S
Serial No. _____

INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Welcome!

Thank you for purchasing the Sony Stereo Cassette Deck. Before operating the unit, please read this manual thoroughly and retain it for future reference.

The TC-KA1ESA and TC-KE500S are provided with an FET input PB amplifier which enables higher quality sound output. (For details on the FET input PB amplifier, see "Glossary" on page 15.)

About This Manual

The instructions in this manual are for models TC-KA1ESA and TC-KE500S. All illustrations in this manual show the TC-KE500S.

Please note the following distinguishing features of each model:

TC-KA1ESA

- Is for sale in the U.S.A. and Canada.

TC-KE500S

- Is for sale in the U.S.A., the U.K., all European countries, Australia, and other countries.

Conventions

- Instructions in this manual describe the controls on the deck.
- The following icon is used in this manual:



Indicates useful information or tips that make a task easier.

TABLE OF CONTENTS

Getting Started

Unpacking 4
Hooking Up the System 4

Playing a Tape 5

Recording on a Tape 6

Advanced Playback Operations

Locating a Track (Multi-AMS/Auto Play/Memory Play) 8

Advanced Recording Operations

Adjusting Bias and Recording Level Calibration 9
Monitoring the Recorded Sound 10
Inserting a Blank Space During Recording (Record Muting) 10

Additional Information

Precautions 11
Notes on Cassette Tapes 11
Cleaning 12
Troubleshooting 13
Specifications 14
Glossary 15

Index Back cover

Getting Started


Unpacking

Check that you have received the following supplied item:

- Audio connecting cords (2)

Hooking Up the System


This section describes how to hook up the tape deck to an amplifier. Be sure to turn off the power of each component before making the connections.




Hookups

When connecting an audio connecting cord, be sure to match the color-coded cord to the appropriate jacks on the components: Red (right) to Red and White (left) to White. Be sure to make connections firmly to avoid hum and noise.

Connect the tape deck to the amplifier as shown below.




To connect your tape deck to another tape deck
Connect both tape decks as shown below.



Setting the voltage selector (only on models supplied with a voltage selector)

Check that the voltage selector on the rear panel of the tape deck is set to the local power line voltage. If not, set the selector to the correct position using a screwdriver before connecting the AC power cord to an AC outlet.




Connecting the AC power cord

Connect the AC power cord to an AC outlet.

Where do I go next?

Now you're ready to use your tape deck.
For basic operations, go to pages 5 to 7; for advanced operations, go to the sections starting from page 8.

Playing a Tape



• See page 4 for hookup information.

To play a tape recorded with the Dolby NR* system

Turn DOLBY NR to the same Dolby system that the tape was recorded in—B, C, or S. Please note that the B, C, and S settings on both sides are identical during playback since the MPX filter operates only during recording.

• You can connect the headphones to PHONES.

* Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.


"DOLBY" and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

1 Turn on the amplifier and select the tape deck position.

2 Press POWER, and then press EJECT. Insert a cassette and close the cassette holder.

"TAPE" and the tape type (I, II, or IV) appear in the display.

With the side you want to play facing you




3 Press . The deck starts playing. Adjust the volume on the amplifier. Do not press POWER or EJECT while the tape deck is operating. If you do so, the tape may be damaged.

To	Press
Stop playing	
Pause	PAUSE. Press the button again to resume play.
Fast-forward or rewind	or when the deck is stopped
Increase the tape fast-forward or rewind speed	or again during fast-forwarding or rewinding
Take out the cassette	EJECT after stopping playing

6 Start playing the program source.

To	Press
Stop recording	■
Pause	⏸ PAUSE. Press the button again to resume recording.
Take out the cassette	⏏ EJECT after stopping recording



To adjust the recording balance

Turn BALANCE so that the L (left channel) and R (right channel) peak level meters in the display are at the levels you want.

To record with the Dolby NR system

Turn DOLBY NR clockwise to the position you want (B, C, or S) before you start recording.

If you cannot get satisfying results when recording FM broadcasts with Dolby NR system

Turn DOLBY NR counterclockwise to the position you want (B, C, or S with MPX FILTER) before you start recording. The filter turns on to make the Dolby NR system work more effectively. "FILTER" appears in the display. (For details on the MPX filter, see "Glossary" on page 15.)

The Dolby HX PRO* system automatically works during recording

You can check how much blank remains on the tape

- 1 Locate the end of the recorded portion on the tape.
- 2 Press RESET to reset the tape counter to "0.00."
- 3 Press ►► to fast-forward the tape to its end. The tape counter shows the approximate amount of remaining time.

* HX Pro headroom extension originated by Bang & Olufsen and manufactured under license from Dolby Laboratories Licensing Corporation.


"DOLBY," the double-D symbol and "HX PRO" are trademarks of Dolby Laboratories Licensing Corporation.

For details on DOLBY HX PRO, see "Glossary" on page 15.

Advanced Playback Operations

Locating a Track (Multi-AMS/ Auto Play/Memory Play)

You can locate the following/previous tracks (Multi-AMS: Automatic Music Sensor) or the beginning of a tape quickly. You can even locate a specific point anywhere on a tape.




To locate	Press
the beginning of the next or succeeding tracks (Multi-AMS*)	▶▶ as many times as you want while playing. For example, to locate 2 tracks ahead, press twice.
the beginning of the current track (Multi-AMS*)	◀◀ once while playing
the beginning of the preceding tracks (Multi-AMS*)	◀◀ as many times as you want while playing. For example, to locate 2 tracks behind, press three times.
the beginning of a tape (Auto Play)	MEMORY repeatedly until "MEMORY" disappears in the display. Then press ◀◀ while holding down ▶▶.
a particular point on a tape (Memory Play)	MEMORY repeatedly until "MEMORY" appears in the display. Find the point you want, and press RESET to reset the tape counter and to memorize the point. To locate the memorized point, press ◀◀ while holding down ▶▶. (Press ◀◀ only to stop at "0.00.")

* You can use the Multi-AMS to locate up to the 30th track after or before the current track.

What happens during Multi-AMS operation

When Multi-AMS is operating, "PLAY" appears. And each time the deck detects a blank space, the indicated number decreases by one. After locating the beginning of the specified track, the counter indication appears again and the deck starts playing the track.

↓: Beginning of track




Notes

- The Multi-AMS function may not work correctly if:
 - the blank space between tracks is less than 4 seconds long.
 - the signal strength of the left and right channels are very different.
 - there is a passage of low frequencies or very low volume within a track.
- Since the counter is not a digital clock, it will differ from the actual elapsed playback or recording time.

Adjusting Bias and Recording Level Calibration


Since there are many different types of cassettes on the market, the tape deck automatically sets the appropriate equalization characteristics and bias current for each tape type (ATS: Automatic Tape Selection).

However, you can get better recording results by adjusting the bias current and recording level calibration.



1 Insert the cassette you want to record on.


2 Press CALIBRATION. The display for adjusting the bias current and recording level calibration appears.




3 Press REC.

4 Press PAUSE or ▷ to record the test tones. (You can't hear the test tones.) After two or three seconds, the meters showing the level of the test tones appear in the display. Then adjust, in sequence, the bias current and recording level calibration.

5 Adjust BIAS so that both meters indicate equal signal levels. If the upper meter shows a higher level than the lower meter, turn BIAS clockwise. If the lower meter shows a higher level than the upper meter, turn BIAS counterclockwise.



6 Adjust REC LEVEL so that both meters reach the recommended level. Turn REC LEVEL clockwise to increase both meters. Turn REC LEVEL counterclockwise to decrease both meters.



Repeat steps 5 and 6 if necessary.

7 Press ■, then press CALIBRATION to stop recording the test tones. The display returns to normal.

8 Rewind the tape and start the actual recording.

You can also adjust the bias current and recording level calibration according to your own taste. For details, see page 15.


Notes

- Because the meters use a wider amplitude during tape calibration, they are more sensitive to slight changes in signal level.
- When you use metal (type IV) tapes, the frequency response to adjustments of the bias current is small. Therefore, adjusting the bias current with the range of this tape deck (a range of about $\pm 20\%$) may not be effective.

Advanced Recording Operations

Monitoring the Recorded Sound

- You can compare the quality of the recorded sound with the sound of the program source while recording.




While recording, press MONITOR repeatedly until "TAPE" appears in the display. You can monitor the sound being recorded.

To listen to the sound of the program source Press MONITOR repeatedly until "SOURCE" appears in the display.

Inserting a Blank Space During Recording (Record Muting)

You can insert a blank space of 4 seconds between each track. The blank spaces between tracks let you locate the track easily with the Multi-AMS function (see page 8). Also, use this function to eliminate only unwanted portions on the tape.



- 1 Start recording.
 - 2 Press O REC MUTE once when you want to insert a blank space.
"REC" in the display starts flashing and the tape moves on without recording any signals. After 4 seconds, "II" lights up and the tape deck is now ready to resume recording.
 - 3 Press II PAUSE or ▷ to resume recording.
- 💡 **To insert a blank space longer than 4 seconds**
Hold down O REC MUTE as long as you want. After 4 seconds, "REC" flashes faster. When you release the O REC MUTE, "II" lights up and the tape deck is ready to resume recording. Press II PAUSE or ▷ to resume recording.
 - 💡 **To insert a blank space of less than 4 seconds**
After pressing O REC MUTE, press II PAUSE at any time. The deck changes to recording pause. To resume recording, press ● REC instead of II PAUSE.

Additional Information

Precautions

On safety

- Do not **disassemble** the cabinet — this may result in an electrical shock. Refer servicing to qualified personnel only.
- Should any solid object or liquid fall into the cabinet, unplug the tape deck and have it checked by qualified personnel before operating it any further.

On power sources

- Before operating the tape deck, check that the operating voltage of the tape deck is identical with your local power supply. The operating voltage is indicated on the nameplate at the rear of the tape deck.
- The unit is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the unit itself has been turned off.
- If you are not going to use the tape deck for a long time, be sure to disconnect the tape deck from the wall outlet. To disconnect the AC power cord (mains lead), grasp the plug itself; never pull the cord.
- AC power cord must be changed only at the qualified service shop.

On operation

- Because of a safety mechanism, the function buttons will not operate if the cassette holder is not completely closed, if there is no cassette in the cassette holder, or if a cassette has been incorrectly inserted into the cassette holder.
- Be sure to stop the tape before turning off the tape deck. Otherwise, the tape may be damaged.

On placement

- Place the tape deck in a location with adequate ventilation to prevent heat build-up in the tape deck.
- Do not place the tape deck:
 - on a soft surface such as a rug that might block the ventilation holes on the bottom.
 - in a location near heat sources.
 - in a place subject to direct sunlight.
 - in an inclined position.
 - in a place subject to excessive dust or mechanical shock.

On cleaning the tape deck

Clean the cabinet, panel and controls with a soft cloth slightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent such as alcohol or benzine.

If you have any questions or problems concerning your tape deck, please consult your nearest Sony dealer.


For the customers in the U.S.A.

For detailed safety precautions, see the leaflet "IMPORTANT SAFEGUARDS."

Notes on Cassette Tapes


To protect the recording

Break off the record-protect tab for side A or B.




To record on a tape having a broken tab

Cover the record-protect tab hole for side A or B with adhesive tape.



When you are using a type II or type IV tape, be careful not to cover the detector slots that the deck uses to determine the tape type.



On tapes longer than 90 minutes


We do not recommend the use of tapes longer than 90 minutes except for a long continuous recording or playback. They are very thin and tend to be stretched easily.

On handling cassettes

- To prevent the heads and tape path from getting dirty, avoid touching the tape surface of a cassette.
- Place cassettes away from equipment with magnets, such as speakers and amplifiers; it may cause tape distortion or erase the recordings.
- Do not expose cassettes to direct sunlight, extremely cold temperature or moisture.

Additional Information

Cleaning




Cleaning the heads and tape path

Clean the heads and tape path of the tape deck after every 10 hours of operation to guard against:

- a decrease in sound level
- excessive wow or flutter
- sound dropout
- incomplete erasure

To ensure better recording, we recommend that you clean the heads and tape path before every recording.

- 1 Press  EJECT to open the cassette holder.
- 2 With the tape deck turned off, wipe the heads, the pinch roller, and the capstan with a cotton swab slightly moistened with alcohol or a commercially available cleaning fluid for tape decks.
Do not insert a cassette until the cleaned areas are completely dry.

Demagnetizing the heads

After 20 to 30 hours of use, or when you notice a hissing sound or loss of high frequencies, demagnetize the heads with a commercially available demagnetizer for tape decks. Please refer to the instructions of the demagnetizer.

Troubleshooting

If you've experienced any of the following difficulties while using the tape deck, use this troubleshooting guide to help you remedy the problem. Should any problem persist, consult your nearest Sony dealer.

The function buttons do not work.

- ➔ The tape deck has just been turned on and does not operate for about 3 seconds. Wait until "II" stops flashing.
- ➔ Check that the cassette is inserted correctly and the cassette holder is closed completely.

The tape stops before the tape has been fully rewind.

- ➔ The tape is slack. Take up the tape slack.
- ➔ If "MEMORY" is shown in the display, press MEMORY repeatedly until the indication disappears.
- ➔ The cassette shell is bent. Use another cassette.

The tape deck does not play or record.

- ➔ The tape has reeled to the end.
- ➔ The tape is slack. Take up the tape slack.
- ➔ The record-protect tab has been removed from the cassette. Cover the slot with tape (page 11).
- ➔ Clean the heads and tape path and demagnetize the heads (page 12).
- ➔ Check that the tape deck is properly connected (page 4).
- ➔ Make sure the amplifier is correctly set.

There is excessive wow, flutter, or a sound dropout.

- ➔ The capstans and pinch rollers are dirty. Clean them (see page 12).

There is a decrease in sound level or a sound dropout./ The tape does not erase completely./Noise increases.

- ➔ The heads and tape path are dirty. Clean them (see page 12).
- ➔ The heads are magnetized. Demagnetize them (see page 12).

There is hum or noise.

- ➔ The tape deck is placed near a TV or VCR. Place the tape deck away from the TV or VCR.
- ➔ The tape deck is placed on or under the amplifier. Place the tape deck away from the amplifier.

There is an unbalanced tone.

- ➔ Check that the DOLBY NR control is set to the position where the tape was recorded.
- ➔ The tape deck is placed near a TV or VCR. Place the tape deck away from the TV or VCR.

The Multi-AMS function does not work properly.

- ➔ One of the tracks contains a long pause, a passage of low frequencies or very low volume, or a gradual increase or decrease in volume.
- ➔ The space before a track is less than 4 seconds long. Insert a blank space of 4 seconds using **Q** REC MUTE button.
- ➔ The signal strength of the left and right channels are very different.
- ➔ There is noise in the space before a track.
- ➔ You pressed **▶▶** button immediately before the next track, or **◀◀** button immediately after the beginning of the current track.

Glossary


ATS

Automatic Tape Selection. The tape deck automatically sets the appropriate equalization characteristics and bias current according to the tape type inserted in the deck.

Bias calibration

Adjustment for optimum recording. You can get better recording results with minimum distortion and flat frequency response by adjusting the bias current to the appropriate level. Lowering the bias current can boost high-frequency response, but also cause higher distortion. On the other hand, raising the bias current can minimize distortion, but also reduce high-frequency response. To balance both the bias current and high-frequency response, it is necessary to adjust the bias current appropriately.

However, to suit your taste, you can also adjust the bias current as you want.




Dolby HX PRO system

Distortion and noise reduction system. The Dolby HX PRO system reduces distortion and noise in high-frequency response while recording. A tape recorded with this system brings the same high-quality sound even when you play the tape on the other tape decks.

Dolby NR (noise reduction) system


Noise reduction system for eliminating hissing noise. The Dolby NR system boosts the low-level signals in high frequency during recording and restores them during playback.

There are 4 types in the Dolby NR system: A, B, C and S. A-type is for professional use (not available on this tape deck), and B, C and S-types are for consumer use. S-type has the maximum noise reduction capability, followed by C and B.



FET input PB amplifier

The FET input PB amplifier is a circuit that is positioned between the playing head and the operational amplifier. Unlike conventional amplifier circuits, which require a low noise, medium-quality operational amplifier because of its direct link with the playing head, the noise-free signal that the FET input PB amplifier provides enables the use of a higher quality operational amplifier, and more natural sounding output.



New Amplifier

MPX filter


Multiplex filter. A filter for eliminating the 19-kHz stereo carrier and the 38-kHz sub-carrier signals that may impair the Dolby NR system. Usually the tuner has an MPX filter. If you cannot get a satisfying result when recording FM broadcasts with Dolby NR system, your tuner does not have a filter or the filter is not working. In this case, turn the DOLBY NR switch counterclockwise to the position you want (B, C, or S with MPX FILTER).

Multi-AMS

Multi-Automatic Music Sensor is a function that locates the beginning of up to 30 tracks before or after the current track by detecting a blank space (of over 4 seconds) between tracks.

Recording level calibration

Adjustment for optimum recording. Even when you have adjusted the recording level correctly, the playing level might turn out to be low depending on the tape used. By adjusting the recording level calibration, you can compensate for the low recording level. When you record on a tape with the Dolby NR system, this function works more effectively.



Tape counter

A display element that shows the elapsed recording or playing time as a digital readout. Since the counter is not a digital clock, the displayed value will differ slightly from the actual elapsed recording or playing time. The counter value also includes the length of the leader tape.

Test tones

15-kHz, 3-kHz and 400-Hz signals produced by the tape deck when you do the bias and recording level calibration.

Index

Index

A

- Adjusting
 - bias calibration 9
 - recording balance 7
 - recording level 6
 - recording level calibration 9
- ATS 9, 15
- Auto play 8
- Automatic Music Sensor. *See* Multi-AMS
- Automatic Tape Selector. *See* ATS

B

- Balance 7
- Bias calibration 9, 15

C

- Calibration 9, 15
- Cassette. *See* Tape
- Checking the remaining time. *See* Remaining time
- Cleaning
 - cabinet 11
 - heads and tape path 12
- Connecting. *See* Hookups
- Counter. *See* Tape counter

D, E

- Demagnetizing the heads 12
- Dolby HX PRO system 7, 15
- Dolby NR system 5, 7, 15

F

- FET input PB amplifier 15

G

- Glossary 15

H

- Heads
 - cleaning 12
 - demagnetizing 12
- Hooking up the system 4
- Hookups 4

I, J, K

- Insert
 - blank space 10
 - cassette 5, 6

L

- Locating
 - beginning of the tape 8
 - particular point 8
 - tracks 8

M

- Memory play 8
- Monitoring sound 10
- MPX filter. *See* Multiplex filter
- Multi-AMS 8, 15
- Multiplex filter 7, 15

N, O

- Noise reduction 7, 15
- Notes on cassette tapes. *See* Tape notes

P, Q

- Playing
 - a tape 5
 - auto play 8
 - memory play 8
- Precautions 11

R

- Recording
 - level calibration 9, 15
 - on a tape 6
- Record muting 10
- Remaining time 7

S

- Searching. *See* Locating
- Specifications 14

T

- Tape
 - counter 7, 8, 15
 - notes 11
 - path cleaning 12
 - protect the recording 11
 - type 5, 6, 11
- Test tones 9, 15
- Troubleshooting 13

U, V, W, X, Y, Z

- Unpacking 4

Names of Controls

Buttons

- CALIBRATION 9
- MEMORY 8
- MONITOR 10
- RESET 8
- ◀/▶ AMS 8
- ◀ (rewind) 5, 8
- ▶ (play) 5, 6, 8 - 10
- ▶▶ (fast-forward) 5, 8
- ⏏ EJECT 5 - 7
- (stop) 5, 7
- ⏏ PAUSE 5 - 7, 10
- ⏏ REC MUTE (record muting) 10
- REC (recording) 6, 9

Switches

- DOLBY NR (noise reduction) 5, 7
- POWER 5, 6

Controls

- BALANCE 7
- BIAS 9
- REC (recording) LEVEL 6, 9

Jack

- PHONES 5

Others

- Cassette holder 5, 6