

# ***Stereo Cassette Deck***

---

Operating Instructions

***TC-KA6ES  
TC-KA3ES***


## WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet.

Refer servicing to qualified personnel only.

### FOR THE CUSTOMERS IN THE UNITED STATES



This symbol is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

#### Owner’s record

The model and serial numbers are located on the rear of the unit. Record the serial number in the space provided below. Refer to these numbers whenever you call upon your Sony dealer regarding this product.

Model No. TC-KA3ES

Serial No. \_\_\_\_\_

### FOR THE CUSTOMERS IN CANADA

#### CAUTION

TO PREVENT ELECTRIC SHOCK, DO NOT USE THIS POLARIZED AC PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.

## Welcome!

Thank you for purchasing the Sony Stereo Cassette Deck. Before operating the unit, please read this manual thoroughly and retain it for future reference.

## About This Manual

The instructions in this manual are for models TC-KA6ES and TC-KA3ES. All illustrations in this manual show the TC-KA3ES.

Please note the following distinguishing features of each model:

#### TC-KA6ES

- Uses an SD head
- Does not have an HX PRO button; the Dolby HX PRO function is continuously on
- Is for sale in Europe only

#### TC-KA3ES

- Uses an LA head
- Has an HX PRO button for turning the Dolby HX PRO function on and off
- Is for sale in the U.S.A., Canada, and other non-European countries

#### Conventions

- Instructions in this manual describe the controls on the deck.
- The following icons are used in this manual:



Indicates useful information or tips that make a task easier.



Indicates a task that requires use of the remote.  
(Canadian model only)

# TABLE OF CONTENTS

---

Recording on a Tape	4
Playing a Tape	6

---

Getting Started	
Unpacking	7
Hooking Up the System	7

---

Advanced Playback Operations	
Locating a Track (AMS/Auto Play/Memory Play)	9
Playing Using a Timer	9

---

Advanced Recording Operations	
Adjusting Bias, Recording Level and Recording Equalizer Calibration	10
Monitoring the Recorded Sound	11
Inserting a Blank Space During Recording (Record Muting)	11
Recording Using a Timer	12
Synchro-Recording With a CD Player (Canadian Model Only)	12


---

Additional Information	
Precautions	13
Notes on Cassette Tapes	13
Cleaning	14
Troubleshooting	15
Specifications	16
Glossary	17


---


Index	18
-------	----

# Recording on a Tape





See page 7 for hookup information.

 **To protect recordings against accidental erasure**  
Break out the record-protect tab(s) (see page 13).

- 1** Turn on the amplifier and play the program source you want to record.
- 2** Set **TIMER** to **OFF** and press **POWER**.
- 3** Press  **OPEN/CLOSE** and insert a cassette.


With the side you want to record facing you



- 4** Press  **REC**.  
The cassette holder closes and the deck becomes ready to record. "SOURCE" and the tape type (I, II, or IV) appear in the display.



- 5** Turn **REC LEVEL** to adjust the recording level.  
The recording level should not exceed the recommended level for the indicated tape type.

After doing the all adjustments, stop playing the program source.



For type I or type II tape


For type IV tape

- 6** Press  **PAUSE** or .  
Recording starts.

7 Start playing the program source.


To	Press
Stop recording	■
Pause	⏸ PAUSE. Press the button again to resume recording.
Take out the cassette	⏏ OPEN/CLOSE after stopping recording

Use these buttons (controls) for additional operations




To adjust the recording balance

Turn REC LEVEL so that the L (left channel) and R (right channel) peak level meters in the display are at the levels you want. For normal settings, keep the red mark on each control aligned with each other.



To increase the left (L) channel level only, turn the outer control clockwise.



To increase the right (R) channel level only, turn the inner control clockwise.

To record with the Dolby NR\* system

Set DOLBY NR to the position you want (B, C, or S) before you start recording.

To record with Dolby HX PRO

Press HX PRO. "HX PRO" appears in the display. The HX PRO button and indicator are provided on TC-KA3ES only. (For details on HX PRO, see "Glossary" on page 17.)


If you cannot get satisfying results when recording FM broadcasts with Dolby NR system

Set MPX FILTER to ON. The filter turns on to make the Dolby NR system work more effectively. "FILTER" appears in the display. (For details on the MPX filter, see "Glossary" on page 17.)


- You can check how much blank remains on the tape
- 1 Locate the end of the recorded portion on the tape.
  - 2 Press RESET to reset the tape counter to "0.00."
  - 3 Press ►► to fast-forward the tape to its end. The tape counter shows the approximate amount of remaining time.


\* Dolby noise reduction and HX Pro headroom extension manufactured under license from Dolby Laboratories Licensing Corporation. HX Pro originated by Bang & Olufsen. "DOLBY," the double-D symbol and "HX PRO" are trademarks of Dolby Laboratories Licensing Corporation.


# Playing a Tape





See page 7 for hookup information.






 **To play a tape recorded with the Dolby NR system**  
Set DOLBY NR to the same position that the tape was recorded in—B, C, or S.

 **You can connect the headphones to PHONES**  
To adjust the volume, turn PHONES LEVEL.

- 1 Turn on the amplifier and select the tape deck position.
- 2 Set TIMER to OFF and press POWER.
- 3 Press  OPEN/CLOSE and insert a cassette.



- 4 Press .
- The cassette holder closes and the deck starts playing. "TAPE" and the tape type (I, II, or IV) appear in the display. Adjust the volume on the amplifier.

To	Press
Stop playing	
Pause	 PAUSE. Press the button again to resume play.
Fast-forward or rewind	 or  when the deck is stopped
Take out the cassette	 OPEN/CLOSE after stopping playing


Unpacking


Check that you have received the following supplied items:

- Remote commander (remote) RM-J701 (1)\*
- Size AA (R6) batteries (2)\*
- Audio connecting cord (2)

\* Canadian model only

Inserting batteries into the remote (Canadian model only)

Insert two size AA (R6) batteries, matching the + and – on the batteries with the markings inside the battery compartment. When using the remote, point it at the remote control sensor  on the tape deck.



 When to replace batteries


With normal use, the batteries should last for about 6 months. When the remote no longer operates the tape deck, replace all the batteries.

Notes

- Do not leave the remote near an extremely hot or humid place.
- Do not drop any foreign object into the remote casing, particularly when replacing the batteries.
- Do not expose the remote sensor to direct sunlight or lighting equipment. Doing so may cause a malfunction.
- If you don't use the remote for an extended period of time, remove the batteries to avoid possible damage from battery leakage and corrosion.

Hooking Up the System


This section describes how to hook up the tape deck to an amplifier. Be sure to turn off the power of each component before making the connections.



Hookups

When connecting an audio cord, be sure to match the color-coded cord to the appropriate jacks on the components: Red (right) to Red and White (left) to White. Be sure to make connections firmly to avoid hum and noise.


Connect the tape deck to the amplifier as shown below.



(Continued)


### To connect your tape deck to another tape deck

Connect both tape decks as shown below.



### Setting the voltage selector (only on models supplied with a voltage selector)

Check that the voltage selector on the rear panel of the tape deck is set to the local power line voltage. If not, set the selector to the correct position using a screwdriver before connecting the AC power cord to an AC outlet.



### Connecting the AC power cord

Connect the AC power cord to an AC outlet.

The tape deck's Memory Backup function (page 17) keeps the various settings in memory even after you turn off the power as long as AC power cord is plugged in.


### Where do I go next?

Now you're ready to use your tape deck.

For basic operations, go to pages 4 to 6; for advanced operations, go to the sections immediately after this one.

Locating a Track (AMS/Auto Play/ Memory Play)

You can locate the following/previous tracks (AMS: Automatic Music Sensor) or the beginning of a tape quickly. You can even locate a specific point anywhere on a tape.



To locate	Press
the beginning of the next or succeeding tracks (AMS*)	⏮ as many times as you want while playing. For example, to locate 2 tracks ahead, press twice.
the beginning of the current track (AMS*)	⏮ once while playing
the beginning of the preceding tracks (AMS*)	⏮ as many times as you want while playing. For example, to locate 2 tracks behind, press three times.
the beginning of a tape (auto play)	MEMORY repeatedly until "MEMORY" disappears in the display. Then press ⏮ while holding down ⏭.
a particular point on a tape (memory play)	MEMORY repeatedly until "MEMORY" appears in the display. Find the point you want, and press RESET to reset the tape counter and to memorize the point. To locate the memorized point, press ⏮ while holding down ⏭. (Press ⏮ only to stop at "0.00.")

\* You can use the AMS to locate up to the 30th track after or before the current track.

You can change the indication on the display (Canadian model only)

Press DISPLAY on the remote repeatedly to change the display as follows:


→ tape counter only → no display → full display

Notes

- The AMS function may not work correctly if:
  - the blank space between tracks is less than 4 seconds long.
  - the signal strength of the left and right channels are very different.
  - there is a passage of low frequencies or very low volume within a track.
- Since the counter is not a digital clock, it will differ from the actual elapsed playback or recording time.

Playing Using a Timer

You can start playing a tape at any time you want by connecting a timer (not supplied). Please also refer to the instructions of the timer if you need help.




- 1 Insert a cassette.
- 2 Set TIMER on the tape deck to PLAY.
- 3 Set the timer to the time you want. The tape deck turns off. When the set time comes, the tape deck turns on and start playing.
- 4 After you have used the timer, set TIMER on the tape deck to OFF.


## Adjusting Bias, Recording Level and Recording Equalizer Calibration

Since there are many different types of cassettes on the market, the tape deck automatically sets the appropriate equalization characteristics and bias current for each tape type (ATS: Automatic Tape Selection).


However, you can get better recording results by adjusting the bias current, recording level and recording equalizer.




- 1 Insert the cassette you want to record on.
- 2 Press CALIBRATION.  
The display for adjusting the bias, recording level and recording equalizer appears.




- 3 Press ● REC.
- 4 Press II PAUSE or ► to record the test tones. (You can't hear the test tones.)  
After two or three seconds, the meters showing the level of the test tones appear in the display.  
Then adjust, in sequence, the bias, recording level and recording equalizer.
- 5 Adjust BIAS CALIBRATION so that both meters indicate equal signal levels.  
If the upper meter shows a higher level than the lower meter, turn the BIAS CALIBRATION clockwise.  
If the lower meter shows a higher level than the upper meter, turn the BIAS CALIBRATION counterclockwise.



- 6 Adjust REC LEVEL CALIBRATION so that only ■ appears. Make sure either ◀ or ▶ does not appear.  
If ▶ appears, turn REC LEVEL CALIBRATION clockwise.  
If ◀ appears, turn REC LEVEL CALIBRATION counterclockwise.



- 7 Adjust REC EQUALIZER CALIBRATION so that both meters reach the recommended level.  
Turn REC EQUALIZER CALIBRATION clockwise to increase both meters.  
Turn REC EQUALIZER CALIBRATION counterclockwise to decrease both meters.



Repeat steps 5 to 7 if necessary.

- 8 Press ■ to stop recording the test tones.  
The display returns to normal.
- 9 Rewind the tape and start the actual recording.


You can also adjust the bias, recording level and the recording equalizer according to your own taste  
For details, see on page 17.

### Notes

- Because the meters use a wider amplitude during tape calibration, they are more sensitive to slight changes in signal level.
- When you use metal (type IV) tapes, the frequency response to adjustments of the bias current is small. Therefore, adjusting the bias current with the range of this tape deck (a range of about  $\pm 20\%$ ) may not be effective.

## Monitoring the Recorded Sound

You can compare the quality of the recorded sound with the sound of the program source while recording.



While recording, press MONITOR repeatedly until "TAPE" appears in the display.


You can monitor the sound being recorded.

### To listen to the sound of the program source

Press MONITOR repeatedly until "SOURCE" appears in the display.

## Inserting a Blank Space During Recording (Record Muting)

You can insert a blank space of 4 seconds between each track. The blank spaces between tracks let you locate the track easily with the AMS function (see page 9). Also, use this function to eliminate only unwanted portions on the tape.




- 1 Start recording.
- 2 Press **○ REC MUTE** once when you want to insert a blank space.  
The REC indicator starts flashing and the tape moves on without recording any signals.  
After 4 seconds, the **|| PAUSE** indicator lights up and the tape deck is now ready to resume recording.
- 3 Press **|| PAUSE** or **▶** to resume recording.

- 💡 To insert a blank space longer than 4 seconds**  
Hold down **○ REC MUTE** as long as you want. After 4 seconds, the REC indicator flashes faster.  
When you release the **○ REC MUTE**, the **|| PAUSE** indicator lights up and the tape deck is ready to resume recording.  
Press **|| PAUSE** or **▶** to resume recording.

- 💡 To insert a blank space of less than 4 seconds**  
After pressing **○ REC MUTE**, press **|| PAUSE** at any time. The deck changes to recording pause. To resume recording, press **● REC** instead of **|| PAUSE**.

## Recording Using a Timer

You can start recording on a tape at any time you want by connecting a timer (not supplied). Please also refer to the instructions of the timer if you need help.




- 1 Insert a cassette.
- 2 On the amplifier, select the program source you want to record.
- 3 On the tape deck, set **TIMER** to **REC**.
- 4 Set the timer to the time you want.  
The tape deck turns off. When the set time comes, the tape deck turns on and start recording.
- 5 After you have used the timer, set **TIMER** on the tape deck to **OFF**.

### Note

If the **TIMER** switch is set to **REC**, the tape deck will automatically start recording when you turn on the tape deck.

## Synchro-Recording With a CD Player (Canadian Model Only) ⓘ

By pressing **CD SYNCHRO START** on the remote (supplied with the Canadian model only), you can perform synchro-recording on your tape deck with a Sony CD player. This function is possible only with Sony CD players with remote control capability.



- 1 Insert a CD into the CD player.
- 2 Insert a cassette into the tape deck.
- 3 Press **CD SYNCHRO STANDBY** on the remote. The CD player changes to play pause and the tape deck to recording pause.
- 4 Press **CD SYNCHRO START** on the remote. The tape deck starts recording, and then the CD player starts playing.

### To stop Synchro-Recording

Press **CD SYNCHRO STOP**.

### To pause Synchro-Recording

Press **II** for the tape deck and CD player at the same time.  
Press both buttons again to resume Synchro-Recording.



### You can use the remote of your tape deck to operate the CD player

To start CD play, press **II** twice; to pause CD play, press **II** once; to locate a CD track, press **I<<** or **>>I**.

### Precautions

#### On safety

- Do not disassemble the cabinet — this may result in an electrical shock. Refer servicing to qualified personnel only.
- Should any solid object or liquid fall into the cabinet, unplug the tape deck and have it checked by qualified personnel before operating it any further.

#### On power sources

- Before operating the tape deck, check that the operating voltage of the tape deck is identical with your local power supply. The operating voltage is indicated on the nameplate at the rear of the tape deck.
- The tape deck is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the tape deck itself has been turned off.
- If you are not going to use the tape deck for a long time, be sure to disconnect the tape deck from the wall outlet. To disconnect the AC power cord (mains lead), grasp the plug itself; never pull the cord.
- Should the AC power cord (mains lead) need to be changed, have it done at a qualified service shop only.

#### On placement

- Place the tape deck in a location with adequate ventilation to prevent heat build-up in the tape deck.
- Do not place the tape deck:
  - on a soft surface such as a rug that might block the ventilation holes on the bottom.
  - in a location near heat sources.
  - in a place subject to direct sunlight.
  - in an inclined position.
  - in a place subject to excessive dust or mechanical shock.

#### On cleaning the tape deck

Clean the cabinet, panel and controls with a soft cloth slightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent such as alcohol or benzene.

If you have any questions or problems concerning your tape deck, please consult your nearest Sony dealer.


#### For the customers in the U.S.A.

For detailed safety precautions, see the leaflet "IMPORTANT SAFEGUARDS."

### Notes on Cassette Tapes


#### To protect the recording

Break off the respective tab for side A or B.




#### To record on a tape having a broken tab

Cover the respective tab hole for side A or B with adhesive tape.



When you are using a type II or type IV tape, be careful not to cover the slots that the deck uses to determine the tape type.



#### On tapes longer than 90 minutes


We do not recommend the use of tapes longer than 90 minutes except for a long continuous recording or playback. They are very thin and tend to be stretched easily.

#### On handling cassettes

- To prevent the heads and tape path from getting dirty, avoid touching the tape surface of a cassette.
- Place cassettes away from equipment with magnets, such as speakers and amplifiers; it may cause tape distortion or erase the recordings.
- Do not expose cassettes to direct sunlight, extremely cold temperature or moisture.

## Cleaning

Inside of the cassette holder



### Cleaning the heads and tape path

Clean the heads and tape path of the tape deck after every 10 hours of operation to guard against:

- a decrease in sound level
- excessive wow or flutter
- sound dropout
- incomplete erasure

To ensure better recording, we recommend that you clean the heads and tape path before every recording.

- 1** Set the volume control on the amplifier to minimum.
- 2** With the tape deck turned off, hold down ≡ OPEN/CLOSE and press POWER. The holder opens, the heads rise, and the pinch rollers begin to rotate.
- 3** Wipe the heads, the pinch rollers, and the capstans with a cotton swab slightly moistened with alcohol or a commercially available cleaning fluid for tape decks.
- 4** When completed, press ≡ OPEN/CLOSE again. Do not insert a cassette until the cleaned areas are completely dry.

## Demagnetizing the heads

After 20 to 30 hours of use, or when you notice a hissing sound or loss of high frequencies, demagnetize the heads with a commercially available demagnetizer for tape decks. Please refer to the instructions of the demagnetizer.

## Troubleshooting

If you've experienced any of the following difficulties while using the tape deck, use this troubleshooting guide to help you remedy the problem. Should any problem persist, consult your nearest Sony dealer.

### The cassette holder does not close.

- ➔ Reinsert the AC power cord, then close the cassette holder.

### The function buttons do not work.

- ➔ The tape deck has just been turned on and does not operate for about 3 seconds. Wait until the **II** indicator stops flashing.
- ➔ Check that the cassette is inserted correctly and the cassette holder is closed completely.

### Playback or recording begins when the power is turned on.

- ➔ Set **TIMER** on the tape deck to **OFF**.

### The tape stops before the tape has been fully rewound.

- ➔ The tape is slack. Take up the tape slack.
- ➔ If **"MEMORY"** is shown in the display, press **MEMORY** repeatedly until the indication disappears.
- ➔ The cassette shell is bent. Use another cassette.

### The tape deck does not play or record.

- ➔ The tape has reeled to the end.
- ➔ The tape is slack. Take up the tape slack.
- ➔ The record-protect tab has been removed from the cassette. Cover the slot with tape (page 13).
- ➔ Clean the heads and tape path and demagnetize the heads (page 14).
- ➔ Check that the tape deck is properly connected (page 7).
- ➔ Make sure the amplifier is correctly set.

### There is excessive wow, flutter, or a sound dropout.

- ➔ The capstans and pinch rollers are dirty. Clean them (see page 14).

### There is a decrease in sound level or a sound dropout./The tape does not erase completely./Noise increases.

- ➔ The heads and tape path are dirty. Clean them (see page 14).
- ➔ The heads are magnetized. Demagnetize them (see page 14).

### There is hum or noise.

- ➔ The tape deck is placed near a TV or VCR. Place the tape deck away from the TV or VCR.
- ➔ The tape deck is placed on or under the amplifier. Place the tape deck away from the amplifier.

### There is an unbalanced tone.

- ➔ Check that the **DOLBY NR** control is set to the position where the tape was recorded.
- ➔ The tape deck is placed near a TV or VCR. Place the tape deck away from the TV or VCR.

### The AMS function does not work properly.

- ➔ One of the tracks contains a long pause, a passage of low frequencies or very low volume, or a gradual increase or decrease in volume.
- ➔ The space before a track is less than 4 seconds long. Insert a blank space of 4 seconds using **○ REC MUTE** button.
- ➔ The signal strength of the left and right channels are very different.
- ➔ There is noise in the space before a track.
- ➔ You pressed **▶▶** button immediately before the next track, or **◀◀** button immediately after the beginning of the current track.

## Specifications

System		
Recording system		
4-track 2-channel stereo		
Fast winding time (approx.)		
90 sec. (with Sony C-60 cassette)		
Bias		
AC bias		
Heads		
Head (×1)	TC-KA6ES	TC-KA3ES
Erasing	S&F	S&F
Recording	SD	LA
Playing	SD	LA
Motors		
Capstan motor × 1 (direct drive linear torque BSL motor)		
Reel motor × 1 (DC motor)		
Assist (mechanism drive) motor × 1 (DC motor)		
Signal-to-noise ratio (at peak level, weighted, and with Dolby NR off)		
Type I tape, Sony Type I (NORMAL): 57 dB		
Type II tape, Sony Type II (HIGH): 59 dB		
Type IV tape, Sony Type IV (METAL): 61 dB		
S/N ratio improvement		
Dolby NR on	Approximate values	
B	5 dB at 1 kHz, 10 dB at 5 kHz	
C	15 dB at 500 Hz, 20 dB at 1 kHz	
S	10 dB at 100 Hz, 24 dB at 1 kHz	
Harmonic distortion		
Tape type	TC-KA6ES	TC-KA3ES
Type I tape Sony Type I (NORMAL)	0.4% (160 nWb/m 315 Hz, 3rd H.D.)	
Type IV tape Sony Type IV (METAL)	1.5% (250 nWb/m 315 Hz, 3rd H.D.)	1.3% (250 nWb/m 315 Hz, 3rd H.D.)
Frequency response (Dolby NR off)		
Tape type	TC-KA6ES	TC-KA3ES
Type I tape Sony Type I (NORMAL)	20 - 17,000 Hz (±3 dB, IEC)	15 - 17,000 Hz (±3 dB, IEC)
Type II tape Sony Type II (HIGH)	20 - 19,000 Hz (±3 dB, IEC)	15 - 20,000 Hz (±3 dB, IEC)
Type IV tape Sony Type IV (METAL)	20 - 21,000 Hz (±3 dB, IEC)	15 - 22,000 Hz (±3 dB, IEC)
	20 - 16,000 Hz (±3 dB, -4dB recording)	15 - 16,000 Hz (±3 dB, -4dB recording)

Wow and flutter	
TC-KA6ES	TC-KA3ES
±0.05 % W. Peak (IEC)	±0.04% W. Peak (IEC)
0.025 % W. RMS (NAB)	0.022% W. RMS (NAB)
±0.07 % W. Peak (DIN)	±0.065% W. Peak (DIN)

Inputs	
Line inputs (phono jacks)	
Sensitivity: 0.16 V	
Input impedance: 47 kilohms	
Outputs	
Line outputs (phono jacks)	
Rated output level : 0.5 V at a load impedance of 47 kilohms	
Load impedance : Over 10 kilohms	
Headphones (stereo phone jack)	
Output level : 0 - 3 mW at a load impedance of 32 ohms	

General	
Power requirements	
Where purchased	Power requirements
U.S.A. and Canada	120 V AC, 60 Hz
Europe	220 - 230 V AC, 50/60 Hz
Other countries	120, 220 or 240 V AC adjustable, 50/60 Hz

Power consumption	
30 W	
Dimensions (approx.) (w/h/d)	
430 × 135 × 360 mm (17 × 5 <sup>3</sup> / <sub>8</sub> × 14 <sup>1</sup> / <sub>4</sub> inches)	
incl. projecting parts and controls	
Mass (approx.)	
7.6 kg (16 lbs 13 oz)	
Supplied accessories	
Audio connecting cords (2)	
Remote commander RM-J701 (1)*	
Sony batteries SUM-3(NS) (2)*	

\* Canadian model only

Design and specifications are subject to change without notice.

Glossary

AMS


Automatic Music Sensor. A function that locates the beginning of a track by detecting a blank space of over 4 seconds between tracks.

ATS

Automatic Tape Selection. The tape deck automatically sets the appropriate equalization characteristics and bias current according to the tape type inserted in the deck.

Bias calibration

Adjustment for optimum recording. You can get better recording results with minimum distortion and flat frequency response by adjusting the bias current to the appropriate level. Lowering the bias current can boost high-frequency response, but also cause higher distortion. On the other hand, raising the bias current can minimize distortion, but also reduce high-frequency response. To balance both the bias current and high-frequency response, it is necessary to adjust the bias current appropriately. However, to suit your taste, you can also adjust the bias current as you want.




Dolby HX PRO system

Distortion and noise reduction system. The Dolby HX PRO system reduces distortion and noise in high-frequency response while recording. A tape recorded with this system brings the same high-quality sound even when you play the tape on the other tape decks.

Dolby NR (noise reduction) system

Noise reduction system for eliminating hissing noise. The Dolby NR system boosts the low-level signals in high frequency during recording and restores them during playback. There are 4 types in the Dolby NR system: A, B, C and S. A-type is for professional use (not available on this tape deck), and B, C and S-types are for consumer use. S-type has the maximum noise reduction capability, followed by C and B.



Memory Backup


Function for storing tape deck operating parameters after the power is turned off. The memorized parameters are:  
— linear counter and counter memory parameters  
— MPX FILTER, Dolby HX PRO and MONITOR settings.  
To reset parameters to their original factory settings, turn on the tape deck while holding down both RESET and  $\odot$  REC MUTE.

MPX filter

Multiplex filter. A filter for eliminating the 19-kHz stereo carrier and the 38-kHz sub-carrier signals that may impair the Dolby NR system. Usually the tuner has an MPX filter. If you cannot get a satisfying result when recording FM broadcasts with Dolby NR system, your tuner does not have a filter or the filter is not working. In this case, set the MPX FILTER switch on the tape deck to ON.


Recording equalizer calibration

Adjustment for optimum recording. Use the REC EQ control to adjust the equalizer to suit your taste. Turning the control clockwise emphasizes the high and middle frequencies; turning the control counterclockwise reduces the high and middle frequencies.



Recording level calibration

Adjustment for optimum recording. Even when you have adjusted the recording level correctly, the playing level might turn out to be low depending on the tape used. By adjusting the recording level calibration, you can compensate for the low recording level. When you record on a tape with the Dolby NR system, this function works more effectively.



Tape counter

A display element that shows the elapsed recording or playing time as a digital readout. Since the counter is not a digital clock, the displayed value will differ slightly from the actual elapsed recording or playing time. The counter value also includes the length of the leader tape.

Test tones

15-kHz, 3-kHz and 400-Hz signals produced by the tape deck when you do the bias, recording equalizer and recording level calibration.

## Index

## A

- Adjusting
  - recording balance 5
  - bias calibration 10
  - recording equalizer calibration 10
  - recording level 4
  - recording level calibration 10
  - volume 6
- AMS 9, 17
- ATS 10, 17
- Auto play 9
- Automatic Music Sensor. *See* AMS
- Automatic Tape Selector. *See* ATS

## B, C

- Balance 5
- Bias calibration 10, 17
- Cassette. *See* Tape
- Checking the remaining time 5
- Cleaning
  - cabinet 13
  - heads and tape path 14
- Connecting. *See* Hookups
- Counter. *See* tape counter

## D, E, F, G

- Demagnetizing the heads 14
- Dolby HX PRO system 5, 17
- Dolby NR system 5, 6, 17
- Glossary 17

## H, I, J, K

- Heads
  - cleaning 14
  - démagnetizing 14
- Hooking up the system 7
- Hookups 7
- Insert
  - batteries into the remote 7
  - blank space 11
  - cassette 4, 6

## L

- Locating
  - beginning of the tape 9
  - particular point 9
  - tracks 9

## M, N, O

- Memory backup 17
- Memory play 9
- Monitoring sound 11
- MPX filter. *See* Multiplex filter
- Multiplex filter 5, 17
- Noise reduction 5, 17
- Notes on cassette tapes. *See* Tape notes

## P, Q

- Playing
  - a tape 6
  - auto play 9
  - memory play 9
  - using a timer. *See* Timer
  - playing
- Precautions 13

## R

- Recording
  - equalizer calibration 10, 17
  - level calibration 10, 17
  - on a tape 4
  - using a timer. *See* Timer
  - recording
- Record muting 11
- Remaining time 5

## S

- Searching. *See* Locating
- Specifications 16
- Synchro-recording 12

## T

- Tape
  - counter 5, 9, 17
  - notes 13
  - path cleaning 14
  - protect the recording 13
  - type 4, 6, 13
- Test tones 10, 17
- Timer
  - playing 9
  - recording 12
- Troubleshooting 15

## U, V, W, X, Y, Z

- Unpacking 7

## Names of Controls

## Buttons

- CALIBRATION 10
- CD SYNCHRO STANDBY 12
- CD SYNCHRO START 12
- CD SYNCHRO STOP 12
- HX PRO 5
- MEMORY 9
- MONITOR 11
- MPX (multiplex) FILTER 5
- RESET 9
- ⏮ / ⏭ (AMS) 9
- ⏮ / ⏭ CD (CD AMS) 12
- ⏮ (rewind) 6, 9
- ▶ (play) 4, 9, 10
- ⏭ (fast-forward) 6
- ⏻ OPEN/CLOSE 4 - 6
- (stop) 5, 6
- ⏸ PAUSE 4 - 6
- ⏸ CD (CD pause) 12
- REC MUTE (record muting) 11
- REC (recording) 4, 10

## Switches

- DOLBY NR (noise reduction) 5, 6
- POWER 4, 6, 14
- TIMER 4, 6, 9, 12

## Controls

- BIAS 10, 17
- PHONES LEVEL 6
- REC (recording) EQ (equalizer) 10, 17
- REC (recording) LEVEL 4
- REC (recording) LEVEL (for calibration) 10, 17

## Jack

- PHONES 6

## Others

- Cassette holder 4, 6

**INFORMATION**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**CAUTION**

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.