

# ***Audio Adapter***

---

Operating Instructions

**CLiÉ**

***PEGA-SA500***

## WARNING

### Owner's Record

The model number and serial number are located at the rear of the product. Record the serial number in the space provided below. Refer to them whenever you call upon your Sony dealer regarding this product.

Model No. PEGA-SA500

Serial No. \_\_\_\_\_

### CAUTION

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

### NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by rotating the equipment off and on, the user is encouraged to try to correct the interference using one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If you have question about this product, call the Sony Customer Information Center at keep on next line 1-877-760-7669; or write to the Sony Customer Information Center at 12451 Gateway Boulevard, Fort Myers, FL 33913. The number below is for FCC-related matters only.

### Declaration of Conformity

Trade Name: SONY

Model No.: PEGA-SA500

Responsible Party: Sony Electronics Inc.

Address: 680 Kinderkamack Road, Oradell, NJ 07649 USA

Telephone No.: 201-930-6972

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

The supplied interface cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules.

### On the supplied software

- Copyright laws prohibit reproducing the software or the software manual in whole or in part, or renting the software without the permission of the copyright holder.
- In no event will SONY be liable for any financial damage or loss of profits, including claims made by third parties, arising out of the use of the software supplied with this player.
- In the event a problem occurs with this software as a result of defective manufacturing, SONY will replace it at SONY's option or issue a refund. However, SONY bears no other responsibility.
- The software provided with this product cannot be used with equipment other than that which it is designated for use with.
- Please note that, due to continued efforts to improve quality, the software specifications may be changed without notice.

Program © 2001 Sony Corporation, or its subsidiaries. All rights reserved.

Documentation © 2001 Sony Corporation



- CLIE, Jog Dial, Memory Stick, the Memory Stick logo and PictureGear are trademarks of Sony Corporation.
- HotSync and Palm OS are registered trademarks, and the HotSync logo and Palm are trademarks of Palm, Inc. or its subsidiaries.
- Microsoft® and Windows® are registered trademarks of Microsoft Corporation in the United States and/or other countries.
- RealJukebox is trademark of RealNetworks, Inc..
- generic media and gMovie are trademarks of generic media, inc.
- Adobe and Acrobat are trademarks of Adobe Systems Incorporated.
- All other trademarks are trademarks of their respective owners.

### CAUTION

Please contact your nearest Sony dealer regarding the problem you are experiencing with your Sony product.

### Notes

- Sony does not support third-party add-on applications. If you are having a problem with a third-party application, please contact the developer or publisher of that software.
- The illustrations in this manual may differ from the actual software.
- Explanations in this manual assume that you are familiar with basic operations of Windows®. For how to use your computer and operating system, please refer to their respective manuals.

Before using this product, be sure to read the accompanying End-User's License Agreement.

# Contents

Welcome .....	4
What you can do with the Audio Adapter .....	4
CLIE handheld models that support the Audio Adapter .....	4
Unpacking Your Audio Adapter ....	5
What's in the Supplied CD-ROM ...	5
Controls and Connectors and Their Functions .....	6
Installing the Software .....	7
Listening to Audio Files .....	9
Operation overview .....	9
Preparations performed on your computer .....	9
Transferring audio files to the Memory Stick on your CLIE handheld from your computer .....	10
Connecting the Audio Adapter .....	12

Using Audio Player for Adapter application on your CLIE handheld .....	13
Playing audio files with the Audio Adapter .....	15
Using the online manual for Audio Player for Adapter .....	17
Watching Movies with Audio Sound .....	18
Operation overview .....	18
Transferring movies to your CLIE handheld from your computer .....	18
Connecting the Audio Adapter .....	19
Using gMovie application on your CLIE handheld .....	19
Using the online manual for gMovie .....	21
Others .....	22
Specifications .....	22
Notes on use .....	23
Troubleshooting .....	24

---

# Welcome

## What you can do with the Audio Adapter

The Audio Adapter allows you to play back audio on CLIÉ handheld models that have no audio playback capabilities.

Connecting the remote-controller-shaped adapter to the interface connector on your CLIÉ handheld enables the CLIÉ handheld to play back audio.

### Audio Player for Adapter:

Audio Player for Adapter is a software application that allows your CLIÉ handheld to play back MP3-format audio data stored on a Memory Stick media. It is contained on the CD-ROM supplied with this Audio Adapter.

### gMovie Ver.1.4:

gMovie™ is a software application that allows your CLIÉ handheld to play back movies with audio sound stored on DRAM or Memory Stick® media. It is contained on the CD-ROM supplied with this Audio Adapter.

#### Notes

- Never install Audio Player for Adapter supplied with this adapter onto a CLIÉ handheld with audio playback capabilities\*. Installation of such software will cause the CLIÉ handheld to malfunction.
- The Audio Adapter provides playback of MP3-format audio data and gMovie audio sound only. Please note that it does not support ATRAC3-format data, for which MagicGate™ Memory Stick media is required. For specifications of the MP3 formatted files available for playback, see the online manual of Audio Player for Adapter.
- Some CLIÉ handhelds may be slow to respond when they are connected to this adapter. This is not malfunction.

\* PEG-N710C, PEG-N760C (as of September 2001)


## CLIÉ handheld models that support the Audio Adapter

- PEG-S300
- PEG-S320
- PEG-N610C

---

# Unpacking Your Audio Adapter

- ❑ Audio adapter (1)




- ❑ Headphones (1 pair)
- ❑ CD-ROM (1)
- ❑ Operating Instructions (1)
- ❑ Warranty card (1)

---

## What's in the Supplied CD-ROM

- **Software and application for playing MP3 audio files**  
RealJukebox 2 Basic for Sony (The rest is omitted as "RealJukebox for Sony")  
Audio Player for Adapter
- **Software and application for playing movies with audio sound**  
PictureGear Ver. 4.4 Lite  
gMovie Ver. 1.4
- **Software for displaying the online manual of Audio Player for Adapter and gMovie**  
Adobe Acrobat Reader

# Controls and Connectors and Their Functions



- 1 Interface connector**
- 2 ►/■ AMS button**  
Starts or stops playback.
- 3 ◀◀/▶▶ AMS button**  
Searches for the beginning of the current or next track.
- 4 Volume adjustment button**  
Adjusts the headphone volume.
- 5 Busy lamp**  
Lights when the Audio Adapter is running.
- 6 Lock release button**  
Press and hold this button down to connect/disconnect the interface connector to/from your CLIÉ handheld. For connection, make sure that the connector is firmly seated in place when you release the button.
- 7 HOLD switch**  
Use this switch to prevent accidental operation of the buttons.  
Slide the HOLD switch to ON to disable button operations on the Audio Adapter.
- 8 Clip**  
Use this clip to hook the Audio Adapter to your pocket and so on.
- 9 Headphones jack**  
Connect the supplied headphones here to listen to audio.

---

# Installing the Software

To play back MP3-format audio files and movies with audio on your CLIE handheld using the Audio Adapter, you must first install Audio Player for Adapter, gMovie, and the required system softwares onto your CLIE handheld from the supplied CD-ROM. You must also install RealJukebox for Sony and PictureGear onto your computer from it.

## Notes

- Never install Audio Player for Adapter supplied with this adapter to a CLIE handheld with audio playback capabilities\*. Installation of such software will cause the CLIE handheld to malfunction.
- The Audio Adapter provides playback of MP3-format audio data and gMovie audio sound only. Please note that it does not support ATRAC3-format data, for which MagicGate Memory Stick media is required.
- Make sure to attach the cradle to your CLIE handheld and connect it to your computer for HotSync® operation before installing the software. For information on connecting the cradle to your computer and HotSync operation, see the manual that came with your CLIE handheld.
- Installation requires a CD-ROM drive. If your computer does not have an internal CD-ROM drive, make sure to provide CD-ROM access for your computer before performing the following procedure. For information on how to use CD-ROMs, see the printed or online manual for your computer or CD-ROM drive.

\* PEG-N710C, PEG-N760C (as of September 2001)

## 1 Insert the supplied CD-ROM into the CD-ROM drive on your computer.

The installer software starts up and the Installation Menu screen appears.



If the installer software does not start up automatically, open the CD-ROM window and double-click the “Setup” icon (Setup.exe).

## 2 Click “Install Audio Adapter system files.”

(Continued)

### **3 Follow the on-screen instructions of the installer software.**

- In the screen for selecting the PEG-S series or PEG-N series model, select the model that applies to your CLIÉ handheld.

#### **Notes**

- If you have more than one model, install the software onto each model.
- In the screen for selecting a user name, select the name that you will be using.

### **4 When the screen that ends the installation appears, click [Finish].**

Your computer is now ready for installing the software for Audio Adapter. The Installation Menu screen appears on the display monitor of your computer. Install RealJukebox for Sony, PictureGear, etc. to your computer.

### **5 Click “Install RealJukebox for Sony.”**

Follow the on-screen instructions to proceed.

### **6 Click “Install image and movie software....”**

Follow the on-screen instructions to proceed.


Installation onto your computer is now complete. Continue by installing the software applications which are prepared as shown in 1 to 4.

### **7 Perform a software reset on your CLIÉ handheld.**

For information on doing a software reset, see the manual that came with your CLIÉ handheld.

### **8 With the cradle attached to the CLIÉ handheld, connect the CLIÉ handheld to your computer.**

### **9 Activate the local HotSync function on your CLIÉ handheld.**

Press the  button on the front of the cradle. The local HotSync function is activated and softwares for the Audio Adapter that are set on the steps 3 to 5 is installed on your CLIÉ handheld.



---

# Listening to Audio Files

Memory Stick is required for playing back audio files with Audio Player for Adapter.

## Operation overview

Follow the procedure mentioned below:

- ① Follow the procedure mentioned on page 7 and 8 to install the necessary software onto your computer and CLIÉ handheld.
- ② Prepare to transfer to your computer.
- ③ Move the audio files from your computer to the Memory Stick on your CLIÉ handheld.
- ④ Connect the Audio Adapter.
- ⑤ Start up and operate the Audio Player for Adapter application on your CLIÉ handheld.

## Preparations performed on your computer

The Audio Adapter provides playback of MP3-format audio data only. Special software is required for managing or creating MP3-format audio files on your computer.

Use commercially available MP3-compatible audio management software, or the RealJukebox for Sony software provided on the supplied CD-ROM.

\* RealJukebox is a product of RealNetworks, Inc.

### ● How to convert audio CD data to MP3-format data using the supplied RealJukebox for Sony software.

Use RealJukebox for Sony software to convert data on an audio CD to the MP3-format and register the data to a playlist on the hard disk.

### 1 Double-click the RealJukebox icon on your Windows desktop, or click [Start], point to "Programs", "Real", "RealJukebox", and then click "RealJukebox".

RealJukebox starts up.

When you start up the RealJukebox software for the first time, the Settings screen appears. Follow the procedure for setup. For more information, refer to the online manual for Audio Player for Adapter.

(Continued)

## 2 Make the following settings on the main window of RealJukebox.

These settings are required for first-time use only.

- ① Click “Tools” and “Preferences” on the menu bar, and select “Audio Quality.”
  - Select “MP3 Audio” under “Select a Format.”
  - Select “96 kbps Stereo” under “Select a Quality Level.”
  - Click ☒ for “Secure my Music Files when encoding” under “Secure Files” to uncheck it.

The copyright warning window appears.

- ② Read the copyright warning window carefully, and click the radio button for “I accept the above terms” to check it.
- ③ Click “OK.”


## 3 Insert the audio CD with the data that you want to convert to into the CD-ROM drive.

The “Auto-record” dialog box appears.

## 4 Click “Yes, record the CD now” and then click [OK].

Recording starts.

When recording completes, MP3-format audio data is saved to the folder at C:\My Music\ (Artist’s name)\ (CD Title).

To cancel the recording, click .

### Notes

- If you have purchased commercially available MP3-compatible audio management software, refer to the manual or help files for that software.
- Some MP3 formats are not supported for successful playback depending on the audio management software.

## Transferring audio files to the Memory Stick on your CLIÉ handheld from your computer

- 1 Make sure the write-protect tab on the Memory Stick media is not in the LOCK position, and then insert the media into the Memory Stick slot on your CLIÉ handheld.
- 2 Turn the Jog Dial navigator on the home screen of your CLIÉ handheld to select the “AudioPlayer” icon, and then press the Jog Dial navigator.

You can also start up Audio Player for Adapter by tapping the “AudioPlayer” icon.

Audio Player for Adapter starts up.

**3 Using the USB cable or the cradle which comes with the CLIÉ handheld, attach your CLIÉ handheld to your computer.**

**4 Tap , "Options", and then "Transfer" consecutively. Audio Player for Adapter changes to Transfer mode.**

**5 Double-click the "My Computer" icon on your Windows desktop.**

Your CLIÉ handheld in Transfer mode appears as a removable drive in the "My Computer" window.

**6 Double-click the "Removable Drive" icon.**

**7 Double-click the "PALM", "PROGRAMS", and then "MSAUDIO" folders.**

If these folders do not exist, create them on the Memory Stick media using Windows Explorer. Make sure that the Memory Stick media has sufficient capacity.

**8 Drag and drop the MP3-format audio files (to be played back on your CLIÉ handheld) into the folder you opened in step 7.**

#### Notes


- Do not exit or operate HotSync while transferring music data (while Memory Stick lamp is flashing).
- For information on transferring MP3-format audio files to your CLIÉ handheld, see the online manual for Audio Player for Adapter.
- If the automatic shut-off function of your CLIÉ handheld is activated in the middle of the above steps, the connection between the CLIÉ handheld and your computer is interrupted. Turn on the CLIÉ handheld once again and exit the Transfer mode, and then follow the step 4 on the previous page to re-enter the Transfer mode.

## You can also use the Memory Stick slot on your computer


For more information, refer to the online manual for Audio Player for Adapter.

## Connecting the Audio Adapter

- 1 Connect the headphones to the headphones jack on the adapter.



- 2 Connect the Audio Adapter to the Interface connector on your CLIÉ handheld.



### Notes

- Do not connect any equipment that is connected to other equipment, such as an amplifier, to the headphones jack on this adapter. Such a connection may cause the CLIÉ handheld to malfunction.
- Do not apply strong shock to the connector while using. This action may cause malfunction.

## Disconnecting the Audio Adapter

Press and hold down the lock release button on the Audio Adapter to remove the adapter.

## Wearing the headphones

Insert the ear piece with the “R” mark into your right ear, and the other with the “L” mark into your left ear.



# Using Audio Player for Adapter application on your CLIÉ handheld

Audio Player for Adapter allows you to play back audio files. Before starting playback, be sure the battery is fully charged.

## Notes

- The automatic shut-off function of your CLIÉ handheld is disabled during playback.
- Playback automatically stops when battery power becomes low; however, you can still use other software applications such as Memo Pad or Address Book. Make sure to recharge the battery as soon as possible before it is completely drained.
- When Audio Player for Adapter or gMovie is starting up, Beam Transfer is not possible. "Beam Receive" under "Preferences" may be set to OFF, in some cases.

## 1 Insert the media into the Memory Stick slot on your CLIÉ handheld.

## 2 Turn the Jog Dial navigator on the home screen of your CLIÉ handheld to select the "AudioPlayer" icon, and then press the Jog Dial navigator to start up Audio Player.

You can also tap the "AudioPlayer" icon to start up the software. Audio Player for Adapter starts and loads the music data from the Memory Stick media.

Do not remove the Memory Stick media while the data is being loaded (also while the Memory Stick lamp on your CLIÉ handheld is flashing). Otherwise, the data may be destroyed or corrupted, or the CLIÉ handheld may malfunction.

## Notes

- When the built-in battery power in the CLIÉ handheld is not charged sufficiently, the malfunctions may occur. For example, the Audio Player for Adapter does not start up or operate, or the power is turned off suddenly while using. Be sure to charge the battery sufficiently before using.
- Depending on the number of music selections stored on the Memory Stick media, it may take some time to load the music data. All Audio Player for Adapter operations are disabled at this time; this, however, is not a malfunction.

## 3 Tap .

Playback starts from the first music selection.

During playback, the music data that you loaded with RealJukebox for Sony software or your MP3-compatible audio management software is displayed.

(Continued)










Playback automatically stops at the end of the last music selection.

## To stop playback



Tap .

## Other operations

To pause	Tap  .
To go to the beginning of the current track	Tap  .
To go to the beginning of previous tracks	Tap  twice or more.
To go to the beginning of the next track	Tap  .
To go to the beginning of later tracks	Tap  twice or more.
To rewind	Press and hold  .
To fast forward	Press and hold  .

## To adjust the volume

You can adjust the volume by one of the three following ways.

- Tap  or .
- Turn the Jog Dial navigator\*.
- Press the scroll button on your CLIÉ handheld.

\* If it is set to adjust volume in the "Select JOG Func" in the menu of Audio Player for Adapter, see the online manual of Audio Player for Adapter for more information.

## To minimize sound leakage (volume limiter, AVLS\*)

Tap  to change it to .

\* AVLS stands for “Automatic Volume Limiter System.” It limits the volume to minimize sound leakage, damage to your hearing, and potential danger caused by the inability to hear surrounding sounds, all of which are caused by high volume sound.

## Playing audio files with the Audio Adapter

If you turn off your CLIÉ handheld while Audio Player for Adapter is running, you can start playback of songs by just pressing the playback button. Otherwise, turn on your CLIÉ handheld and start Audio Player for Adapter, and then follow this procedure:


- 1 Connect the Audio Adapter to your CLIÉ handheld.**
- 2 Insert the Memory Stick media into the Memory Stick slot.**
- 3 Connect the headphones.**
- 4 Press ► on the Audio Adapter.**  
Playback starts from the first song.  
Playback stops automatically when the song reaches the end.

### To stop playback

Press ■ on the Audio Adapter.

#### Note

If playback does not start even when you press ► on the Audio Adapter, hold ► down again for a few seconds.



(Continued)

## To perform the following operations


Pause	Press ■.
Go to the beginning of the current track	Press ◀◀.
Go to previous tracks	Press ◀◀ repeatedly.
Go to the beginning of the next track	Press ▶▶.
Go to the beginning of succeeding tracks	Press ▶▶ repeatedly.
To rewind	Press ◀◀ and hold.
To fast forward	Press ▶▶ and hold.
Adjust the volume	Press + or -.

## Locking the controls (Hold)

To prevent the controls from being accidentally operated when you carry the player, use the HOLD function.

**Slide the HOLD switch of the Audio Adapter to ON (see the illustration below).**

None of the controls on the Audio Adapter will operate.



Even if you set the HOLD switch on the Audio Adapter to ON, you can control your CLIE handheld with its own buttons.



## Using the online manual for Audio Player for Adapter

Detailed information on Audio Player for Adapter is provided in the online manual provided on the supplied CD-ROM. To view the online manual, Acrobat Reader must be installed on your computer.

**1 Insert the supplied CD-ROM into the CD-ROM drive of your computer.**

The installation screen automatically appears.

**2 Click [Manuals...].**

The [Manuals] folder appears.

**3 Double-click "Audio Player for Adapter Manual.pdf."**

The online manual appears.

### When Acrobat Reader is not installed

**1 Insert the supplied CD-ROM into the CD-ROM drive of your computer.**

**2 Click [Exit].**

**3 Double-click the [My computer] icon on your Windows desktop.**

**4 Right-click the CD-ROM drive icon and select [Open] in the shortcut menu.**

**5 Double-click the "pc" folder.**

**6 Double-click the "Acrobat" folder.**

**7 Double-click "ar500enu.exe."**

# Watching Movies with Audio Sound

## Operation overview

Follow the procedure mentioned below:

- ① Follow the procedure mentioned on page 7 and 8 to install the necessary software onto your computer and CLIÉ handheld.
- ② Transfer movies from your computer to your CLIÉ handheld.
- ③ Connect the Audio Adapter.
- ④ Start up and operate the gMovie application on your CLIÉ handheld.

## Transferring movies to your CLIÉ handheld from your computer

Prepare the movies that you want to watch on your CLIÉ handheld and transfer them to the CLIÉ handheld using the HotSync function.

### **1 Start PictureGear Ver. 4.4 Lite on your computer.**

For more information, refer to the online manual for gMovie.

### **2 Click to select the slides (movie files) that you want to transfer to your CLIÉ handheld.**

You can select multiple the slides by pressing down the Ctrl or Shift key while clicking on each still.

### **3 From the "File" menu, select "Output services," and then "Install the image during the next HotSync."**

The "Install the image during the next HotSync" window appears.

### **4 Click ▼ to display the user's name list and select the one for the CLIÉ handheld to which you wish to transfer movies.**

If necessary, click [Movie settings] and specify the size and the compression rate of the movies in the "Detailed settings for CLIÉ handheld movies" dialogbox.

### **5 Click [OK].**

The selected movies and the transfer destination are registered to PictureGear Ver. 4.4 Lite.

## **6 Attach your CLIÉ handheld to your computer, and then press the HotSync button on the cradle.**

The registered movies are automatically transferred to the CLIÉ handheld of the selected user.

## **Transferring movies to Memory Stick media**

You can also transfer movies in CLIÉ-compatible format to the Memory Stick which is inserted to the Memory Stick drive on your computer. Select “Output CLIE format file to Memory Stick” in step 2 in the above procedure.

Once movies are stored on the Memory Stick media, you can enjoy them on your CLIÉ handheld at any time .

## **Connecting the Audio Adapter**

See page 12 and connect it.

## **Using gMovie application on your CLIÉ handheld**

Follow the steps below to play back movies transferred to your CLIÉ handheld.

### **1 Turn the Jog Dial navigator on the home screen of your CLIÉ handheld to select the “gMovie” icon and press the Jog Dial navigator to start up gMovie.**

You can also tap the “gMovie” icon to start up the software. gMovie starts up and the movie list screen appears.

### **2 Tap the movie in the list that you want to watch.**

Playback of the selected movie starts.




(Continued)


## To pause playback

Tap .


To restart playback, tap .

## To adjust the volume


To lower the volume, tap the left end of .

To raise the volume, tap the right end of .


## To return to the movie list screen

Tap  in the top right corner of the screen.


## To play back the next movie


Tap  in the top right corner of the screen.

## To play back the previous movie

Tap  in the top right corner of the screen.


## To play back movies one after another (continuous playback)

Press  in the top right corner of the screen with the stylus for at least 1 second.

The icon turns into , and movies are played back one after another.

To resume normal playback, press  with the stylus for at least 1 second.

## To delete a movie


**1** Play back the movie that you want to delete and tap .

**2** Tap "Delete".

**3** Tap [OK].

The selected movie is deleted and the movie list screen appears.

### Notes

- When this adapter is connected to your CLIÉ handheld, some movie files with audio sound may not play back smoothly compared with the situation you do not connect it. This is not malfunction.
- When the built-in battery is not charged sufficiently, it may occur the situations as follows. Be sure to charge the battery sufficiently before using.
  - Audio sound cannot play back.
  - The audio sound icon  does not appear in the screen.
  - Busy lamp on the Audio Adapter does not light.
  - The manual operation buttons on the Audio Adapter are deactivated.

## Using the online manual for gMovie

Detailed information on gMovie is provided in the online manual provided on the supplied CD-ROM. To display the online manual, Acrobat Reader must be installed on your computer.

**1 Insert the supplied CD-ROM into the CD-ROM drive of your computer.**

The installation screen automatically appears.

**2 Click [Manuals...].**

The [Manuals...] folder appears.

**3 Double-click "gMovie Manual.pdf."**

The online manual appears.

### If Acrobat Reader is not installed

**1 Insert the supplied CD-ROM into the CD-ROM drive of your computer.**

**2 Click [Exit].**

**3 Double-click the [My computer] icon on your Windows desktop.**

**4 Right-click the CD-ROM drive icon and select [Open] in the shortcut menu.**

**5 Double-click the "pc" folder.**

**6 Double-click the "Acrobat" folder.**

**7 Double-click "ar500enu.exe."**

---

# Others

## Specifications

**CLIÉ handheld models that support the Audio Adapter:**

- PEG-S300
- PEG-S320
- PEG-N610C

**Interface:**

Connector on the bottom of the CLIÉ handheld

**Design:**

Remote control type

**Output:**

Stereo headphones jack

**Power:**

Supplied from the CLIÉ handheld (3.5 to 4.2 V)

**Power consumption:**

Approx. 200 mW maximum

**Continuous audio playback hours:**

Approx 3.5 to 4.0 hours of audio playback\* (when the front or back light function is OFF)

\* The above figures are subject to temperature changes and usage conditions.

**Maximum dimensions (W/H/D):**

Approx. 30 × 74 × 12 mm (1.2 × 2.9 × 0.5 in.)

**Weight:**

Approx. 40 g (1.4 oz.) (excluding headphones)

**Operating temperature:**

5 to 35 °C

**Accessories:**

See page 5.

### Placement limitations

- To prevent malfunction, do not use or store the adapter in locations subject to:

- **Extremely high temperatures**

The temperature rises extremely high within a car that is parked in the sun, or a car with its windows closed during the summer.

Leaving the adapter in a car under these conditions may cause deformation of the adapter case or malfunction of the adapter.

- **Direct sunlight or heat sources**

Use or storage of the adapter in direct sunlight, or near a heat source may cause deformation of the adapter case or malfunction of the adapter.

- **Strong vibrations**

- **Strong magnetic fields**

- **Sand**

Protect the adapter from sand in sandy locations such as the seashore. Sand may cause the adapter to malfunction or damage it irreparably.

### On use

- Do not drop the adapter or subject it to strong physical shocks.
- Keep the adapter away from TV sets, AM radio receivers, radio tuners and other sources of radio interference.
- Prevent the connector of the adapter (or the cord) from coming in contact with any metal objects. Contact with such objects may cause a short circuit.

(Continued)

## On cleaning

- Clean the adapter with a soft dry cloth or tissue paper. If the adapter is badly soiled, moisten a soft cloth with a mild detergent solution, wring it out well, and use it to wipe the adapter. Wipe off any remaining moisture with a soft, dry cloth.
- Do not use any type of solvent, such as alcohol, thinner, or benzene. Use of such solvents may cause deformation of the adapter case or damage to the finish.
- When using a chemical cleaning cloth, follow the instructions included with the cloth.
- Use of volatile sprays, such as insect spray, or leaving the adapter on a rubber or vinyl product may cause deformation of the adapter case, or the coating to peel off.

## On moisture condensation

If the adapter is brought directly from a cold location to a warm one, moisture may condense inside the adapter. Use of the adapter in such a condition may cause a fire or malfunction within the adapter. When moisture has condensed, allow the adapter to sit at least an hour before using it.

# Troubleshooting

## Playback

- Buttons on the Audio Adapter do not work.
  - ➔ Slide the HOLD switch on the Audio Adapter to OFF.
  - ➔ Unless you turn off your CLIÉ handheld while Audio Player for Adapter is running, pressing a button on the Audio Adapter does not start the CLIÉ handheld.
- I hear some skips and noise during playback.
  - ➔ Check the MP3 format. For the MP3 formats available for playback, see “What you can do with the Audio Player” in the online manual of Audio Player for Adapter.
- I cannot start up Audio Player for Adapter or cannot play back audio sound files.
  - ➔ Disconnect and connect the connector several times.
  - ➔ Charge the built-in battery in the CLIÉ handheld sufficiently.



## Connection with your computer

- Connection abruptly drops.
  - ➔ Connect the AC power adapter to the cradle.
  - ➔ Check the cradle or USB cable and your computer for appropriate connection.
  - ➔ Attach the cradle or USB cable firmly to your CLIÉ handheld.
- I cannot transfer as many music pieces as expected. (Available recording time is not long enough.)
  - ➔ The Memory Stick media contains data other than audio files. This decreases the memory capacity that you can use for music transferring. Copy the data in the Memory Stick media to your computer, for example, to increase the capacity.
- I see the drive but not its contents on my computer after I connect my CLIÉ handheld to my computer.
  - ➔ Insert the Memory Stick media into your CLIÉ handheld first, and then connect it to your computer.
- I don't see the removable media on my computer during Transfer mode.
  - ➔ Exit the Transfer mode after making sure that the power of your CLIÉ handheld is ON, and then retry music transferring.
- The operation of my CLIÉ handheld is unstable while it is connected to my computer.
  - ➔ If the cradle or the connection USB cable is connected to your computer via a USB hub or USB extension cable, the operation is not guaranteed. Connect the cradle or the connection USB cable directly to your computer.
- A warning window for device removal appears on the desktop.
  - ➔ Click [OK] and proceed.
  - ➔ Do not tap "Stop" or remove your CLIÉ handheld from the cradle during Transfer mode.

## Others

- I hear no operation sounds from my CLIÉ handheld.
  - ➔ You hear no operation sounds (clicking sounds) from your CLIÉ handheld while Audio Player for Adapter or gMovie is running. However, you do hear warning and error sounds from your CLIÉ handheld.
- I cannot insert the Memory Stick media.
  - ➔ Insert it in an appropriate direction.
- Error display appears while using Audio Player for Adapter or gMovie application software.
  - ➔ When the battery power is low, these software applications may not run in order to protect the contents in the memory. Fully recharge the battery on your CLIÉ handheld and start it up again.
- The remaining power indication in the screen of Audio Player for Adapter is different from the one in the home screen (main menu) on your CLIÉ handheld.
  - ➔ This is not malfunction.
- I cannot use the Memory Stick media that I used with other devices before.
  - ➔ If the Memory Stick media is formatted with your computer, copy necessary data into your computer. Then, follow the instructions in the operation instructions of your CLIÉ handheld to format the media.
- I cannot use the Audio Adapter for a while after I insert the Memory Stick media.
  - ➔ If the Memory Stick with many music pieces recorded is inserted, no operations may be allowed. This is not a malfunction. Wait until the name of the music piece appears on the Audio Player window or the Memory Stick indicator turns off.



For the latest support information,  
check our official Sony CLIÉ Web site

**<http://www.sony.com/clie>**

<http://www.world.sony.com/>

Printed on recycled paper

Printed in Japan