

English

Using the CD power manage function

To improve tuner reception

When tuner reception is poor, set CD player power off by the CD power manage function.

CD power is factory set to on.

1 Press FUNCTION repeatedly to switch the function to CD.

2 Press I/⏻ to turn off the system.

3 Press I/⏻ while holding ■.

“CD POWER OFF” appears.

To set the CD power on

Repeat the procedure above and “CD POWER ON” appears.

Note

When “CD POWER OFF” is selected, CD access time is increased.

Français

Emploi de la fonction de gestion de l'alimentation du lecteur CD

Pour améliorer la réception du tuner

Si la réception du tuner est mauvaise, désactivez l'alimentation du lecteur CD à l'aide de la fonction de gestion de l'alimentation du lecteur CD.

L'alimentation du lecteur CD a été activée en usine.

1 Appuyez plusieurs fois sur FUNCTION pour passer à la fonction CD.

2 Appuyez sur I/⏻ pour éteindre la chaîne.

3 Appuyez sur I/⏻ tout en maintenant la touche ■ enfoncée.

« CD POWER OFF » s'affiche.

Pour activer l'alimentation du lecteur CD

Répétez les opérations ci-dessus et « CD POWER ON » s'affiche.

Remarque

Lorsque « CD POWER OFF » est sélectionné, le temps d'accès au CD augmente.