

**日本語****使用上のご注意****曲転送について**

本機をパソコンに接続して、SonicStageから曲を転送するときには、本機上の表示で「USB Connect」の上のアイコンが左右にアニメーション表示されている間、もしくは、SonicStage上で[転送状態]が「転送済み」から「-」になるまで、USB接続ケーブルを抜かないでください。

**フォーマット(初期化)について**

フォーマット(初期化)は、必ず本機上でおこなってください(フォーマットすると記録されたデータはすべて消却されますので、フォーマットする前に内容を確認してください)。

Windows のエクスプローラを使ってフォーマットすると、SonicStageで曲を転送しても“NO DATA”や“FORMAT ERROR”というメッセージが本機上に表示され再生できないことがあります。そのような場合は、必ず本機上でフォーマット(初期化)をおこなってください。

**English****Note on using****On the transfer**

When you transfer audio files from your computer to the Network Walkman using SonicStage, do not disconnect the USB cable while the icon above “USB Connect” on the Network Walkman display is animating, or until “Transferred” changes to “-” in [Status] of the SonicStage screen.

**On the format**

Be sure to format the built-in flash memory using the Menu mode on this unit. (Check all contents before formatting as all data stored will be erased.)

If you format the built-in flash memory using Windows Explorer, “NO DATA” or “FORMAT ERROR” may appear on this unit and any track may not play back, even if it is transferred by SonicStage. In this case, format the built-in memory on this unit.