

November 28, 1996

---

## **Modem - Changing to IRQ 10 for PCV70/90**

---

The following information details the basic steps to change the modem to IRQ 10:

1. Click on Start.
2. Click on Settings.
3. Double Click on System.
4. Select the Device Manager tab on top of the window.
5. Select 28.8 DSVD Modem.

**Note:** Be sure that you have selected this properly by verifying that you see two 28.8 DSVD modems.

6. If you have two 28.8 Modems, select the lower one and click on Remove.
7. Select Start.
8. Select Shutdown.
9. Select Shutdown the Computer.
10. Allow enough time for the computer to power off.
11. Wait 5 seconds, then power the computer back on.
12. Press F3 when prompted by the screen.
13. Press F1 when prompted by the screen.
14. Select Advanced from the top menu.
15. Select Plug and Play configuration from the menu.
16. Press Enter.
17. Select Configuration Mode (press the Arrow Keys up or down).
18. Press Enter.
19. Select Use BIOS Setup.
20. Press Enter.
21. Arrow down to IRQ 9.
22. Press Enter.
23. Select Used By ISA Card.
24. Press Enter.
25. Press the ESC key twice.
26. Select Exit Saving Changes.
27. Press Enter.
28. Select Yes.
29. Press Enter.
30. The computer will reboot and windows should autodetect the modem and reinstall it on IRQ 10.