

## **How to Set Up a Pre-Existing Compuserve Account**

---

The following details the steps necessary to set up a pre-existing Compuserve account on your Sony PC:

1. Click on WINDOWS 95 Start button.
2. Select the PROGRAMS folder of the Start menu list.
3. Select the COMPUSERVE folder.
4. Select the program "Compuserve Information Manager".
5. Close the window titled "Connect to Compuserve"
6. Select the menu item SPECIAL.
7. Select "Session Settings..." of the menu list for SPECIAL .
8. Fill in your Name, User ID, Password & Access Phone #.
9. Set Connector to COM3.
10. Set Baud Rate to 28800.
11. Click on "Modem..." button.
12. From Modem list select "Intel SatisFAXtion Modem/400".
13. Select the OK button.
14. Select the OK button.
15. Select File
16. From the menu, select File->Connect
17. Click the Connect button