

2001 Accessory Compatability Chart

		DSC-P30	DSC-P50	DSC-F505V	DSC-P1	DSC-S75/DSC-S85	MVC-FD75	MVC-FD87	MVC-FD92	MVC-FD97	MCV-CD200	MCV-CD300	MVC-CD1000	CCD-TR818	CCD-TRV58	CCD-TRV68	CCD-TRV88	CCD-TRV98	DCR-TRV130	DCR-TRV230	DCR-TRV330	DCR-TRV530	DCR-TRV730	DCR-TRV830	DCR-PCS Discon	DCR-PC9	DCR-TRV17	DCR-TRV30	DCR-PC110	DCR-TRV900	DCR-WX2000	
Starter Kit	ACC-KITF330													X	X	X	X	X	X		X	X	X	X	X		X	X	X	X	X	
	ACC-KITFM50										X	X									X	X	X	X	X		X	X	X	X		
	ACC-MVCD							X	X	X		X	X																			
	ACC-MVC2						X	X	X																							
	ACC-CSS					X																										
Carrying Case	ACC-CSPW	X	X																													
	LCS-VA1													X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	
	LCS-VA2													X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	
Just Fit	LCS-MVC3						X	X	X		X	X																				
	LCS-CD1000												X																			
Just Fit	LCS-FD95									X																						
	LCM-F505			X																												
	LCS-CSC					X																										
	LCM-TRVX																											X	X			
Hard Case	LCH-VX2000																															X
Hard Case	LCH-TRV900																															X
Just Fit	LCM-PCA																														X	
Just Fit	LCM-PCY2																										X					
Just Fit	LCM-SX					X																										
Charger	LCSCP1	X	X		X																											
	AC-VQ11	X	X	X	X																					X						
	DC-VQ11	X	X	X	X																					X						
	ACLS1	X	X	X	X																											
	AC-VQ850D					X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		X	X	X	X	X	X
	BC-V615					X	X	X	X				X	X	X	X	X	X	X							X	X	X	X	X	X	X
	BC-VM50					X					X	X								X	X	X	X	X			X	X	X	X	X	X
DC power supply Battery	BC-V500					X	X	X	X				X	X	X	X	X	X	X								X	X	X	X	X	X
	DCC-L50					X					X	X		X	X	X	X	X	X	X	X	X	X	X		X	X	X	X	X	X	
	NP-F960													X	X	X	X	X	X												X	X
	NP-F750													X	X	X	X	X	X												X	X
	NP-F550						X	X	X	X			X	X	X	X	X	X	X												X	X
	NP-FM50					X					X	X								X	X	X	X	X		X	X	X	X			
	NP-FM70																			X	X	X	X	X		X	X	X	X			
	NP-FM90																			X	X	X	X	X		X	X	X	X			
	NP-FM91																			X	X	X	X	X		X	X	X	X			
	NP-FS11	X	X	X																						X						
Lenses&Filter	NP-FS21																								X							
	NP-FS31																								X							
	VCL-0637H	X	X				X	X	X		X			X	X	X	X	X	X	X	X	X	X	X					X	X		
	VCL-R2037	X	X				X	X	X		X			X	X	X	X	X	X	X	X	X	X	X					X	X		
	VCL-HG0737X	X	X				X	X	X		X			X	X	X	X	X	X	X	X	X	X	X					X	X		
	VCL-HG2037X	X	X				X	X	X		X			X	X	X	X	X	X	X	X	X	X	X					X	X		
	VCL-MHG07	X	X	X		X**	X	X	X	X	X	X**	X	X	X	X	X	X	X	X	X	X	X	X					X			
	VCL-ES06A	X	X	X		X**	X	X	X	X	X	X**	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	
VCL-ES20A						X	X	X	X			X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		

2001 Accessory Compatability Chart

		DSC-P30	DSC-P50	DSC-F505V	DSC-P1	DSC-S75/DSC-S85	MVC-FD75	MVC-FD87	MVC-FD92	MVC-FD97	MVC-CD200	MVC-CD300	MVC-CD1000	CCD-TR818	CCD-TRV58	CCD-TRV68	CCD-TRV88	CCD-TRV98	DCR-TRV130	DCR-TRV230	DCR-TRV330	DCR-TRV530	DCR-TRV730	DCR-TRV830	DCR-PC5 Discon	DCR-PC9	DCR-TRV17	DCR-TRV30	DCR-PC110	DCR-TRV900	DCR-VX2000	
	VF-R37K	X	X				X	X	X		X			X	X	X	X	X	X	X	X	X	X									
	VF-37PKS	X	X				X	X	X		X			X	X	X	X	X	X	X	X	X	X									
	VF-30PKS																								X	X	X					
	VADS70					X**						X**																				
	VF-R52K			X		X**				X		X**	X																		X	
	VCL-0630S																								X	X	X					
	VCL-R2030S																								X	X	X					
	VCL-0752H																															X
	VCL-1452H			X																												X
	VCL-HG0758																															X
	VCL-HG1758																															X
Lights	VCL-58PK																															X
	HVL-IRC													X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
	HVL-IRH2																				X	X	X	X				X	X	X	X	X
	HVL-S3D																				X	X	X	X				X	X	X	X	X
	HVL-20DW2													X	X	X	X	X	X													X
	HVL-20DM																			X	X	X	X	X		X	X	X	X			X
Video Flash	HVL-FDH3																			X	X	X	X	X			X	X	X	X	X	X
Video Flash	HVL-FH1100																			X	X	X	X	X					X	X	X	X
Mic	ECM-HS1																			X	X	X	X	X			X	X	X	X	X	X
Accy Arm	VCT-S30L													X	X	X	X	X	X	X	X	X	X		X	X	X	X	X	X	X	X
Flash DSC																																
	HVL-F1000			X		X			X	X	X	X	X																			
Tripods	VCT-870RM																			X	X	X	X	X		X	X	X	X	X	X	X
	VCT-R610	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		X	X	X	X	X	X	X	X
	VCT-480RM					X			X	X	X	X	X							X	X	X	X	X		X	X	X	X	X	X	X
Playback Options	VCT-D580RM					X			X	X	X	X	X							X	X	X	X	X		X	X	X	X	X	X	X
	VCT-D680RM					X			X	X	X	X	X							X	X	X	X	X		X	X	X	X	X	X	X
	VCT-TK1	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		X	X	X	X	X	X	X	X
	IFT-R20																		X	X	X	X	X	X		X	X	X	X	X	X	X
	GV-D800																		X	X	X	X	X	X								
	GV-D200																		X	X	X	X	X	X								
	GV-D900																			X	X	X	X									
	GV-D300																															
	DSR-ME1 Editor																															
	RFU-95UCX														X	X	X	X	X	X	X	X	X		X	X	X	X	X	X	X	X
	REW-88													X	X	X	X	X	X	X	X	X										
I.Link Connectivity	VMC-IL4435																			X	X	X	X	X		X	X	X	X	X	X	X
	VMC-IL4415																			X	X	X	X	X		X	X	X	X	X	X	X
	VMC-IL4615																			X	X	X	X	X		X	X	X	X	X	X	X
Digital Media	DVMC-DA2													X	X	X	X	X														
	5-MCR-156A											X	X	X																		
	MCR-156A											X	X	X																		
	3MCRW-156A											X	X	X																		
	MCRW-156A											X	X	X																		
MS Digital Media	MSA-128A	X	X	X	X	X		X	X	X											X	X	X	X	X	X	X	X	X	X	X***	X

2001 Accessory Compatability Chart

		DSC-P30	DSC-P50	DSC-F505V	DSC-P1	DSC-S75/DSC-S85	MVC-FD75	MVC-FD87	MVC-FD92	MVC-FD97	MCV-CD200	MCV-CD300	MVC-CD1000	CCD-TR818	CCD-TRV58	CCD-TRV68	CCD-TRV88	CCD-TRV98	DCR-TRV130	DCR-TRV230	DCR-TRV330	DCR-TRV530	DCR-TRV730	DCR-TRV830	DCR-PC5 Discon	DCR-PC9	DCR-TRV17	DCR-TRV30	DCR-PC110	DCR-TRV900	DCR-VX2000
	MSA-64A	X	X	X	X	X		X	X	X											X	X	X	X	X	X	X	X	X	X	X
	MSA-32A	X	X	X	X	X		X	X	X											X	X	X	X	X	X	X	X	X	X	X
	MSA-16A	X	X	X	X	X		X	X	X											X	X	X	X	X	X	X	X	X	X	X
	MSA-8A	X	X	X	X	X		X	X	X											X	X	X	X	X	X	X	X	X	X	X
	MSAC-FD2MA	X	X	X	X	X		X	X	X											X	X	X	X	X	X	X	X	X	X	X
	MSAC-PC2	X	X	X	X	X		X	X	X											X	X	X	X	X	X	X	X	X	X	X
	MSAC-US1A	X	X	X	X	X		X	X	X											X	X	X	X	X	X	X	X	X	X	X
	MSAC-US5	X	X	X	X	X		X	X	X											X	X	X	X	X	X	X	X	X	X	X
Digital Photo Printer	DPP-SV55	X	X	X	X	X	X*	X	X	X	X*	X*	X*								X	X	X	X	X	X	X	X	X	X	X
	SVM-25LS	X	X	X	X	X	X	X	X	X	X	X	X								X	X	X	X	X	X	X	X	X	X	X
	SVM-25LW	X	X	X	X	X	X	X	X	X	X	X	X								X	X	X	X	X	X	X	X	X	X	X
	SVM-30SS	X	X	X	X	X	X	X	X	X	X	X	X								X	X	X	X	X	X	X	X	X	X	X
	SVM-30SW	X	X	X	X	X	X	X	X	X	X	X	X								X	X	X	X	X	X	X	X	X	X	X
	SVM-30SW09	X	X	X	X	X	X	X	X	X	X	X	X								X	X	X	X	X	X	X	X	X	X	X
Cam Printer	PVP-MSH																				X	X	X	X			X	X			
	CPPM-NR40																				X	X	X	X			X	X			
	CPPM-SC40																				X	X	X	X			X	X			
* With PC Connection																															

** Requires VADS70

*** Requires MSAC-PC2