




### BP-T16

**Replacement For**  
Panasonic, Sony,  
Southwestern Bell,  
Toshiba, Uniden




### BP-T18

**Replacement For**  
Panasonic, Sharp,  
Sony, Toshiba,  
Uniden




### BP-T21

**Replacement For**  
Sony



### BP-T23

**Replacement For**  
AT&T/Lucent,  
Sony, Vtech




### BP-T24

**Replacement For**  
Sony



### BP-T25

**Replacement For**  
Bell South



### BP-T26

**Replacement For**  
Cobra, Conair,  
Northwestern Bell  
Sanyo, Southwestern Bell




### BP-T27

**Replacement For**  
AT&T/Lucent,  
General Electric, Magnavox,  
Phone Mate, Sharp



### BP-T28

**Replacement For**  
General Electric




### BP-T30

**Replacement For**  
AT&T/Lucent



### BP-T31

**Replacement For**  
Sony




### BP-T33

**Replacement For**  
General Electric,  
Northwestern Bell,  
Southwestern Bell




### BP-T35

**Replacement For**  
Panasonic



### BP-T37

**Replacement For**  
Southwestern Bell



### BP-T40

**Replacement For**  
Sony



### BP-T50

**Replacement For**  
Sony

**AT&T/LUCENT**

If you have Phone Model # ...buy Sony Battery #

3400	BP-T27
3410	BP-T27
4000X	BP-T27
4051	BP-T27
4110	BP-T27
4200	BP-T27
4300	BP-T27
4310	BP-T27
4315	BP-T27
4320	BP-T27
4325	BP-T27
4330	BP-T27
4331	BP-T27
4335	BP-T27
4336	BP-T27
4337	BP-T27
4340	BP-T27
4345	BP-T27
4410	BP-T27
4600	BP-T27
4605	BP-T27
4610	BP-T27
4615	BP-T27
4690	BP-T27
4695	BP-T27
4725	BP-T27
4800	BP-T27
4805	BP-T27
4810	BP-T27
4815	BP-T27
4905	BP-T16
4935	BP-T16
5200	BP-T27
5210	BP-T27

**AT&T/LUCENT**

If you have Phone Model # ...buy Sony Battery #

5250	BP-T27
5300	BP-T27
5310	BP-T27
5320	BP-T27
5352	BP-T27
5400	BP-T27
5405	BP-T27
5450	BP-T27
5455	BP-T27
5460	BP-T27
5470	BP-T27
5471	BP-T27
5475	BP-T27
5480	BP-T27
5481	BP-T27
5483	BP-T27
5484	BP-T27
5489	BP-T27
5490	BP-T27
5491	BP-T27
5495	BP-T27
5500	BP-T27
5510	BP-T27
5515	BP-T27
5520	BP-T27
5552	BP-T27
5600	BP-T27
5630	BP-T27
5631	BP-T27
5635	BP-T27
5650	BP-T27
5655	BP-T27
5700	BP-T27
5710	BP-T27

**AT&T/LUCENT**

If you have Phone Model # ...buy Sony Battery #

5715	BP-T27
5830	BP-T27
5860	BP-T27
7210	BP-T27
7215	BP-T27
7220	BP-T27
7225	BP-T27
7235	BP-T27
7310	BP-T27
7330	BP-T27
7332	BP-T27
7340	BP-T27
7345	BP-T27
7415	BP-T27
7420	BP-T27
7510	BP-T27
7512	BP-T27
7610	BP-T27
7620	BP-T27
7625	BP-T27
7630	BP-T27
7640	BP-T27
7650	BP-T27
7700	BP-T27
7710	BP-T27
7715	BP-T27
7720	BP-T27
9100	BP-T30
9105	BP-T23
9110	BP-T23
9120	BP-T30
9200	BP-T23

**BELL SOUTH**

If you have Phone Model # ...buy Sony Battery #

673	BP-T25
798	BP-T25
799	BP-T25
810	BP-T25
820	BP-T25
822	BP-T25
3533	BP-T25
3887	BP-T25
MH9020	BP-T33

**COBRA**

If you have Phone Model # ...buy Sony Battery #

AN8630	BP-T26
--------	--------

**CONAIR**

If you have Phone Model # ...buy Sony Battery #

XS2510	BP-T26
--------	--------

**GENERAL ELECTRIC**

If you have Phone Model # ...buy Sony Battery #

29500	BP-T28
29505	BP-T28
29530	BP-T27
29535	BP-T27
29615	BP-T27
29616	BP-T27
29635	BP-T27
29640	BP-T27
29645	BP-T27
29680	BP-T27
29685	BP-T27
29730	BP-T27
29735	BP-T27
29740	BP-T27

**GENERAL ELECTRIC**

If you have Phone Model # ...buy Sony Battery #

29745	BP-T27
29750	BP-T27
29751	BP-T27
29752	BP-T27
29768	BP-T27
29769	BP-T27
29770	BP-T27
29774	BP-T27
29775	BP-T27
29782	BP-T27
29785	BP-T27
29790	BP-T27
29921	BP-T33

**MAGNAVOX**

If you have Phone Model # ...buy Sony Battery #

CLT254	BP-T27
--------	--------

**NORTHWESTERN BELL**

If you have Phone Model # ...buy Sony Battery #

32508	BP-T26
32509	BP-T28
32528	BP-T26
32701	BP-T26
33600	BP-T26
33601	BP-T26
33700	BP-T26
38200	BP-T26
38500	BP-T26
39202	BP-T33

**PANASONIC**

If you have Phone Model # ...buy Sony Battery #

KXT3610	BP-T16
---------	--------

**PANASONIC**

If you have Phone Model # ...buy Sony Battery #

KXT3620	BP-T16
KXT3640	BP-T16
KXT3702	BP-T16
KXT3705	BP-T16
KXT3710	BP-T16
KXT3712	BP-T16
KXT3720	BP-T16
KXT3725	BP-T16
KXT3730	BP-T16
KXT3732	BP-T16
KXT3848	BP-T16
KXT3850	BP-T16
KXT3855	BP-T16
KXT3860	BP-T16
KXT3870	BP-T16
KXT3875	BP-T16
KXT3880	BP-T18
KXT3908	BP-T16
KXT3910	BP-T16
KXT3912	BP-T16
KXT3920	BP-T16
KXT3925	BP-T16
KXT3930	BP-T16
KXT3932	BP-T16
KXT3935	BP-T16
KXT3940	BP-T16
KXT3945	BP-T16
KXT3950	BP-T16
KXT3960	BP-T16
KXT3962	BP-T16
KXT3965	BP-T16
KXT3967	BP-T16
KXT3968	BP-T16
KXT3980	BP-T16

**PANASONIC**

If you have Phone Model # ...buy Sony Battery #

KXT4108	BP-T16
KXT4109	BP-T16
KXT4168	BP-T16
KXT4169	BP-T16
KXT4200	BP-T16
KXT4300	BP-T16
KXT4310	BP-T16
KXT4330	BP-T16
KXT4340	BP-T16
KXT4342	BP-T16
KXT4350	BP-T16
KXT4360	BP-T16
KXT4365	BP-T16
KXT4370	BP-T16
KXT4400	BP-T16
KXT4410	BP-T16
KXT4500	BP-T16
KXT4550	BP-T16
KXT4600	BP-T16
KXTC100	BP-T16
KXTC109	BP-T16
KXTC150	BP-T16
KXTC155	BP-T16
KXTC157	BP-T16
KXTC160	BP-T16
KXTC165	BP-T16
KXTC170	BP-T16
KXTC180	BP-T16
KXTC185	BP-T16
KXTC187	BP-T16
KXTC190	BP-T16
KXTC197	BP-T16
KXTC280	BP-T16
KXTC289	BP-T16
KXTC412	BP-T16

**PANASONIC**

If you have Phone Model # ...buy Sony Battery #

KXTC424	BP-T16
KXTC900	BP-T35
KXTC901	BP-T18
KXTC904	BP-T18
KXTC909	BP-T35
KXTC910	BP-T35
KXTC911	BP-T18
KXTC919	BP-T35
KXTC935	BP-T18
KXTC938	BP-T35
KXTC940	BP-T35
KXTC1400	BP-T18
KXTC1430	BP-T18
KXTC1450	BP-T18
KXTC1700	BP-T18
KXTCC106	BP-T16
KXTCC116	BP-T16
KXTCC425	BP-T16
KXTCC902	BP-T35
KXTCC912	BP-T35
KXTCC942	BP-T35
KXTCM410	BP-T16
KXTCM415	BP-T16
KXTCM417	BP-T16
KXTCM418	BP-T16
KXTCM420	BP-T16
KXTCM422	BP-T16
KXTCM440	BP-T16
KXTCM938	BP-T35
KXTCM939	BP-T18
KXTCM940	BP-T35
KXTCM943	BP-T18
KXTC970	BP-T35
KXTC971	BP-T35

## PHONE MATE

If you have Phone Model # ...buy Sony Battery #

2150	BP-T27
2350	BP-T27
2870	BP-T27
2970	BP-T27
CP725	BP-T27
TC508	BP-T27
TC520	BP-T27
TC530	BP-T27
TC540	BP-T27

## SANYO

If you have Phone Model # ...buy Sony Battery #

CAS100	BP-T26
CAS1200	BP-T26
CAS130	BP-T26
CAS160	BP-T26
CAS170	BP-T26
CAS837	BP-T26
CLT937	BP-T33
CLT957	BP-T33

## SHARP

If you have Phone Model # ...buy Sony Battery #

CL400	BP-T18
CL410	BP-T18
CL505	BP-T27
CL510	BP-T27
FT5400	BP-T18
FT5410	BP-T18
FT5505	BP-T27

## SONY

If you have Phone Model # ...buy Sony Battery #

SPP-1000	BP-T40
SPP-1010	BP-T40
SPP-111	BP-T16
SPP-115	BP-T40
SPP-120	BP-T40
SPP-160	BP-T40
SPP-170	BP-T40
SPP-180	BP-T40
SPP-190	BP-T40
SPP-2000	BP-T40
SPP-2010	BP-T40
SPP-205	BP-T16
SPP-2100	BP-T40
SPP-320	BP-T40
SPP-55	BP-T16
SPP-57	BP-T16
SPP-58	BP-T16
SPP-62	BP-T21
SPP-65	BP-T16
SPP-70	BP-T40
SPP-71	BP-T16
SPP-72	BP-T16
SPP-73	BP-T16
SPP-75	BP-T40
SPP-77	BP-T40
SPP-85	BP-T40
SPP-900	BP-T23
SPP-930	BP-T23
SPP-933	BP-T18
SPP-935	BP-T23
SPP-95	BP-T40
SPP-97	BP-T40
SPP-A1050	BP-T18
SPP-A1070	BP-T18

## SONY

If you have Phone Model # ...buy Sony Battery #

SPP-A20	BP-T16
SPP-A2470	BP-T31
SPP-A2480	BP-T24
SPP-A250	BP-T16
SPP-A2770	BP-T38
SPP-A2780	BP-T38
SPP-A40	BP-T16
SPP-A400	BP-T16
SPP-A450	BP-T16
SPP-A5000	BP-T40
SPP-A60	BP-T16
SPP-A700	BP-T16
SPP-A900	BP-T18
SPP-A9171	BP-T31
SPP-A9276	BP-T24
SPP-A940	BP-T23
SPP-A941	BP-T23
SPP-A945	BP-T23
SPP-A946	BP-T18
SPP-A957	BP-T24
SPP-A967	BP-T24
SPP-A968	BP-T24
SPP-A972	BP-T23
SPP-A973	BP-T23
SPP-A985	BP-T23
SPP-AQ25	BP-T16
SPP-AQ500	BP-T16
SPP-AQ600	BP-T16
SPP-D900	BP-T18
SPP-ER1	BP-T18
SPP-ER101	BP-T18
SPP-H273	BP-T38
SPP-ID200	BP-T40
SPP-ID300	BP-T16

## SONY

If you have Phone Model # ...buy Sony Battery #

SPP-ID400	BP-T16
SPP-ID910	BP-T23
SPP-ID970	BP-T23
SPP-ID975	BP-T23
SPP-IM977	BP-T23
SPP-IM982	BP-T23
SPP-M100	BP-T40
SPP-M502	BP-T16
SPP-M920	BP-T23
SPP-M932	BP-T23
SPP-M937	BP-T23
SPP-N1000	BP-T50
SPP-N1003	BP-T50
SPP-N1004	BP-T50
SPP-N1020	BP-T18
SPP-N1025	BP-T18
SPP-Q100	BP-T40
SPP-Q105	BP-T40
SPP-Q110	BP-T16
SPP-Q120	BP-T16
SPP-Q150	BP-T16
SPP-Q200	BP-T40
SPP-Q210	BP-T40
SPP-Q300	BP-T40
SPP-Q400	BP-T40
SPP-Q405	BP-T40
SPP-S20	BP-T40
SPP-S2430	BP-T24
SPP-S2720	BP-T38
SPP-S2730	BP-T38
SPP-S9000	BP-T31
SPP-S9001	BP-T31
SPP-S9101	BP-T31
SPP-S9104	BPT-31

## SONY

If you have Phone Model # ...buy Sony Battery #

SPP-S9226	BP-T24
SPP-SS950	BP-T18
SPP-SS951	BP-T24
SPP-SS955	BP-T24
SPP-SS960	BP-T18
SPP-SS961	BP-T24
SPP-SS965	BP-T24
SPP-SS966	BP-T24
SPP-X30	BP-T40
SPP-X50	BP-T40
SPP-X90	BP-T40

## SOUTHWESTERN BELL

If you have Phone Model # ...buy Sony Battery #

FF1722	BP-T37
FF642	BP-T37
FF643	BP-T37
FF674	BP-T37
FF692	BP-T37
FF693	BP-T37
FF694	BP-T37
FF701	BP-T37

## TOSHIBA

If you have Phone Model # ...buy Sony Battery #

FT-6004	BP-T16
FT-6503	BP-T16
FT-8006	BP-T18
FT-9003	BP-T16
FT-9005	BP-T16
FT-9006	BP-T16
FT-9305	BP-T16
FT-9506	BP-T16

## VTech

If you have Phone Model # ...buy Sony Battery #

9001	BP-T23
910ADL	BP-T23
912ADL	BP-T23
914ADL	BP-T23
917ADX	BP-T23
920ADL	BP-T23
VT1920	BP-T23
VT1920C	BP-T23
VT1930	BP-T23
VT1930C	BP-T23
VT1970	BP-T23
VT1970CI	BP-T23

## UNIDEN

If you have Phone Model # ...buy Sony Battery #

CT301	BP-T16
DX3565	BP-T16
DX1860	BP-T16
EX945	BP-T18
EXA915	BP-T18
EXA950	BP-T18
EXAI918	BP-T18
EXI916	BP-T18
EXI917	BP-T18
EXP7900	BP-T18
EXP91	BP-T18
EXP92	BP-T18
EXP920	BP-T18
EXP95	BP-T40
XC302	BP-T16
XC305	BP-T16
XC310	BP-T16
XC314	BP-T16
XC320	BP-T16

## UNIDEN

If you have Phone Model # ...buy Sony Battery #

XC330	BP-T16
XC3510	BP-T16
XC3515	BP-T16
XC3545	BP-T16
XC610	BP-T16
XC611	BP-T16
XC645	BP-T16
XC714	BP-T16
XCA4500	BP-T16
XCA4510	BP-T16
XCA4515	BP-T16
XCA650	BP-T16
XCA1680	BP-T16
XCI660	BP-T16
XCI665	BP-T16