

CD BOOMBOX - 3 CD CHANGER	CFD-C1000
CD Changer	3 Disc
CD RMS	20 Track
CD Repeat Modes:	4 Mode
1/All/RMS/Shuffle	Yes
CD Loading	Front Carousel
8x Oversampling	Yes
D/A Converter	1Bit
Double Cassette	Yes
Auto Shut-Off	Yes
Easy Preset Tuner	Yes
Presets	10 AM/10 FM
AM/FM Tuning	Digital
Detachable Speaker System	Yes
Electronic Sound Modes	4 Pattern
Mega Bass®	Yes
Multi-Function LCD	Back-Lit
Remote Commander® Remote Control	Yes
Clock/Timer	Yes
Automatic Music Sensor (AMS)	Yes
Synchronized CD/Cassette Dubbing	Yes
Power Source	AC Only