

# DAV-FR1/FR8/FR9

## SERVICE MANUAL

Ver 1.0 2004.06

*US Model*

DAV-FR1/FR8/FR9

*Canadian Model*

DAV-FR1

- DAV-FR1/FR8/FR9 are composed of following models.  
As service manuals are issued for each component model, please refer to them.

### COMPONENT MODEL NAME

	DAV-FR1	DAV-FR8	DAV-FR9
SACD/DVD RECEIVER	HCD-FR1	HCD-FR8	HCD-FR9
FRONT SPEAKER	SS-TS20	SS-TS21	SS-TS21
CENTER SPEAKER	SS-CT44	SS-CT33	SS-CT33
SURROUND SPEAKER	SS-TS20	SS-TS20	SS-TS21
SUB WOOFER	SS-WS12		

### PARTS LIST

Part No.      Description

#### ACCESSORIES

\*\*\*\*\*

1-478-698-11 COMMANDER, STANDARD (RM-SP350)  
1-754-059-12 ANTENNA, LOOP (AM)  
1-754-147-41 ANTENNA (FM)  
1-769-108-11 CORD, CONNECTION (VIDEO CORD)  
1-827-244-11 CORD (WITH CONNECTOR)

4-255-434-13 MANUAL, INSTRUCTION (ENGLISH)  
4-255-434-23 MANUAL, INSTRUCTION (FRENCH)(CND)

- Abbreviation  
CND : Canadian model.

## DVD HOME THEATRE SYSTEM

9-879-007-01

2004F16-1

© 2004.06

**Sony Corporation**

Home Audio Company

Published by Sony Engineering Corporation

# SONY®

## REVISION HISTORY

Clicking the version allows you to jump to the revised page.

Also, clicking the version at the upper right on the revised page allows you to jump to the next revised page.

[illegible]