

DIGITAL8® ACCESSORIES (Jan. 02)		DCR-TRV130	DCR-TRV230	DCR-TRV330	DCR-TRV530	DCR-TRV730	DCR-TRV830
Starter Kit	ACC-KITF330	X					
	ACC-KITFM50		X	X	X	X	X
Carrying Case	LCS-VA1	X	X	X	X	X	X
	LCS-VA3	X	X	X	X	X	X
	LCS-VA2	X	X	X	X	X	X
	LCS-VA2	X	X	X	X	X	X
Charger	AC-VQ850D	X	X	X	X	X	X
	BC-V615	X					
	BC-VM50		X	X	X	X	X
	BC-V500	X					
DC power supply	DCC-L50	X	X	X	X	X	X
Battery	NP-F960	X					
	NP-F750	X					
	NP-F550	X					
	NP-FM50		X	X	X	X	X
	NP-FM70		X	X	X	X	X
	NP-FM90		X	X	X	X	X
	NP-FM91		X	X	X	X	X
	NP-FM91		X	X	X	X	X
Lenses & Filter	VCL-0637H	X	X	X	X	X	X
	VCL-R2037	X	X	X	X	X	X
	VCL-HG0737X	X	X	X	X	X	X
	VCL-HG2037X	X	X	X	X	X	X
	VCL-MHG07A	X	X	X	X	X	X
	VF-R37K	X	X	X	X	X	X
	VF-37PKS	X	X	X	X	X	X
	VF-37PKS	X	X	X	X	X	X
Lights	HVL-IRC	X	X	X	X	X	X
	HVL-IRH2		X	X	X	X	X
	HVL-S3D		X	X	X	X	X
	HVL-20DW2	X					
	HVL-20DM		X	X	X	X	X
Video Flash	HVL-FDH3		X	X	X	X	X
Video Flash	HVL-FH1100		X	X	X	X	X
Mic	ECM-HS1		X	X	X	X	X
Accy Arm	VCT-S30L	X	X	X	X	X	X

		DCR-TRV130	DCR-TRV230	DCR-TRV330	DCR-TRV530	DCR-TRV730	DCR-TRV830
Tripods	VCT-870RM		X	X	X	X	X
	VCT-R610	X	X	X	X	X	X
	VCT-D480RM		X	X	X	X	X
	VCT-D580RM		X	X	X	X	X
	VCT-D680RM		X	X	X	X	X
	VCT-TK1	X	X	X	X	X	X
Playback Options	IFT-R20	X	X	X	X	X	X
	GV-D800	X	X	X	X	X	X
	GV-D200	X	X	X	X	X	X
	RFU-95UCX	X	X	X	X	X	X
	REW-88	X	X	X	X	X	X
i.LINK® Connectivity	VMC-IL4435	X	X	X	X	X	X
	VMC-IL4415	X	X	X	X	X	X
	VMC-IL4615	X	X	X	X	X	X
Memory Stick® Digital Media	MSA-128A			X	X	X	X
	MSA-64A			X	X	X	X
	MSA-32A			X	X	X	X
	MSA-16A			X	X	X	X
	MSA-8A			X	X	X	X
	MSAC-FD2MA			X	X	X	X
	MSAC-PC2			X	X	X	X
	MSAC-US1A			X	X	X	X
	MSAC-US5			X	X	X	X
Digital Photo Printer	DPP-SV55			X	X	X	X
	DPP-SV77			X	X	X	X
	SVM-25LS			X	X	X	X
	SVM-25LW			X	X	X	X
	SVM-30SS			X	X	X	X
	SVM-30SW			X	X	X	X
	SVM-30SW09			X	X	X	X
Cam Printer	PVP-MSH			X	X	X	X
	CPPM-NR40			X	X	X	X
	CPPM-SC40			X	X	X	X