

MacView (gray, with rotary dial and 9 DIP switches)		Apple Computer	Mac IIci, IIsi	Macintosh LC, LC II - or - Performa 400, 405, 410, 430	Macintosh LC III, LC 475 - or - Performa 450, 460, 466, 467, 475, 476	Macintosh IIfx, IIfx - or - Performa 600, 600 CD	Macintosh LC 630, Performa 630 Series, Performa 640 - or - Quadra 630	Macintosh Quadra 700, 900	Macintosh Quadra 605, 610, 650, 800, 950 - or - Centris 610, 650	Macintosh Quadra 840AV, 660AV - or - Centris 660AV
SONY Computer Monitor										
CPD-1320	640 x 480 @ 60 Hz	-	G (7,8,9)	G (7,8,9)	-	G (7,8,9)	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	G (7,8,9)
CPD-1304, or CPD-1425	640 x 480 @ 60 Hz	-	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)
	640 x 480 @ 67 Hz	J	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)
	800 x 600 @ 56 Hz	-	-	-	-	-	G (7,8,9) *	-	-	-
	800 x 600 @ 60 Hz	-	-	-	-	-	G (7,8,9) *	-	-	-
	832 x 624 @ 75 Hz	-	-	F (7,8,9)	-	-	F (7,8,9)	F (7,8,9)	F (7,8,9)	F (7,8,9)
	1024 x 768 @ 60 Hz	-	-	-	-	-	-	-	-	G (7,8,9) *
CPD-1304S, or CPD-1430, or CPD-1604S, or CPD-1730	640 x 400 @ 67 Hz	-	-	J (7,8,9) *	J (7,8,9) *	J (7,8,9) *	-	-	-	J (7,8,9) *
	640 x 480 @ 60 Hz	-	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)
	640 x 480 @ 67 Hz	J	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)
	800 x 600 @ 56 Hz	-	-	-	-	-	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *
	800 x 600 @ 60 Hz	-	-	-	-	-	G (7,8,9) *	-	-	-
	800 x 600 @ 72 Hz	-	-	-	-	-	G (7,8,9) *	-	-	G (7,8,9) *
	832 x 624 @ 75 Hz	-	-	F (7,8,9)	-	F (7,8,9)	F (7,8,9)	F (7,8,9)	F (7,8,9)	F (7,8,9)
	1024 x 768 @ 60 Hz	-	-	-	-	-	-	-	-	G (7,8,9) *
	1024 x 768 @ 70 Hz	-	-	-	-	-	-	-	-	G (7,8,9) *
CPD-100SX, or CPD-100VS, or CPD-15SF1, or CPD-15SF2, or CPD-15SX1, or CPD-17SF1, or CPD-17SF2	640 x 480 @ 60 Hz	-	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)
	640 x 480 @ 67 Hz	J	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)
	800 x 600 @ 56 Hz	-	-	-	-	-	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *
	800 x 600 @ 60 Hz	-	-	-	-	-	G (7,8,9) *	-	-	-
	800 x 600 @ 72 Hz	-	-	-	-	-	G (7,8,9) *	-	-	G (7,8,9) *
	832 x 624 @ 75 Hz	-	-	F (7,8,9)	-	F (7,8,9)	F (7,8,9)	F (7,8,9)	F (7,8,9)	F (7,8,9)
	1024 x 768 @ 60 Hz	-	-	-	-	-	-	-	-	G (7,8,9) *
	1024 x 768 @ 70 Hz	-	-	-	-	-	-	-	-	G (7,8,9) *
	1024 x 768 @ 75 Hz	-	-	-	-	-	-	D (7,8,9)	D (7,8,9)	D (7,8,9)
CPD-100SF, or CPD-200SX, or CPD-220VS, or GDM-1936, or GDM-2036S	640 x 400 @ 67 Hz	-	-	J (7,8,9) *	J (7,8,9) *	J (7,8,9) *	-	-	-	J (7,8,9) *
	640 x 480 @ 60 Hz	-	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)
	640 x 480 @ 67 Hz	J	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)
	800 x 600 @ 56 Hz	-	-	-	-	-	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *
	800 x 600 @ 60 Hz	-	-	-	-	-	G (7,8,9) *	-	-	-
	800 x 600 @ 72 Hz	-	-	-	-	-	G (7,8,9) *	-	-	G (7,8,9) *
	832 x 624 @ 75 Hz	-	-	F (7,8,9)	-	F (7,8,9)	F (7,8,9)	F (7,8,9)	F (7,8,9)	F (7,8,9)
	1024 x 768 @ 60 Hz	-	-	-	-	-	-	-	-	G (7,8,9) *
	1024 x 768 @ 70 Hz	-	-	-	-	-	-	-	-	G (7,8,9) *
	1024 x 768 @ 75 Hz	-	-	-	-	-	-	-	D (7,8,9)	D (7,8,9)
	1152 x 870 @ 75 Hz	-	-	-	-	-	P (7,8,9)	P (7,8,9)	P (7,8,9)	P (7,8,9)
CPD-200SF, or CPD-20SF2, or CPD-300SFT, or GDM-17SE1, or GDM-17SE2T, or GDM-2000TC, or GDM-2038, or GDM-20SE1, or GDM-20SE2T, or GDM-W900	640 x 400 @ 67 Hz	-	-	J (7,8,9) *	J (7,8,9) *	J (7,8,9) *	-	-	-	J (7,8,9) *
	640 x 480 @ 60 Hz	-	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)
	640 x 480 @ 67 Hz	J	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)
	800 x 600 @ 56 Hz	-	-	-	-	-	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *
	800 x 600 @ 60 Hz	-	-	-	-	-	G (7,8,9) *	-	-	-
	800 x 600 @ 72 Hz	-	-	-	-	-	G (7,8,9) *	-	-	G (7,8,9) *
	832 x 624 @ 75 Hz	-	-	F (7,8,9)	-	F (7,8,9)	F (7,8,9)	F (7,8,9)	F (7,8,9)	F (7,8,9)
	1024 x 768 @ 60 Hz	-	-	-	-	-	-	-	-	G (7,8,9) *
	1024 x 768 @ 70 Hz	-	-	-	-	-	-	-	-	G (7,8,9) *
	1024 x 768 @ 75 Hz	-	-	-	-	-	-	-	D (7,8,9)	D (7,8,9)
	1152 x 870 @ 75 Hz	-	-	-	-	-	P (7,8,9)	P (7,8,9)	P (7,8,9)	P (7,8,9)
	1280 x 1024 @ 75 Hz	-	-	-	-	-	-	-	-	-
On-the-fly Resolution Switching (under System 7.5/7.6)							●	●	●	●

MacView (gray, with rotary dial and 9 DIP switches)		Apple Computer	Power Macintosh 6100, 6100AV, 7100, 7100AV, 8100, 8100AV - with - DRAM Video Port (HDI-45) ***	Workgroup Server 6150, 8150, 9150 - with - DRAM Video Port (HDI-45) ***	Performa 6100 Series, 6200 Series, 6300 Series - with - DRAM Video Port (HDI-45) ***	Power Macintosh 7100, 8100 - with - VRAM Video Card (DB-15)	Power Macintosh 7200, 7500, 8500, 9500 Video Card (DB-15)	Power Macintosh 6100AV, 7100AV, 8100AV - with - AV Video Card (DB-15)
SONY Computer Monitor								
CPD-1320	640 x 480 @ 60 Hz		G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)
CPD-1304, or CPD-1425	640 x 480 @ 60 Hz		G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)
	640 x 480 @ 67 Hz		J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *
	800 x 600 @ 56 Hz		-	-	-	-	-	-
	800 x 600 @ 60 Hz		-	-	-	-	-	-
	832 x 624 @ 75 Hz		J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *
	1024 x 768 @ 60 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
CPD-1304S, or CPD-1604S, or CPD-1730	640 x 400 @ 67 Hz		-	-	-	J (7,8,9) *	J (7,8,9) *	J (7,8,9) *
	640 x 480 @ 60 Hz		G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)
	640 x 480 @ 67 Hz		J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *
	800 x 600 @ 56 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	800 x 600 @ 60 Hz		-	-	-	-	-	-
	800 x 600 @ 72 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	832 x 624 @ 75 Hz		J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *
	1024 x 768 @ 60 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	1024 x 768 @ 70 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
CPD-100SX, or CPD-100VS, or CPD-15SF1, or CPD-15SF2, or CPD-15SX1, or CPD-17SF1, or CPD-17SF2	640 x 400 @ 60 Hz		G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)
	640 x 480 @ 67 Hz		J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (4,7,8,9) *	J (4,7,8,9) *	J (4,7,8,9) *
	800 x 600 @ 56 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	800 x 600 @ 60 Hz		-	-	-	-	-	-
	800 x 600 @ 72 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	832 x 624 @ 75 Hz		J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (4,7,8,9) *	J (4,7,8,9) *	J (4,7,8,9) *
	1024 x 768 @ 60 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	1024 x 768 @ 70 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	1024 x 768 @ 75 Hz		-	-	-	J (4,7,8,9) *	J (4,7,8,9) *	J (4,7,8,9) *
CPD-100SF, or CPD-200SX, or CPD-220VS, or GDM-1936, or GDM-2036S	640 x 400 @ 67 Hz		-	-	-	J (7,8,9) *	J (7,8,9) *	J (7,8,9) *
	640 x 480 @ 60 Hz		G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)
	640 x 480 @ 67 Hz		J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,7,8,9) *	J (3,7,8,9) *	J (3,7,8,9) *
	800 x 600 @ 56 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	800 x 600 @ 60 Hz		-	-	-	-	-	-
	800 x 600 @ 72 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	832 x 624 @ 75 Hz		J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,7,8,9) *	J (3,7,8,9) *	J (3,7,8,9) *
	1024 x 768 @ 60 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	1024 x 768 @ 70 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	1024 x 768 @ 75 Hz		-	-	-	J (3,7,8,9) *	J (3,7,8,9) *	J (3,7,8,9) *
	1152 x 870 @ 75 Hz		-	-	-	J (3,7,8,9) *	J (3,7,8,9) *	J (3,7,8,9) *
CPD-200SF, or CPD-20SF2, or CPD-300SFT, or GDM-17SE1, or GDM-17SE2T, or GDM-2000TC, or GDM-2038, or GDM-20SE1, or GDM-20SE2T, or GDM-W900	640 x 400 @ 67 Hz		-	-	-	J (7,8,9) *	J (7,8,9) *	J (7,8,9) *
	640 x 480 @ 60 Hz		G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)
	640 x 480 @ 67 Hz		J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,7,8,9) *	J (3,7,8,9) *	J (3,7,8,9) *
	800 x 600 @ 56 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	800 x 600 @ 60 Hz		-	-	-	-	-	-
	800 x 600 @ 72 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	832 x 624 @ 75 Hz		J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,4,7,8,9) *	J (3,7,8,9) *	J (3,7,8,9) *	J (3,7,8,9) *
	1024 x 768 @ 60 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	1024 x 768 @ 70 Hz		-	-	-	G (7,8,9) **	G (7,8,9) **	G (7,8,9) *
	1024 x 768 @ 75 Hz		-	-	-	J (3,7,8,9) *	J (3,7,8,9) *	J (3,7,8,9) *
	1152 x 870 @ 75 Hz		-	-	-	J (3,7,8,9) *	J (3,7,8,9) *	J (3,7,8,9) *
	1280 x 1024 @ 75 Hz		-	-	-	-	J (3,7,8,9) *	-
On-the-fly Resolution Switching (under System 7.5/7.6)			●	●	●	●	●	●

MacView (gray, with rotary dial and 9 DIP switches)		Apple Computer	Macintosh PowerBook 160, 165, 165C, 180, 180C	Macintosh PowerBook 190, 520, 520c, 540, 540c, 5300 Series	Macintosh PowerBook Duo 210, 230, 250, 270c, 280, 280c - with - Duo Dock - or - Duo MiniDock	Macintosh PowerBook Duo 210, 230, 250, 270c, 280, 280c - with - Duo Dock II - or - Duo Dock Plus	Apple Display Card 4.8, 8.24, 8.24GC	Apple Display Card 24AC
SONY Computer Monitor								
CPD-1320	640 x 480 @ 60 Hz	-	-	-	-	-	-	G (7,8,9)
CPD-1304, or CPD-1425	640 x 480 @ 60 Hz	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	-	J (3,4,7,8,9) **
	640 x 480 @ 67 Hz	<u>J (7,8,9)</u>	<u>J (3,4,7,8,9) *</u>	<u>J (7,8,9)</u>	<u>J (7,8,9)</u>	<u>J (7,8,9)</u>	<u>J (7,8,9)</u>	<u>J (3,4,7,8,9) *</u>
	800 x 600 @ 56 Hz	-	-	-	-	-	-	J (3,4,7,8,9) **
	800 x 600 @ 60 Hz	-	-	-	-	-	-	J (3,4,7,8,9) **
	832 x 624 @ 75 Hz	<u>F (7,8,9)</u>	<u>J (3,4,7,8,9) *</u>	<u>F (7,8,9)</u>	<u>F (7,8,9)</u>	<u>F (7,8,9)</u>	<u>F (7,8,9) (B)</u>	<u>J (3,4,7,8,9) *</u>
	1024 x 768 @ 60 Hz	-	-	-	-	-	-	J (3,4,7,8,9) **
CPD-1304S, or CPD-1430, or CPD-1604S, or CPD-1730	640 x 400 @ 67 Hz	J (7,8,9) *	J (7,8,9) *	-	-	-	-	J (7,8,9) *
	640 x 480 @ 60 Hz	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	-	J (3,4,7,8,9) **
	640 x 480 @ 67 Hz	<u>J (7,8,9)</u>	<u>J (3,4,7,8,9) *</u>	<u>J (7,8,9)</u>	<u>J (7,8,9)</u>	<u>J (7,8,9)</u>	<u>J (7,8,9)</u>	<u>J (3,4,7,8,9) *</u>
	800 x 600 @ 56 Hz	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	-	-
	800 x 600 @ 60 Hz	-	-	-	-	-	-	J (3,4,7,8,9) **
	800 x 600 @ 72 Hz	-	-	-	-	-	-	-
	832 x 624 @ 75 Hz	<u>F (7,8,9)</u>	<u>J (3,4,7,8,9) *</u>	<u>F (7,8,9)</u>	<u>F (7,8,9)</u>	<u>F (7,8,9)</u>	<u>F (7,8,9) (B)</u>	<u>J (3,4,7,8,9) *</u>
	1024 x 768 @ 60 Hz	-	-	-	-	-	-	J (3,4,7,8,9) **
	1024 x 768 @ 70 Hz	-	-	-	-	-	-	-
CPD-100SX, or CPD-100VS, or CPD-15SF1, or CPD-15SF2, or CPD-15SX1, or CPD-17SF1, or CPD-17SF2	640 x 480 @ 60 Hz	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	-	J (4,7,8,9) **
	640 x 480 @ 67 Hz	<u>J (7,8,9)</u>	<u>J (3,4,7,8,9) *</u>	<u>J (7,8,9)</u>	<u>J (7,8,9)</u>	<u>J (7,8,9)</u>	<u>J (7,8,9)</u>	<u>J (4,7,8,9) *</u>
	800 x 600 @ 56 Hz	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	-	-
	800 x 600 @ 60 Hz	-	-	-	-	-	-	J (4,7,8,9) **
	800 x 600 @ 72 Hz	-	-	-	-	-	-	-
	832 x 624 @ 75 Hz	<u>F (7,8,9)</u>	<u>J (3,4,7,8,9) *</u>	<u>F (7,8,9)</u>	<u>F (7,8,9)</u>	<u>F (7,8,9)</u>	<u>F (7,8,9) (B)</u>	<u>J (4,7,8,9) *</u>
	1024 x 768 @ 60 Hz	-	-	-	-	-	-	J (4,7,8,9) **
	1024 x 768 @ 70 Hz	-	-	-	-	-	-	-
	1024 x 768 @ 75 Hz	-	-	-	-	<u>D (7,8,9)</u>	-	<u>J (4,7,8,9) *</u>
CPD-100SF, or CPD-200SX, or CPD-220VS, or GDM-1936, or GDM-2036S	640 x 400 @ 67 Hz	J (7,8,9) *	J (7,8,9) *	-	-	-	-	J (7,8,9) *
	640 x 480 @ 60 Hz	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	-	J (3,7,8,9) **
	640 x 480 @ 67 Hz	J (7,8,9)	<u>J (3,4,7,8,9) *</u>	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (7,8,9)	J (3,7,8,9) *
	800 x 600 @ 56 Hz	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	-	-
	800 x 600 @ 60 Hz	-	-	-	-	-	-	J (3,7,8,9) **
	800 x 600 @ 72 Hz	-	-	-	-	-	-	-
	832 x 624 @ 75 Hz	<u>F (7,8,9)</u>	<u>J (3,4,7,8,9) *</u>	<u>F (7,8,9)</u>	<u>F (7,8,9)</u>	<u>F (7,8,9)</u>	<u>F (7,8,9) (B)</u>	J (3,7,8,9) *
	1024 x 768 @ 60 Hz	-	-	-	-	-	-	J (3,7,8,9) **
	1024 x 768 @ 70 Hz	-	-	-	-	-	-	-
	1024 x 768 @ 75 Hz	-	-	-	-	<u>D (7,8,9)</u>	-	<u>J (3,7,8,9) *</u>
	1152 x 870 @ 75 Hz	-	-	-	-	<u>P (7,8,9)</u>	<u>P (7,8,9)</u>	<u>J (3,7,8,9) *</u>
CPD-200SF, or CPD-20SF2, or CPD-300SFT, or GDM-17SE1, or GDM-17SE2T, or GDM-2000TC, or GDM-2038, or GDM-20SE1, or GDM-20SE2T, or GDM-W900	640 x 400 @ 67 Hz	J (7,8,9) *	J (7,8,9) *	-	-	-	-	J (7,8,9) *
	640 x 480 @ 60 Hz	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	G (7,8,9)	-	J (3,7,8,9) **
	640 x 480 @ 67 Hz	<u>J (7,8,9)</u>	<u>J (3,4,7,8,9) *</u>	<u>J (7,8,9)</u>	<u>J (7,8,9)</u>	<u>J (7,8,9)</u>	J (7,8,9)	J (3,7,8,9) *
	800 x 600 @ 56 Hz	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	G (7,8,9) *	-	-
	800 x 600 @ 60 Hz	-	-	-	-	-	-	J (3,7,8,9) **
	800 x 600 @ 72 Hz	-	-	-	-	-	-	-
	832 x 624 @ 75 Hz	<u>F (7,8,9)</u>	<u>J (3,4,7,8,9) *</u>	<u>F (7,8,9)</u>	<u>F (7,8,9)</u>	<u>F (7,8,9)</u>	<u>F (7,8,9) (B)</u>	J (3,7,8,9) *
	1024 x 768 @ 60 Hz	-	-	-	-	-	-	J (3,7,8,9) **
	1024 x 768 @ 70 Hz	-	-	-	-	-	-	-
	1024 x 768 @ 75 Hz	-	-	-	-	<u>D (7,8,9)</u>	-	<u>J (3,7,8,9) *</u>
	1152 x 870 @ 75 Hz	-	-	-	-	<u>P (7,8,9)</u>	<u>P (7,8,9)</u>	<u>J (3,7,8,9) *</u>
On-the-fly Resolution Switching (under System 7.5/7.6)			●		●			●

Important Notes

Resolution	Video Mode
640 x 480 67 Hz	= Macintosh Hi-Res Display
832 x 624 75 Hz	= Macintosh 16" Color Display
1024 x 768 75 Hz	= 19" RGB Display
1152 x 870 75 Hz	= Mac 21" Color

<u>Underline</u>	= Recommended setting.	Bold	= Macintosh resolution.	Normal	= VGA Resolution.
●	= Computer supports Apple resolution switching software included with System 7.5.				
*	= Use one of the following control panels to select the resolution listed: 1) Monitors control panel (must click on the Options button). 2) Sound & Displays control panel. 3) Monitors & Sound control panel.				
**	= The Option key on the keyboard must be held down while clicking the Options button in the Monitors Control Panel.				
***	= DHAM Video Port requires Apple HDI-45 to DB-15 video cable (M2681LL/A). (Macintosh 6100/60 includes Apple HDI-45 to DB-15 cable.)				
****	= Requires Apple's Basic Color Monitor system extension.				
(B)	= Must have revision B of ROM on video board.				
-	= Not a working combination.				

If System 7.5 software is installed and a spot appears in the same column as your computer,

you may replace the listed dial and DIP switch settings with the following settings:

F (7,8,9)	Change to	J (3,4,7,8,9) *	= Set dial to J and DIP switches 3, 4, 7, 8 and 9 to ON (Supports 640 x 480 @ 67 Hz & 832 x 624 @ 75 Hz)
D (7,8,9)	Change to	J (4,7,8,9) *	= Set dial to J and DIP switches 4, 7, 8 and 9 to ON (Supports 640 x 480 @ 67 Hz ; 832 x 624 @ 75 Hz ; 1024 x 768 @ 75 Hz)
P (7,8,9)	Change to	J (3,7,8,9) *	= Set dial to J and DIP switches 3, 7, 8 and 9 to ON (Supports 640 x 480 @ 67Hz & 832 x 624 @ 75 Hz & 1024 x 768 @ 75 Hz & 1152 x 870 @ 75 Hz)

* Once you have the correct adapter settings, you can switch on-the-fly between available resolutions by going into the control panel folder, choosing Monitors and clicking options. You must click on the "Rearrange on Close" box before you can use the resolution switching software.

If your Macintosh computer or Sony computer monitor are not listed on this chart, please call (800) 883-7669 and request document number 2851 in order to receive an updated chart via FAX.