

How to Reinstall the Sound Drivers? PCV 70 90

Follow these steps to reinstall the sound drivers on a PCV 70 90.

1. Click Start, point to Settings, and click Control Panel.
2. Double-click the System icon.
3. Click the Device Manager tab.
4. Double-click the entry for Sound, Video, and Game Controllers.
5. Click to highlight Yamaha OPL3-SA sound system and click Remove.
6. Click OK to confirm removal.
7. Click Close.
8. Click Start and click Shutdown.
9. Select Restart the Computer and click Yes.
10. The drivers will be reinstalled when the system reboots.

DRIVER NOTE: If prompted for a driver directory path, insert the Recovery CD in the CDROM drive and type G:\Drivers\Opl3sa.