

May 20, 1997

---

## **How To Setup a Joystick in Windows 95**

---

**Follow the joystick installation instructions provided by the manufacturer to load the joystick software, if necessary. Make certain your joystick is plugged into the game port at the back of the computer. Next, follow the instructions below to configure the joystick in Windows 95:**

1. Go to the Start menu and choose Settings / Control Panel.
2. Double-click on the Joystick icon.
3. Find the option for your joystick from Joystick configuration. Refer to the joystick manufacturer's documentation for the correct option selection.
4. Click on the <Calibrate> button to begin the calibration procedure. Follow the prompts to complete the procedure.
5. Click on the <Test> button to test the joystick. If you have any problems while calibrating or testing the joystick, the joystick may not work.
6. Click on the <Apply> button.

NOTE: If you have problems when calibrating or testing the joystick, the joystick might not be working properly, the game port may have a problem, or it may be a problem with Windows 95. Contact the manufacturer of the joystick for troubleshooting tips.

NOTE: For illustrations of game port hook ups, refer to the on-line Sony PC System Manual. From the desktop, select Sony folder/Sony PC Help Library/Sony PC System Manual/Index tab/enter "joystick"/click <Display>.

For additional information on configuring a joystick in Windows 95, from the desktop go to the Start button/Help/Index tab/enter "joystick,"/click <Display>.