

Tech Fax # 10620

March 4, 1999

How to Reinstall the Sound Drivers on a Sony Notebook System? PCG 705 707 717 719 729

Follow the steps below to reinstall the ESS Sound Drivers on a PCG 705 707 717 719 729.

1. Insert Application Recovery CD into the CDROM drive.

NOTE: Use Application Recovery CD # 1 for the PCG 729

2. At the Welcome screen, click OK.
3. Double-click the Drivers folder.
4. Double-click the Sound Driver icon to begin the installation.
5. When the setup is finished, click OK.
6. At the Application Recovery CD - Drivers window, click Quit.
7. Click OK to exit the Sony Application Recovery CD.