


1 Unpacking Your VAIO Notebook


The DVD ROM drive is located in the multipurpose drive bay. To check the complete contents of the box, see the VAIO® Notebook User Guide.



2 Inserting the Battery Pack


Insert the battery pack in the left battery bay on the computer.

When your computer is plugged in, battery indicator 1 on the LED panel on the computer lights when the battery is installed. See the User Guide for general battery information.



3 Opening the Notebook


Slide the LCD lock lever in the direction of the arrow and lift the cover.



4 Attaching the Power Cord

- You may use either AC power or a battery pack as a power source.*
- Plug the AC adapter cable into the DC IN connector on the computer.
- Plug the power cord into the AC power adapter and a grounded AC outlet or power strip.

* The AC outlet is the power source when the AC power adapter is connected. The battery pack continues to charge if kept in the computer when AC power is used.



5 Connecting the Phone Line

- Plug one end of the phone cable into the line jack on the front of the computer.
- Plug the other end of the phone cable into the wall jack.

Register your computer to extend your hardware limited warranty from 90 days to a full year from the original date of purchase.



6 Starting the Notebook

- Press the power switch on the computer to turn on the power. The power indicator turns on.
- You may sign up for Internet access with a Sony preferred Internet Service Provider.

Setting up your VAIO® Notebook

For more information, see your VAIO Notebook User Guide.