

Draft

Graffiti® 2 powered by Jot®

Operating Instructions

Graffiti® 2 powered by Jot® is a handwriting input system which is pre-installed on your CLIE handheld. **Graffiti® writing mentioned in the supplied manuals is not installed on your CLIE™ handheld.** To use Graffiti® 2 powered by Jot® with your CLIE handheld, please read this manual. (Graffiti® 2 powered by Jot® is referred to as Graffiti® 2 in this manual.)

*Jot is a registered trademark of Communication Intelligence Corporation.

Using Graffiti® 2 to enter text	2
What is Graffiti® 2?	2
Referencing “Graffiti 2 Demo” and “Graffiti 2 Help”	2
Writing a stroke on your CLIE™ handheld	4
Using the Graffiti® 2 writing area	4
Using navigation strokes and shortcuts	8

CLIE

Using Graffiti® 2 to enter text

What is Graffiti® 2?

Graffiti® 2 is a unique writing method for quickly and easily entering text into CLIÉ applications. Text is entered in the Graffiti® 2 writing area using the stylus. Graffiti® 2 recognizes your handwriting and immediately converts it to typed text.





Example Graffiti® 2 shapes of A, B, C, K, and T

Referencing “Graffiti 2 Demo” and “Graffiti 2 Help”

Starting “Graffiti 2 Demo” on your CLIÉ handheld

Graffiti 2 Demo on your CLIÉ handheld is a tutorial application from which you can learn and practice Graffiti® 2 writing method. **Graffiti 2 Demo** has writing tips and a demonstration showing how to write the stroke(s). Follow the steps below to start the application.

- 1 Rotate the Jog Dial™ navigator to select the Graffiti 2  icon on the Application Launcher screen and press the Jog Dial™ navigator.
The Graffiti 2 screen is displayed.




- 2 Tap **Try It!**.

The Writing Tip screen is displayed. Follow the on-screen explanations and tap **Previous**, **Next**, or **Tips** for useful information of Graffiti® 2 writer, as required.

Note


The next time you start **Graffiti 2 Demo**, the last screen you previously viewed is displayed.

The final screen of **Graffiti 2 Demo** is the **Stroke Lookup** screen. In this screen, you can learn how to write any character. Tap the arrow ▼ at the top right of the screen and select the character category. When you tap the character you want to learn how to write, its stroke(s) are demonstrated.



Displaying the on-screen Graffiti 2 Help

Drag the stylus from the Graffiti® 2 writing area in the lower part of the screen, to the top of the screen. **Graffiti 2 Help** opens a series of screens that show the character set of Graffiti® 2 writing.




Tip

You can customize the way you write the characters t, p, y, and s. For details, refer to **Tips of Graffiti 2 Demo** on your CLIE handheld.

Writing a stroke on your CLIÉ™ handheld

The dot on each stroke shows where to begin the stroke

Certain characters have similar stroke shapes, but different beginning and end points. Always begin each stroke from the dot and lift the stylus at the end.




Note

You do not need to create the dot when you actually write a stroke. It is only shown in this manual to illustrate where to begin the stroke.

Using the Graffiti® 2 writing area


The Graffiti® 2 writing area is divided into two halves: one for writing the lower case letters of the alphabet and one for writing numbers. The area around the division line is used for writing upper case letters of the alphabet.




Writing upper case letters

To enter an upper case letter, write the stroke(s) across the division line of the Graffiti® 2 writing area*.

* Memo Pad is used as an example application in this manual.



Write the stroke(s) across the division line




Writing lower case letters

To enter a lower case letter, write the stroke(s) on the left-hand side of the Graffiti® 2 writing area.




Write the stroke(s) within this area




Writing numbers

To enter a number, write the stroke(s) on the right-hand side of the Graffiti® 2 writing area.



Write the stroke(s) within this area




(Continued on next page)

Writing symbols


To enter a symbol, activate Symbol mode. In Symbol mode, you can write on the left-hand or right-hand side of the Graffiti® 2 writing area. Follow the steps below to enter a symbol.

- 1 Write the stroke | anywhere within the Graffiti® 2 writing area.

The Punctuation Shift indicator is displayed on the screen to show that you are in Symbol mode.



- 2 Write the symbol stroke(s).



Tip

Write the stroke(s) as soon as you enter Symbol mode before Symbol mode automatically exits.


- 3 Write the stroke | again.

This will enter the symbol, and exit Symbol mode.




Tips

- Some symbols can be entered without activating Symbol mode. You need to write the stroke(s) on the **left-hand** or **right-hand** side of the Graffiti® 2 writing area, depending on the symbol. For details, refer to **Graffiti 2 Help** on your CLIE handheld. This shows which symbols need to be written on the left-hand side of the Graffiti® 2 writing area, and which need to be written on the right-hand side.




- For details on how to write symbol stroke(s), refer to the Stroke Lookup screen of Graffiti 2 Demo on your CLIE handheld.




Writing accented letters

To enter an accented letter, first write the lower case letter or upper case letter, and then write the accent stroke on the right-hand side of the Graffiti® 2 writing area. For details , refer to Graffiti 2 Demo and Graffiti 2 Help on your CLIE handheld.

Graffiti 2 Demo screen



Graffiti 2 Help screen




Using navigation strokes and shortcuts


Using navigation strokes

When you are entering text or operating an application, you can use navigation strokes within the field of the application. For details, refer to **Graffiti 2 Demo** and **Graffiti 2 Help** on your CLIE handheld.

Graffiti 2 Demo screen







Graffiti 2 Help screen




Using shortcuts

Default shortcuts are registered on your CLIE handheld.

To use a shortcut, write the shortcut stroke  followed by the shortcut characters. When you write the shortcut stroke, the Short Cut Shift indicator is displayed at the insertion point to show that you are in Shortcut mode.

For example, if you write the Graffiti® 2 writer shortcut “ds” (, , and ) in the Graffiti® 2 writing area, this enters the current date and time. For details, refer to **Graffiti 2 Demo** on your CLIE handheld.



Tips

- You can also enter shortcuts by using Symbol mode.
- You can also create your own shortcuts. For details, refer to “Customizing your CLIE™ handheld (Preferences): Creating Graffiti® ShortCuts” in the supplied “Handbook.”

Note

If the letter “L” is registered as a menu shortcut for an application, the letters “K,” “T,” “I,” and “X” will not work as menu shortcuts. This is because the first stroke of these two-stroke letters will be mistakenly recognized as the shortcut “L.” If there is no shortcut “L,” any or all of the four letters can be registered as menu shortcuts.

For the latest support information on support
and accessories,
check our official Sony CLIE website

For customers in the U.S.A. and Canada
<http://www.sony.com/clie/>

For customers in Australia, Hong Kong, Malaysia,
Mexico, New Zealand, Singapore, Taiwan and Thailand
<http://vaio-online.sony.com/clie/>

<http://www.sony.net/>



Printed on 100% recycled paper using VOC (Volatile
Organic Compound)-free vegetable oil based ink.

Printed in Japan