


PCGA-CD51/A

SERVICE MANUAL

US Model
Canadian Model



Illust : PCGA-CD51/A



The basic performance of the PCGA-CD51/A is the same as that of the PCGA-CD51. Therefore, this manual describes the points of difference from the PCGA-CD51. Upon repairing or checking the unit, refer to the service manual (9-928-323-11) for the PCGA-CD51 issued previously, as well as this manual.

• Points of difference

| Difference item | PCGA-CD51 | | | PCGA-CD51/A | | |
|-----------------|-----------|--------------|--------------|-------------|--------------|---------------------------------------|
| MAIN UNIT | Ref.No. | Part No. | Description | Ref.No. | Part No. | Description |
| | 6 | 1-772-184-11 | CD-ROM DRIVE | 6 | 1-772-733-11 | DRIVE, CD-ROM |
| ACCESSORIES | Ref.No. | Part No. | Description | Ref.No. | Part No. | Description |
| | — | 4-643-161-01 | INSTALL DISK | — | 1-772-728-21 | DISK, INSTALL (UE) (for Windows 2000) |
| | — | — | — | — | 4-647-656-11 | MANUAL (BEGINNING), INSTRUCTION |
| | — | — | — | — | 4-647-764-11 | MANUAL INSTRUCTION |

This manual and the constituent data may not be replicated, copied nor reprinted in whole or in part without prior written authorization of Sony Corporation.

CD-ROM DRIVE
SONY®