

SONY

FEATURES AND
SPECIFICATIONS
SUBJECT TO CHANGE
WITHOUT NOTICE

TCM-465V

PRESSMAN® PORTABLE CASSETTE RECORDER

- POP-UP MICROPHONE FOR LECTURE RECORDING
- AUTOMATIC MIC SENSITIVITY SETTING
- CUE MARKER INDEXING
- 3 DIGIT TAPE COUNTER
- VOICE OPERATED RECORDING (VOR)
- PLAYBACK SPEED CONTROL (-20% TO +30%)
- CLEAR VOICE™ SOUND SYSTEM
- MIC JACK
- ONE-TOUCH RECORDING
- 3 LED BATTERY LEVEL INDICATOR
- FRONT SPEAKER
- AUTOMATIC SHUT-OFF
- CUE/REVIEW FUNCTION
- PAUSE SWITCH
- STOP PAUSE RELEASE FUNCTION
- EARPHONE JACK
- HINGED BATTERY LID
- DC-IN JACK
- HAND STRAP ATTACHED

PRESSMAN



TCM-465V

FEATURES

- **POP-UP MICROPHONE** is built-in for convenience and provides for distinct recording of lectures and other situations
- **AUTOMATIC MIC SENSITIVITY SETTING** automatically adjusts the built-in microphone to record appropriately in different situations such as meetings, conferences, dictation or one-on-one recordings
- **CUE MARKER INDEXING SYSTEM** lets you place an electronic "mark" at specific tape segments, and provides rapid access during Cue and Review
- **3 DIGIT TAPE COUNTER** makes it easy to find a specific location on the tape for rapid access and editing
- **VOICE OPERATED RECORDING (VOR)** activates the recorder only when audible sound is present, conserving tape and eliminating soundless passages
- **PLAYBACK SPEED CONTROL** (-20% to +30%) lets you adjust playback speed slower or faster than normal, for easy review and editing of recorded information during playback
- **CLEAR VOICE™ SOUND SYSTEM** enhances voice quality during recording and playback for greater clarity
- **MIC JACK (MONAURAL)** lets you connect an external microphone if desired
- **ONE TOUCH RECORDING** for simplified, quick play/record operation
- **3 LED BATTERY LEVEL INDICATOR** provides visible indication of battery power remaining
- **FRONT SPEAKER** has excellent sound quality to monitor tape playback
- **AUTOMATIC SHUT-OFF** at end of tape reduces mechanical wear and conserves battery power
- **CUE/REVIEW FUNCTION** provides sound during fast Forward and Rewind modes to help find specific passages
- **PAUSE SWITCH** allows for instant on-the-spot editing
- **STOP PAUSE RELEASE FUNCTION** automatically turns off the Pause switch whenever the Stop button is pressed, to prevent loss of recording
- **EARPHONE JACK** for private listening with optional earphone
- **HINGED BATTERY LID** helps prevent accidental loss
- **DC-IN JACK** for two-way power operation, using replaceable batteries or optional AC power adaptor
- **HAND STRAP ATTACHED** affords very convenient one-hand use

SPECIFICATIONS

RECORDING SYSTEM: 2 track, 1 channel (standard cassette)
FREQUENCY RESPONSE: 250 - 6300Hz
SPEAKER: 1 7/8" (36mm) dia.
POWER REQUIREMENTS: DC 3V with "AA" x 2 batteries
BATTERY LIFE: Rec/Play: Approx. 11 hours with Sony alkaline batteries
COLOR: Black
DIMENSIONS (WHD): 3 5/8" x 4 5/8" x 1 3/4"
(91 x 115.8 x 42.8mm)
WEIGHT: 6 3/4 oz (195g)
SUPPLIED ACCESSORIES: Hand Strap
OPTIONAL ACCESSORIES: AC-E30HG AC Adaptor

©1998 Sony Electronics Inc.
Reproduction in whole or in part without written permission is prohibited. All rights reserved.
Sony, Clear Voice and Pressman are trademarks of Sony.
Features and specifications are subject to change without notice. Non-metric weights and measures are approximate.

SONY®

Sony Electronics Inc.
1 Sony Drive
Park Ridge, New Jersey 07656
<http://www.sony.com>

FEATURES AND
SPECIFICATIONS
SUBJECT TO CHANGE
WITHOUT NOTICE

Printed in USA 1/98