


**SONY**

FEATURES AND  
SPECIFICATIONS  
SUBJECT TO CHANGE  
WITHOUT NOTICE

# **BM-840T**

## **MICROCASSETTE DESKTOP TRANSCRIBER**

- MICROCASSETTE SYSTEM
- 3-FUNCTION FOOT CONTROL/LISTENING DEVICE SUPPLIED
- 2-SPEED OPERATION
- LCD TAPE COUNTER
- FULLY ADJUSTABLE AUTOMATIC SECRETARIAL REVERSE
- SPEED/TONE/VOLUME CONTROLS
- END-OF-TAPE ALARM
- BUILT-IN PLAYBACK SPEAKER
- BUILT-IN ERASE
- AUTO-STOP FUNCTION



## BM-840T

### FEATURES

- **MICROCASSETTE SYSTEM** uses easy to obtain, easy to store microcassettes for recording and playback convenience
- **3-FUNCTION FOOT CONTROL AND LISTENING DEVICE** are supplied and let the transcriptionist hear the tape while changing the mode from Play to Rewind to Fast Forward without removing hands from the keyboard
- **2-SPEED OPERATION** is compatible with Sony two-speed microcassette recorders, for maximum dictating and transcribing versatility
- **LCD TAPE COUNTER** provides a highly visible 3-digit indication of tape position for locating specific dictation
- **FULLY ADJUSTABLE AUTOMATIC SECRETARIAL REVERSE** automatically replays the last part of the dictation whenever the user stops transcribing, to prevent lost dictation, and lets the operator adjust how much to rewind so tape resumes at the most desirable point prior to where it stopped
- **SPEED/TONE/VOLUME CONTROLS** are individual slider type, front-panel mounted, to allow easy one-finger adjustment for transcribing convenience
- **END-OF-TAPE ALARM** signals when the tape end is reached
- **BUILT-IN PLAYBACK SPEAKER** is useful when one or more persons wishes to listen to the recording without the need to wear earphones
- **BUILT-IN ERASE** may be activated to automatically erase recordings while rewinding the microcassette
- **AUTO-STOP FUNCTION** stops the tape in Fast Forward and Rewind modes when End-of-Document, Electronic Indexes, and other special instruction signals on the tape are reached
- **CASSETTE WINDOW** enables the user to view and confirm tape movement

### SPECIFICATIONS

**TAPE SYSTEM:** 4 track, 2 channel monaural microcassette

**TAPE SPEEDS:** 2.4cm/sec, 1.2cm/sec

**FAST WINDING TIME:** Approx. 1 min 50 sec with MC-60BM cassette @ 2.4cm/sec

**FREQUENCY RESPONSE:** 200 - 6000Hz (2.4cm/sec)  
200 - 4000Hz (1.2cm/sec)

**SPEAKER:** 2 1/4" (57mm) dia.

**POWER OUTPUT:** 350mW (at 10% THD)

**POWER REQUIREMENTS:** 9V with AC-980 AC Adaptor supplied

**CURRENT DRAIN:** Approx. 140mA  
1.4W with supplied AC Adaptor

**DIMENSIONS (WHD):** 7 7/8" x 2 7/8" x 9 3/4"  
(200 x 70 x 245mm)

**WEIGHT:** 2 lbs 11 oz (1.2kg)

**SUPPLIED ACCESSORIES:** AC-980 9V AC Adaptor  
3-Function Foot Control  
Listening Device

**OPTIONAL ACCESSORIES:** MC-60BM Microcassettes

---

©1996 Sony Electronics Inc.

Reproduction in whole or in part without written permission is prohibited. All rights reserved.  
Features and specifications are subject to change without notice. Non-metric weights and measures are approximate.  
Sony is a trademark of Sony.

# SONY®

Sony Electronics Inc.  
1 Sony Drive  
Park Ridge, New Jersey 07656  
<http://www.sony.com>

FEATURES AND  
SPECIFICATIONS  
SUBJECT TO CHANGE  
WITHOUT NOTICE

Printed in USA 1/96