

DAV-DX155/DX255

SERVICE MANUAL

Ver. 1.0 2006.02

US Model
Canadian Model
DAV-DX155/DX255
E Model
Australian Model
DAV-DX155

- DAV-DX155/DX255 are composed of following models.
As service manuals are issued for each component model, please refer to them.

COMPONENT MODEL NAME

	DAV-DX155	DAV-DX255
COMPACT DISCDECK RECEIVER	HCD-DX155	HCD-DX255
FRONT SPEAKER	SS-TS52	
SURROUND SPEAKER	SS-TS51	
CENTER SPEAKER	SS-CT51	
SUB SPEAKER	SS-WS52	SS-WS52B

- Abbreviation
AUS : Australian model
CND : Canadian model
E3 : 240V AC area in E model
SP : Singapore model

PARTS LIST

Part No.	Description	Remarks
	ACCESSORIES *****	
1-479-641-11	COMMANDER, STANDARD (RM-ADU003)(Including Battery Cover)	
1-501-721-13	ANTENNA, LOOP (AM)	
1-542-670-11	MEASUREMENT MIC (MONO)	
1-751-619-23	CORD, CONNECTION (VIDEO)(2.5m YELLOW)	
1-793-184-21	CONNECTOR (F TYPE ADAPTOR) (FM)	
1-831-478-11	CORD (WITH CONNECTOR) (SPEAKER) (DX155)	
1-831-478-21	CORD (WITH CONNECTOR) (SPEAKER) (DX255)	
2-639-385-01	FOOT (For SPEAKERS)	
2-661-595-11	MANUAL, INSTRUCTION (ENGLISH)	
2-661-595-21	MANUAL, INSTRUCTION (FRENCH)	(CND, E3, SP)
2-661-595-31	MANUAL, INSTRUCTION (SPANISH) (SP)	
2-661-595-41	MANUAL, INSTRUCTION (TRADITIONAL CHINESE)(SP)	
2-661-595-51	MANUAL, INSTRUCTION (ARABIC) (E3)	

DVD HOME THEATRE SYSTEM

9-887-097-01
2006B16-1
© 2006.02

Sony Corporation
Home Audio Division
Published by Sony Techno Create Corporation

SONY®

REVISION HISTORY

Clicking the version allows you to jump to the revised page.

Also, clicking the version at the upper right on the revised page allows you to jump to the next revised page.

[illegible]