

English

The system incorporates High-Definition Multimedia Interface (HDMI) technology. The HDMI-related functions on the system have been improved and the THEATRE SYNC function can be also used with the HDMI connection.

By pressing	Button	TV's input source
TV/VIDEO	AUDIO	HDMI1
	SUBTITLE	HDMI2
	ANGLE	HDMI3
	PICTURE NAVI	HDMI4
	WOOFER	HDMI5

For details about the THEATRE SYNC function, refer to page 65 of the Operating Instructions.

Français

La chaîne intègre la technologie High-Definition Multimedia Interface (HDMI). Les fonctions relatives au HDMI ont été améliorées sur cette chaîne et la fonction THEATRE SYNC peut aussi être utilisée avec une connexion HDMI.

En appuyant sur	Touche	Source d'entrée du téléviseur
TV/VIDEO	AUDIO	HDMI1
	SUBTITLE	HDMI2
	ANGLE	HDMI3
	PICTURE NAVI	HDMI4
	WOOFER	HDMI5

Pour le détail sur la fonction THEATRE SYNC, reportez-vous à la page 70 du mode d'emploi.