



ATTACHING THE FERRITE CORE FRC-100 (cat # 8700-900)

When using an optional remote cord (RC-1000S or RC-1000L), or when operating the camera with the optional DiIMAGE Capture software, the cord and USB cable must have the supplied ferrite core (FRC-100) attached. The ferrite core reduces harmful interference.



Slide a thin blunt object under the two latches on the core to open it.



The core must be placed on the end of the cable that is connected to the camera as shown on the right.

Place the core around the cable and close. Confirm the latches on the core have caught.

