

Using an External Mouse with a Sony Notebook Computer

You can use either an external PS/2 or serial port mouse with both the notebook and docking stations. Turn off the computer, plug in the mouse and restart the computer. It will detect the mouse and activate it.

When an external PS/2 mouse is attached, the Touchpad can be disabled. To do this, do the following:

1. Click on the Start button.
2. Select Sony Folder.
3. Select Sony Utilities.
4. Select Sony Notebook Setup.
5. Click on the tab titled Touchpad.
6. Click the radio button labeled "Disable Touchpad."
7. Click on Apply, then OK.

You must be using a PS/2 mouse to disable the Touchpad. If you are using a serial port mouse the Touchpad will not disable.

INTELLIMOUSE NOTE: When attached as a PS/2 device, the Microsoft Intellimouse may not work correctly when used with Sony notebooks.

In order to gain full use of the Intellimouse, use it as a serial device. Use the PS/2-to-Serial Adapter included with the mouse.