

Monitor Self Test Procedures

January 7, 1998

CPD-15SX1,100SX

Raster Aging

Disconnect the video cable from the Computer
Leave the Power switch turned ON
Unplug the power cord
Plug the power cord in again.

Color Bar

NO

CPD-200SX

Raster Aging

Disconnect the video cable from the Computer
Turn on the monitor while holding down
the **← →** buttons keep holding for 3 seconds.

Color Bar

NO

CPD-15SF1,17SF1

Raster Aging

Disconnect the video cable from the Computer
Turn Power off
Push and hold the Power switch ON for 2 seconds

Color Bar

NO

GDM-17SE1,20SE1

Raster Aging

Disconnect the video cable from the Computer
Wait until the light turns amber
Hold down the CTRL button and Power switch for 3 seconds

Color Bar

NO

CPD-15SF2,17SF2,100VS

Raster Aging

Disconnect the video cable from the Computer
Hold the Power switch ON for 2 seconds.

Color Bar

Disconnect the video cable from the Computer
Hold the Power switch ON for 5 seconds.

CPD-100SF,200SF

Raster Aging

Disconnect the video cable from the Computer
Hold the Power switch ON for 2 seconds.

Color Bar

Disconnect the video cable from the Computer
Hold the Power switch ON for 5 seconds.

CPD-20SF2,300SF

Raster Aging

Disconnect the video cable from the Computer
Leave the Power switch turned ON
When the light turns Amber
Press and hold the OPTION button for 2 seconds

Color Bar

Disconnect the video cable from the Computer
Leave the Power switch turned ON
When the light turns Amber
Press and hold the CONTRAST + button for 2 seconds

GDM-17SE2T

Raster Aging

Disconnect the video cable from the Computer
Leave the Power switch turned ON
When the light turns Amber
Press and hold the OPTION button for 2 seconds

Color Bar

Disconnect the video cable from the Computer
Leave the Power switch turned ON
When the light turns Amber
Press and hold the CONTRAST + button for 2 seconds

GDM-20SE2T

Raster Aging

Disconnect the video cable from the Computer
Leave the Power switch turned ON
When the light turns Amber
Press and hold the OPTION button for 2 seconds

Color Bar

Disconnect the video cable from the Computer
Leave the Power switch turned ON
When the light turns Amber
Press and hold the CONTRAST + button for 2 seconds

CPD-220VS,120VS

Raster Aging

Disconnect the video cable from the Computer
Hold the Power switch ON for 4 seconds.

Color Bar

Disconnect the video cable from the Computer
Hold the Power switch ON for 8 seconds.

GDM-W900

Raster Aging

Disconnect the video cable from the Computer
Leave the Power switch turned ON
When the light turns Amber
Press and hold the OPTION button for 2 seconds

Color Bar

Disconnect the video cable from the Computer
Leave the Power switch turned ON
When the light turns Amber
Press and hold the CONTRAST + button for 2 seconds